

SERVICE MANUAL

RA-2 CHASSIS

MODEL COMMANDER DEST. CHASSIS NO.

KP-46C36 RM-Y136A US SCC-K90C-A

KP-48S35 RM-Y136A US SCC-K90B-A
 Canadian SCC-N22A-A


KP-53S35 RM-Y136A US SCC-K90A-A
 Canadian SCC-N22B-A

KP-61S35 RM-Y136A US SCC-K90D-A


MODEL COMMANDER DEST. CHASSIS NO.



RM-Y136A



KP-46C36/48S35/53S35



KP-61S35



996514401



※ Please file according to model size.■

46 48 53 61

COLOR REAR VIDEO PROJECTOR
SONY®

SPECIFICATIONS

Projection system	3 picture tubes, 3 lenses, horizontal in-line system
Picture tube	7 inch high-brightness monochrome tubes (6.3 raster size), with optical coupling and liquid cooling system
Projection lenses	High performance, large-diameter hybrid lens F1.1
Screen size (measured diagonally)	
	KP-46C36 46 inches
	KP-48S35 48 inches
	KP-53S35 53 inches
	KP-61S35 61 inches
Television system	American TV standards
Channel coverage	VHF: 2 - 13 / UHF: 14 - 69 / CATV: 1 - 125
Antenna	75 ohm external antenna terminal for VHF/UHF
Inputs/output	VIDEO IN 1 S VIDEO (4-pin mini DIN): Y: 1 Vp-p, 75-ohms unbalanced, sync negative C: 0.286 Vp-p (Burst signal) 75 ohms VIDEO (phono jack): 1 Vp-p, 75-ohms unbalanced, sync negative AUDIO (phono jacks): 500 mVrms (100% modulation) Impedance: 47 kilohms VIDEO IN 2 (for KP-48S35/53S35/61S35) VIDEO IN 3 (for KP-46C36 only) VIDEO (phono jacks): 1 Vp-p, 75-ohms unbalanced, sync negative AUDIO (phono jacks): 500 mVrms (100% modulation) Impedance: 47 kilohms

MONITOR OUT

VIDEO (phono jack): 1 Vp-p, 75-ohms unbalanced, sync negative
 AUDIO (phono jacks): 500 mVrms (100% modulation), Impedance: 10 kilohms
 AUDIO OUT (phono jacks): 500 mVrms (100% modulation) Impedance: 5 kilohms

Speaker Full range speaker 100 mm (3.9 inches) diameter

Speaker output 10 W x 2

Power requirement 120 V, 60 Hz

Power consumption 165 W
 Standby mode: 3 W

	Dimensions(W/H/D)	Mass
KP-46C36	1,066 x 1,306 x 563 mm (42 x 51 1/2 x 22 1/4 inches)	65 kg (143 lbs 5 oz)
KP-48S35	1,106 x 1,337 x 571 mm (43 3/8 x 52 3/8 x 22 1/2 inches)	67 kg (147 lbs 11 oz)
KP-53S35	1,218 x 1,413 x 614 mm (48 x 55 3/8 x 24 1/4 inches)	69 kg (152 lbs 1 oz)
KP-61S35	1,338 x 1,506 x 642 mm (52 3/4 x 59 3/8 x 25 3/8 inches)	122 kg (268 lbs 15 oz)

Supplied accessories

Remote control RM-Y136A (1)
 Size AA (R6) battery (2)

Optional accessories

U/V mixer EAC-66
 Connecting cables RK-74A, VMC-810S/820S, YC-15V/30V, VMC-720M
 High-contrast protective screen
 SCN-46X1 (For KP-46C36)
 SCN-48X2 (For KP-48S35)
 SCN-53X2 (For KP-53S35)
 SCN-61X2 (For KP-61S35)

Design and specifications are subject to change without notice.

(CAUTION)

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

WARNING!!

AN ISOLATION TRANSFORMER SHOULD BE USED DURING ANY SERVICE TO AVOID POSSIBLE SHOCK HAZARD, BECAUSE OF LIVE CHASSIS.
 THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO THE AC POWER LINE.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK Δ ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL FOR SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL FOR SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

(ATTENTION)

APRES AVOIR DECONNECTE LE CAP DE L'ANODE, COURT-CIRCUITER L'ANODE DU TUBE CATHODIQUE ET CELUI DE L'ANODE DU CAP AU CHASSIS METALLIQUE DE L'APPAREIL, OU AU COUCHE DE CARBONE PEINTE SUR LE TUBE CATHODIQUE OU AU BLINDAGE DU TUBE CATHODIQUE.

ATTENTION!!

AFIN D'EVITER TOUT RESQUE D'ELECTROCUTION PROVENANT D'UN CHÂSSIS SOUS TENSION, UN TRANSFORMATEUR D'ISOLEMENT DOIT ETRE UTILISÉ LORS DE TOUT DÉPANNAGE. LE CHÂSSIS DE CE RÉCEPTEUR EST DIRECTEMENT RACCORDÉ À L'ALIMENTATION SECTEUR.

ATTENTION AUX COMPOSANTS RELATIFS À LA SÉCURITÉ!!

LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET PAR UNE MARQUE Δ SUR LES SCHÉMAS DE PRINCIPE, LES VUES EXPLOSÉES ET LES LISTES DE PIÈCES SONT D'UNE IMPORTANCE CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT. NE LES REMPLACER QUE PAR DES COMPOSANTS SONY DONT LE NUMÉRO DE PIÈCE EST INDIQUÉ DANS LE PRÉSENT MANUEL OU DANS DES SUPPLÉMENTS PUBLIÉS PAR SONY. LES RÉGLAGES DE CIRCUIT DONT L'IMPORTANCE EST CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT SONT IDENTIFIÉS DANS LE PRÉSENT MANUEL. SUIVRE CES PROCÉDURES LORS DE CHAQUE REMPLACEMENT DE COMPOSANTS CRITIQUES, OU LORSQU'UN MAUVAIS FONCTIONNEMENT EST SUSPECTÉ.

SAFETY CHECK-OUT (US Model only)

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
4. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
5. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
6. Check the line cords for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
7. Check the B+ and HV to see if they are at the values specified. Make sure your instruments are accurate; be suspicious of your HV meter if sets always have low HV.
8. Check the metal trim, metallized knobs, screws, and all other exposed metal parts for AC leakage.
Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufactures' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)

HOW TO FIND A GOOD EARTH GROUND

A cold-water pipe is guaranteed earth ground; the cover-plate retaining screw on most AC outlet boxes is also at earth ground. If the retaining screw is to be used as your earth-ground, verify that it is at ground by measuring the resistance between it and a cold-water pipe with an ohmmeter. The reading should be zero ohms. If a cold-water pipe is not accessible, connect a 60-100 watts trouble light (not a neon lamp) between the hot side of the receptacle and the retaining screw. Try both slots, if necessary, to locate the hot side of the line, the lamp should light at normal brilliance if the screw is at ground potential. (See Fig. B)




Fig. A. Using an AC voltmeter to check AC leakage.




Fig. B. Checking for earth ground.

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
1. GENERAL					
	Step 2 : Hookup	5	2-5-2.	Screen Frame Assy Removal (KP-61S35)	24
	Step 3 : Setting up the remote control	8	2-6-1.	Mirror Cover Assy Removal (KP-46C36/48S35/53S35)	25
	Step 4 : Setting up the projection TV automatically (AUTO SET UP)	9	2-6-2.	Reflection Mirror Removal (KP-61S35)	25
	Changing the menu language	11	2-7.	High-Voltage Cable Installation and Removal	25
	Watching the TV	11	2-8.	Picture Tube Removal	25
	Watching two programs at one time - PIP	12	2-9-1.	Service stay Assy How to use and Carry Back Service stay Assy	26
	Freezing the picture (FREEZE)	13	2-9-2.	Picture Tube Bracket Assy Removal	26
	Adjusting the picture (VIDEO)	13	2-9-3.	Setting of Service stay Assy (KP-46C36/48S35/53S35)	27
	Adjusting the color temperature (TRINITONE)	14	2-9-4.	Install a Chassis Assy	27
	Selecting the video mode (VIDEO)	14	3. SET-UP ADJUSTMENTS		29
	Adjusting the sound (AUDIO)	14	4. SAFETY RELATED ADJUSTMENTS		49
	Using audio effect (SURROUND)	15	5. CIRCUIT ADJUSTMENTS		52
	Selecting stereo or bilingual programs (MTS)	15	6. DIAGRAMS		
	Setting the speaker switch (SPEAKER)	15	6-1.	Block Diagrams (1)	56
	Setting audio out (AUDIO OUT)	16		Block Diagrams (2)	59
	Setting daylight saving time (DAYLIGHT SAVING)	16		Block Diagrams (3)	61
	Setting the clock (CURRENT TIME SET)	16	6-2.	Frame Schematic Diagram	63
	Setting the timer to turn the projection TV on and off (ON/OFF TIMER)	17	6-3.	Circuit Boards Location	66
	Customizing the channel names (CHANNEL CAPTION) ..	17	6-4.	Printed Wiring Boards and Schematic Diagrams	66
	Blocking out a channel (CHANNEL BLOCK)	18		• A Board	67
	Setting your favorite channels (FAVORITE CHANNEL) .	18		• HA, P Boards	74
	Setting video labels (VIDEO LABEL)	18		• ZR, ZG Boards	77
	Setting Caption Vision (CAPTION VISION)	19		• G Board	83
	Operating video equipment	19		• CR,CG,CB Boards	87
	Operating a cable box or DBS receiver	20	6-5.	Semiconductors	91
	Troubleshooting	21	7. EXPLODED VIEWS		
	Index to parts and controls	21	7-1.	Cover (KP-46C36/48S35/53S35)	93
2. DISASSEMBLY			7-2.	Cover (KP-61S35)	94
2-1.	Rear Board Removal	23	7-3.	Chassis	95
2-2.	Chassis Assy Removal	23	7-4.	Picture Tube	96
2-3.	Service Position	23	8. ELECTRICAL PARTS LIST		97
2-4-1.	HA Board Removal (KP-46C36)	24			
2-4-2.	HA Board Removal (KP-48S35/53S35/61S35)	24			
2-5-1.	Beznet Assy Removal (KP-46C36/48S35/53S35) ..	24			

SECTION 1 GENERAL


The operating instructions mentioned here are partial abstracts from the Operating Instruction Manual. The page numbers of the Operating Instruction Manual remain as in the manual.

Step 2: Hookup

Although you can use either an indoor or outdoor antenna with your projection TV, we recommend that you connect an outdoor antenna or a cable TV system to get better picture quality.

Connecting an antenna

Connect your antenna cable to the VHF/UHF antenna terminal. If you cannot connect your antenna cable directly to the terminal, follow one of the instructions below depending on your cable type.




Notes

- Most VHF/UHF combination antennas have a signal splitter. Remove the splitter before attaching the appropriate connector.
- If you use the U/V mixer, snow and noise may appear in the picture when viewing cable TV channels over 37.


Connecting an antenna/cable TV system without a VCR

To cable or antenna




To cable box

If your cable company requires you to connect a cable box, make the connection as follows:



To cable box and cable




Pay cable TV systems use scrambled or encoded signals requiring a cable box* in addition to the normal cable connection.

- * The cable box will be supplied by the cable company.

Note

- You cannot watch the signal through an AUX connector as a window picture.

To cable and antenna



Note

- Do not connect anything to the TO CONVERTER connector in this case.

Connecting an antenna/cable TV system with a VCR

For details on connection, see your VCR instruction manual.


Before making the connection, disconnect the AC power cords of the equipment to be connected.

To a conventional VCR


Notes

- For models KP-46C36, you can connect the audio and video outputs of the VCR to VIDEO 3 IN jacks instead of the VIDEO 2 IN jacks.
- To connect a monaural VCR, connect the audio output of the VCR to AUDIO-L (MONO) of VIDEO 1/2/3 IN on the projection TV.

Without a cable box




With a cable box




To an S video equipped VCR

If your VCR has an S VIDEO output connector, make the following connections.
Whenever you connect the cable to the S VIDEO input connector, the projection TV automatically receives S video signals.

Without a cable box



With a cable box




Note

- Video signals are composed of Y (luminance) and C (chroma) signals. The S connection sends the two signals separately preventing degradation, and gives better picture quality compared to conventional connections.

Connecting a DBS receiver

For details on connection, see the instruction manual of the DBS (Digital Broadcasting Satellites) receiver.


To a projection TV



Note

- You can use the S VIDEO connector or the composite video connector for the video connection.


To a projection TV and VCR



Connecting a camcorder

■ KP-46C36 only

Use this connection to view a camcorder picture.




Note

- To connect a monaural camcorder, connect the audio output of the camcorder to AUDIO-L (MONO) of VIDEO 2 INPUT on the projection TV.

Connecting an audio system

When connecting audio equipment, see page 28 for more information.




Note

- You can adjust the bass, treble, and balance, or select surround (page 26) or an MTS (Multichannel TV Sound) mode (page 27) with the supplied remote control.

Connecting two VCRs for tape editing using MONITOR OUT

You can record input images displayed on the screen.


This type of connection should be used only when you connect from the line input of one VCR, and from the line output of a second VCR.



Notes


- Do not change the input signal while editing through MONITOR OUT, or the output signal will also change.
- You can use the S video jack to connect a VCR for playback and the composite video connector to connect a VCR for recording.
- For models KP-46C36, you can connect the audio and video outputs of the VCR to VIDEO 3 IN jacks instead of the VIDEO 2 IN jacks.


- When connecting a single VCR to the projection TV, do not connect the MONITOR OUT to the VCR's line input, while at the same time connecting from the projection TV's VIDEO IN connectors to the VCR's line output, as shown below.



Connecting a Sony SAVA series speaker system

If you have a Sony SAVA series speaker system, connect your speakers to the AUDIO (VAR/FIX) OUT jacks on the rear of the projection TV with the audio cable supplied with the speakers. You can take advantage of the speakers' Dolby Pro Logic® surround system and super woofer mode, and control them with the supplied remote control. When connecting a Sony SAVA series speaker system, see page 27 for more information.

* Manufactured under license from Dolby Laboratories Licensing Corporation. Additionally licensed under Canadian patent number 1,037,877. "Dolby," the double-D symbol  and "Pro Logic" are trademarks of Dolby Laboratories Licensing Corporation.



Step 3: Setting up the remote control

Inserting batteries

Insert two size AA (R6) batteries (supplied) by matching the + and - on the battery to the diagram inside the battery compartment.



Notes

- Under normal conditions, batteries will last up to six months. If the remote control does not operate properly or the indicators of the buttons on the remote control do not light up, the batteries may be worn out. When replacing batteries, replace both of them with new ones.
- Do not mix old batteries with new ones or mix different types of batteries together.
- If the electrolyte inside the battery should leak, wipe the contaminated area of the battery compartment with a cloth and replace the old batteries with new ones. To prevent the electrolyte from leaking, remove the batteries when you don't plan to use the remote control for a long period of time.
- Do not handle the remote control roughly. Do not drop it, step on it, or let it get wet.
- Do not place the remote control in direct sunlight, near a heater, or where the humidity is high.

Getting to know buttons on the remote control


Names of buttons on the remote control are indicated in different colors to represent the available functions.

Button color

Transparent TV/VCR/DBS/Cable box function buttons. Press the appropriate function button first to change the remote control's function.
Green Buttons relevant to power operations.

Label color

White TV/VCR/DBS/Cable box operation buttons.
Yellow PIP operation buttons.
Blue DBS operation buttons.




Step 4: Setting up the projection TV automatically

(AUTO SET UP)

You can set up your projection TV easily by using the AUTO SET UP feature. It presets all the receivable channels, adjusts the convergence and changes the on-screen menu language. To set up the projection TV manually, see "Adjusting convergence" (page 16), "Setting cable TV on or off" (page 17), "Presetting channels" (page 18) and "Changing the menu language" (page 18).

If the projection TV is set to a video input, you cannot perform AUTO SET UP. Press TV/VIDEO so that a channel number appears.




Before you start using AUTO SET UP, be sure to connect the antenna or cable to the projection TV (see page 6).

1 Press POWER to turn the projection TV on.




2 Press SETUP on the front of the projection TV.

AUTO SET UP screen appears.





3 Press CHANNEL +/- or VOLUME + to select the on-screen menu language.

If you prefer Spanish or French to English, you can change the on-screen menu language.





All of the menus will be set to the factory preset condition in the selected language.


4 Press VOLUME - to start AUTO SET UP.



5 Press CHANNEL + to preset channels.



"AUTO PROGRAM" appears on the screen and the TV starts scanning and presetting channels automatically. When all the receivable channels are stored, "AUTO PROGRAM" disappears and the following menu appears. If the projection TV receives cable TV channels, CABLE is set to ON automatically.





To exit AUTO PROGRAM
Press any button.


6 Adjust convergence.

(1) Press CHANNEL +.


The CONVERGENCE adjustment screen appears.



(2) Press TV/VIDEO to select RED or BLUE.




(3) Using CHANNEL +/- or VOLUME +/-, move the line until it converges with the center green line.



To move horizontal line up/down, press CHANNEL +/-.
To move vertical line right/left, press VOLUME +/-.

(4) Repeat steps (2) and (3) to adjust the other lines until all three lines converge and are seen as a white cross.



Note

- Using the AUX connector, press TV (black button) first and make sure that "AUX" is displayed beside the channel number on the screen. Then follow the steps 2 to 6 above to perform AUTO SET UP.


To preview the main functions (DEMO)

Press TV/VIDEO on the projection TV in step 4. The functions and menus are displayed one by one.


To exit DEMO
Press any button.

Erasing or adding channels

After AUTO SET UP, you can erase unnecessary channels or add the channels you want. Preset channels during the day rather than late at night, when some channels may not be broadcasting.



1 Press TV (FUNCTION).



2 Press MENU.

The main menu appears.



3 Press + or - to select, and press + or -.

The SET UP menu appears.



- 4 Press \uparrow or \downarrow to select CHANNEL ERASE/ADD, and press \odot .
The CHANNEL ERASE/ADD menu appears.



5 Erase and/or add channels:

To erase an unwanted channel

- Make sure the cursor (\blacktriangleright) is beside ERASE.
- Press CH \uparrow or \downarrow or the 0-9 buttons to select the channel you want to erase, and press ENTER.




- (3) Press \odot .

The “-” indication appears beside the channel number, showing that the channel is erased from the preset memory.



To add a channel that you want

- Press \uparrow or \downarrow to move the cursor (\blacktriangleright) to ADD.
- Press the 0-9 buttons to select the channel you want to add, and press ENTER.



- (3) Press \odot .

The “+” indication appears beside the channel number, showing that the channel is added to the preset memory.



- 6 To erase and/or add other channels, repeat step 5.

7 Press MENU to return to the original screen.



Notes

- If you erase or add a VHF or UHF channel, the cable TV channel with the same number is also erased or added, and vice versa.
- Erasing and adding channels is also available for the AUX input.

Adjusting convergence (CONVERGENCE)


The projection tube image appears on the screen in three layers (red, green and blue). If they do not converge, the color is poor and the picture blurs. To correct this, adjust convergence. You do not have to do this procedure if you perform AUTO SET UP (page 14). Do this procedure only when you want to adjust it manually.

1 Press MENU.

2 Press \uparrow or \downarrow to select \mathcal{C} , and press \odot .

3 Press \uparrow or \downarrow to select CONVERGENCE, and press \odot .

The CONVERGENCE adjustment screen appears.



- 4 Press \uparrow , \downarrow , \leftarrow , or \rightarrow to move the cursor (\blacktriangleright) to the symbol showing the line you want to adjust, and press \odot .



- +RED: Red vertical and horizontal line (left/right/up/down adjustment)
- +BLUE: Blue vertical and horizontal line (left/right/up/down adjustment)

- 5 Press \uparrow , \downarrow , \leftarrow , or \rightarrow to move the line until it converges with the center green line, and press \odot .



To move	Press
Up	\uparrow
Down	\downarrow
Right	\rightarrow
Left	\leftarrow

- 6 Repeat steps 4 and 5 to adjust the other lines until all three lines converge and are seen as a white cross.

- 7 Press MENU to return to the original screen.

Setting cable TV on or off

If you have connected the projection TV to a cable TV system, set CABLE to ON (the factory setting). If not, set CABLE to OFF.

You do not have to do this procedure if you perform AUTO SET UP (page 14). Do this procedure only when you want to set it manually.

1 Press MENU.

2 Press \uparrow or \downarrow to select \mathcal{C} , and press \odot .

3 Set CABLE to ON or OFF:

- Press \uparrow or \downarrow to move the cursor (\blacktriangleright) to CABLE, and press \odot .
- Press \uparrow or \downarrow to select ON or OFF, and press \odot .




4 Press MENU to return to the original screen.

Note

- If CABLE appears in gray, the projection TV is set to a video input and you cannot select CABLE. Press TV (black button) so that a channel number appears.

Presetting channels

You can preset TV channels easily by using the AUTO PROGRAM feature. You do not have to do this procedure if you perform AUTO SET UP (page 14). Do this procedure only when you want to set it manually.

- 1 Press MENU.
- 2 Press \uparrow or \downarrow to select , and press \odot .
- 3 Press \uparrow or \downarrow to select AUTO PROGRAM, and press \odot .



"AUTO PROGRAM" appears on the screen and the projection TV starts scanning and presetting channels automatically. When all the receivable channels are stored, "AUTO PROGRAM" disappears and the lowest numbered channel is displayed.

- 4 Press MENU to return to the original screen.


To exit AUTO PROGRAM
Press any button.

Notes

- If the AUTO PROGRAM menu appears in gray, the projection TV is set to a video input and you cannot select AUTO PROGRAM. Press TV (black) button so that a channel number appears.
- Presetting channels is also available for the AUX input.

Changing the menu language

If you prefer Spanish or French to English, you can change the menu language. You do not have to do this procedure if you select the language during AUTO SET UP (page 14). Do this procedure only when you want to set it manually.

- 1 Press MENU.
- 2 Press \uparrow or \downarrow to select , and press \odot .
- 3 Press \uparrow or \downarrow to select LANGUAGE, and press \odot .



- 4 Press \uparrow or \downarrow to select your favorite language, "ENGLISH", "ESPAÑOL," or "FRANÇAIS" and press \odot .




- 5 Press MENU to return to the original screen.

Note

- Certain parts of the Spanish or French menus remain in English.

Operations

Watching the TV




- 1 Press TV (POWER) to turn on the projection TV. The TIMER/STANDBY indicator flashes until the picture appears.



If "VIDEO" appears on the screen, press TV (black button) so that a channel number appears.

- 2 Press TV (FUNCTION).



Once you press TV (FUNCTION), the projection TV function is set unless another function button is pressed.

- 3 Select the channel you want:

To select a channel directly

Press the 0-9 buttons, and press ENTER. For example, to select channel 10, press 1, 0 and ENTER.




To scan through channels

Press CH +/- until the channel you want appears.



The channel can also be selected without pressing ENTER.

- 4 Press VOL +/- to adjust the volume.



Switching quickly between two channels

You can use the JUMP button to switch or "jump" back and forth between two channels.

Press JUMP.



Pressing JUMP again switches the channel back to the one you selected last.

Note

- You cannot jump to channels you scanned through using the CH +/- buttons.

Muting the sound

Press MUTE.

"MUTING" appears on the screen.




To restore the sound, press MUTING again, or press VOL +.

Displaying on-screen information

Press **DISPLAY** repeatedly until the desired display appears.

Each time you press **DISPLAY**, the display changes as follows:



- * Channel number, the current time, channel caption (if set), and MTS mode (if SAP is selected) are displayed. SAP indication disappears after three seconds.
- ** Some programs are broadcast with XDS (Extended Data Service) which shows a network name, program name, program type, program length, call letters, and time of the show. When you select XDS with the **DISPLAY** button, this information will be displayed on the screen if the broadcaster offers this service.
- *** Some programs are broadcast with Caption Vision. When you select Caption Vision with the **DISPLAY** button, Caption Vision will be displayed on the screen if the broadcaster offers this service. (See page 34 for selecting Caption Vision.)

To cancel the display, press **DISPLAY** repeatedly until "DISPLAY OFF" appears. "DISPLAY OFF" goes off after three seconds.

Setting the Sleep Timer

The projection TV stays on for the length of time you specify and then shuts off automatically.

Press **SLEEP** repeatedly until the time (minutes) you want appears.

Each time you press **SLEEP**, the time-changes as follows:

30 → 60 → 90 → SLEEP OFF



To cancel the Sleep Timer, press **SLEEP** repeatedly until "SLEEP OFF" appears, or turn off the projection TV.

Watching a video input picture

Press **TV/VIDEO** repeatedly until the desired video input appears.

Each time you press **TV/VIDEO**, the display changes as follows:

■ **KP-41T35/46C36 only**

TV → VIDEO 1 → VIDEO 2 → VIDEO 3

■ **KP-48S35/53S35/61S35 only**

TV → VIDEO 1 → VIDEO 2

TV/VIDEO

To return to the TV picture, press **TV** (black button) so that a channel number appears.

Changing the VHF/UHF input to the AUX input

Press **TV** (black button).


"AUX" appears beside the channel number.



Pressing **TV** (black button) again switches back to the VHF/UHF input.

Watching two programs at one time — PIP


The Picture-in-Picture (PIP) feature allows you to watch both the main picture and a window picture simultaneously.




Use the yellow labelled buttons for PIP operations.

Displaying a window picture

Press **PIP**.



Press **PIP** again to display a smaller window picture.



To remove the window picture, press **PIP** again.

Note

- The window picture may be affected by the condition of the main picture.

Changing the window picture input mode

Press **TV/VIDEO** (yellow labelled button) to select the input mode.

Each time you press **TV/VIDEO** (yellow labelled button), "TV," "VIDEO 1," "VIDEO 2," and "VIDEO 3" (for KP-46C36 only)" appear in sequence.



A window picture will appear in the same input mode as the last time you used PIP.

Note

- If you connect your VCR without a cable box, your PIP input source is a VCR. If you connect your VCR with a cable box, your PIP input source is a VCR or cable box.

Listening to the sound of the window picture

Press **AUDIO**.

The display appears next to the PIP channel number for a few seconds, indicating that the window picture sound is being received.




The sound of the window picture is received.

To restore the main picture sound, press **AUDIO** again. The display moves to the main picture channel number.

Changing TV channels in the window picture


Press **CH +/-** (yellow labelled button).



Changing the position of the window picture

Press POSITION.


Each time you press POSITION, the window picture will move counterclockwise on the screen.



Swapping the main and window pictures

Press SWAP.

Each time you press SWAP, the images and sound from the main and window pictures switch places with another.




Note

- The channels being received through the AUX connector cannot be displayed as a window picture.

Freezing the picture (FREEZE)


The FREEZE feature is useful when you want to write down an information such as a recipe from a cooking program, a displayed address, or a phone number. The frozen picture changes as follows depending on whether the PIP function is used or not.



Press FREEZE.




When the PIP function is not being used



To remove the frozen window picture, press FREEZE again.


When the PIP function is being used



To cancel the frozen window picture, press FREEZE again.

Adjusting the picture (VIDEO)

When watching TV programs, you can adjust the picture to suit your taste. You can adjust the picture of video input(s) as well.



1 Press MENU.

2 Press + or - to select (M), and press (O).



3 Select the item you want to adjust.

For example:

(1) To adjust the brightness, press + or - to move the cursor (P) to BRIGHTNESS.



(2) Press (O).



4 Adjust the selected item:

(1) Press +, -, or - to adjust the item.



(2) Press (O).

The new setting appears in the VIDEO menu.



For details on each item, see "Description of adjustable items" below.

5 To adjust other items, repeat steps 3 and 4.

6 Press MENU to return to the original screen.

Description of adjustable items

Item	Press + or - to	Press + or - to
PICTURE	Decrease picture contrast and give soft color.	Increase picture contrast and give vivid color.
HUE	Make picture tones become purplish.	Make picture tones become greenish.
COLOR	Decrease color intensity.	Increase color intensity.
BRIGHTNESS	Darken the picture.	Brighten the picture.
SHARPNESS	Soften the picture.	Sharpen the picture.


To restore the factory settings

Press RESET after displaying and selecting the VIDEO menu.

All of the settings are restored to the factory settings.

Adjusting the color temperature (TRINITONE)

The TRINITONE feature controls the color temperature, permitting white balance preference adjustment without affecting skin tones.



- 1 Press MENU.
- 2 Press + or + to select and press .
- 3 Press + or + to select TRINITONE and press .



- 4 Press + or + to select NTSC STD, MEDIUM, or HIGH and press .



Choose	To
HIGH	a cool (bluish) white.
MEDIUM	a neutral white.
NTSC STD	a warm (reddish) white.

Selecting the video mode (VIDEO)

The video mode feature allows you to choose three different modes of picture settings. Choose the one that best suits the type of program that you want to watch.

- 1 Press MENU.
- 2 Press + or + to select , and press .
- 3 Press + or + to select MODE, and press .
- 4 Press + or + to select STANDARD, MOVIE, or SPORTS mode, and press .



Choose	To
STANDARD	Receive a standard picture.
MOVIE	Receive a finely detailed picture.
SPORTS	Receive a vivid, bright picture.


- 5 Press MENU to return to the original screen.

Note

- The settings for these modes can be adjusted in the VIDEO menu.

Adjusting the sound (AUDIO)

You can adjust the quality of the TV sound to suit your taste. You can adjust the sound of the video input(s) as well.



- 1 Press MENU.
- 2 Press + or + to select , and press .



- 3 Select the item you want to adjust.

For example:

- (1) To adjust bass, press + or + to move the cursor (►) to BASS.




- (2) Press .



- 4 Adjust the selected item:

- (1) Press +, +, +, or + to adjust the item.



- (2) Press .

The new setting appears in the AUDIO menu.



For details on each item, see "Description of adjustable items" below.

- 5 To adjust other items, repeat steps 3 and 4.

- 6 Press MENU to return to the original screen.

Description of adjustable items

Item	Press + or + to	Press + or + to
TREBLE	Decrease the treble response.	Increase the treble response.
BASS	Decrease the bass response.	Increase the bass response.
BALANCE	Emphasize the left speaker's volume.	Emphasize the right speaker's volume.

To restore the factory settings

Press RESET after displaying and selecting the AUDIO menu.

All of the settings are restored to the factory settings.


Note

- When SPEAKER (page 27) is OFF and AUDIO OUT (page 28) is in the FIXED condition, the volume, TREBLE, BASS, and BALANCE cannot be adjusted.

Using audio effect (SURROUND)

The audio effect (SURROUND) feature simulates sound reproduction with the atmosphere of a movie theater or a concert hall. Audio effect is only effective for stereo programs.

Using the \odot (audio effect) button



1 Press TV (FUNCTION).


2 Press \odot .

Each time you press the \odot button, the display changes as follows:

SURROUND → SURROUND OFF



Using the menu to set audio effect



1 Press MENU.

2 Press \uparrow or \downarrow to select \downarrow , and press \odot .

3 Press \uparrow or \downarrow to select EFFECT, and press \odot .



4 Press \uparrow or \downarrow to select the audio effect mode, and press \odot .



5 Press MENU to return to the original screen.

Selecting stereo or bilingual programs (MTS)

The Multichannel TV Sound (MTS) feature allows you to enjoy stereo sound or Second Audio Programs (SAP) of your choice. The initial setting is stereo sound (STEREO).



Press MTS repeatedly to select STEREO, SAP, or MONO.

STEREO → SAP → MONO

Choose	To
STEREO	Listen to stereo sound. The STEREO indicator on the projection TV lights up when a stereo broadcast is received.
SAP	Listen to bilingual programs. There is no sound when the SAP signal is not broadcasting.
MONO	Listen to monaural sound. Reduce noise during stereo broadcasts.

Note

- Stereo and SAP sounds are subject to program sources.


To set MTS using the menu

- Press MENU.
- Press \uparrow or \downarrow to select \downarrow , and press \odot .
- Press \uparrow or \downarrow to select MTS, and press \odot .
- Press \uparrow or \downarrow to select STEREO, SAP, or MONO.
- Press MENU to return to the original screen.

Setting the speaker switch (SPEAKER)

You may switch off the projection TV speakers when, for example, you want to listen to the sound through a stereo system.

If you connect the Sony SAVA series speaker system to the AUDIO (VAR/FDX) OUT connectors, you can take advantage of the speakers' surround sound and super woofer mode. After making the connections (page 12), set SPEAKER to SAVA SPEAKER, then adjust SURROUND MODE or SUPER WOOFER MODE.



1 Press MENU.

2 Press \uparrow or \downarrow to select \downarrow , and press \odot .

3 Press \uparrow or \downarrow to select SPEAKER, and press \odot .



4 Press \uparrow or \downarrow to select ON, OFF, or SAVA SP, and press \odot .



5 Press MENU to return to the original screen.

Choose	To
ON	Listen to the sound from the projection TV.
OFF	Turn off the projection TV speaker sound and listen to the projection TV's sound solely through the audio system speakers.
SAVA SP	Turn off the projection TV speaker sound and listen to the projection TV's sound through the Sony SAVA series speaker system. You can adjust volume, muting, surround modes, and super woofer mode with the remote control supplied with the projection TV.

To select surround sound or super woofer mode of the SAVA speaker system

After setting SPEAKER to SAVA SP, follow the procedure below.

Press \uparrow or \downarrow to select **SURROUND MODE** or **SUPER WOOFER MODE**, and press \rightarrow .

For details on each option, refer to the operating instructions of the speaker system.




Note

- This feature is only for Sony SAVA speaker system with an operation capability for KP-46C36, KP-48S35, KP-53S35, and KP-61S35.

Setting audio out (AUDIO OUT)

You can change AUDIO OUT to VARIABLE or FIXED when SPEAKER is set to OFF. AUDIO OUT is variable when SPEAKER is set to ON.



- Press **MENU**.
- Press \uparrow or \downarrow to select **J**, and press \rightarrow .
- Press \uparrow or \downarrow to select **AUDIO OUT**, and press \rightarrow .



- Press \uparrow or \downarrow to select **VARIABLE** or **FIXED**, and press \rightarrow .



VARIABLE: Sound output varied according to the projection TV settings. You can adjust the volume, bass, treble, and balance.

FIXED: Sound output is always fixed to a certain level. The volume, bass, treble, and balance are also fixed to the factory settings.

- Press **MENU** to return to the original screen.

Note

- If **AUDIO OUT** appears in gray, set **SPEAKER** to OFF.

Setting daylight saving time (DAYLIGHT SAVING)


If your area uses daylight saving time, change DAYLIGHT SAVING setting depending on the season, before setting the current time.

Daylight saving start

- After the first Sunday in April, set **DAYLIGHT SAVING** to YES. Current time setting (right column) automatically moves one hour ahead.

Daylight saving end

- After the last Sunday in October, set **DAYLIGHT SAVING** to NO. Current time setting automatically moves one hour back.



- Press **MENU**.
- Press \uparrow or \downarrow to select **DAYLIGHT SAVING**, and press \rightarrow .
- Press \uparrow or \downarrow to select **YES** or **NO**, and press \rightarrow .



- Press \uparrow or \downarrow to select **YES** or **NO**, and press \rightarrow .




Choose	To
YES	Set for daylight saving start.
NO	Set for daylight saving end.

- Press **MENU** to return to the original screen.

Setting the clock (CURRENT TIME SET)

Setting the clock enables you to turn the projection TV on and off with the timer. Make sure to set daylight saving time first.



- Press **MENU**.
- Press \uparrow or \downarrow to select **CURRENT TIME SET**, and press \rightarrow .



- Make sure the cursor (\rightarrow) is to the left of "---- AM," and press \rightarrow .



- Set the current day of the week and time.

(1) Press \uparrow or \downarrow to set the day of the week, and press \rightarrow .



(2) Set the hour and minutes in the same way as in step (1). When you press \rightarrow after setting the minutes, the clock starts.




- Press **MENU** to return to the original screen.

Setting the timer to turn the projection TV on and off

(ON/OFF TIMER)

You can set the projection TV to turn on and off at the times you specify. Make sure the clock is set correctly. If it is not, set the clock first (page 29).




- 1 Press **MENU**.
- 2 Press **+** or **-** to select **ON/OFF TIMER**, and press **ENTER**.
- 3 Press **+** or **-** to select **ON/OFF TIMER**, and press **ENTER**.



- 4 Press **ENTER** and enter the ON/OFF TIMER setting.

(1) Press **+** or **-** to set the day(s), and press **ENTER**.

Each time you press **+** or **-**, the days cycle as follows:
 EVERY SUN-SAT → EVERY MON-FRI → SUNDAY → ... → SATURDAY → EVERY SUNDAY → ... → EVERY SATURDAY



- (2) Press **+** or **-** to set the time (hour then minutes) that you want to turn on the projection TV, and press **ENTER**.



- (3) Press **+** or **-** to set the time duration, and press **ENTER**.

Each time you press **+**, the time duration increases by one hour up to a maximum of six hours.



- (4) Press **+** or **-** to select the channel, and press **ENTER**.



The **TIMER** indicator on the projection TV lights up.

- 5 To set the other program, press **ENTER**, and repeat step 4.
- 6 Press **MENU** to return to the original screen.

One minute before the projection TV turns off, the message "TV will turn off soon." is displayed on the screen.

To cancel the timer
 In step 3 or 4, press **RESET**.


Note

- If you unplug the projection TV or a power interruption occurs, the ON/OFF TIMER setting will be erased. Reset the current time, then set the timer.

Customizing the channel names

(CHANNEL CAPTION)

You can add a caption for up to 12 channels. This feature allows you to easily identify which channel you are watching. You can make your own caption.



- 1 Press **MENU**.
- 2 Press **+** or **-** to select **CHANNEL CAPTION**, and press **ENTER**.



- 3 Press **+** or **-** to select **CHANNEL CAPTION**, and press **ENTER**.



- 4 Press **ENTER** and press **+** or **-** to select the channel that you want to caption, and press **ENTER**.



- 5 Enter the letters (up to four) to caption the channel:


(1) Press **+** or **-** to select the first letter.

Each time you press **+** or **-**, the letter changes as follows:

0...9 → A...Z → /... (blank space)



- (2) Press **ENTER**.



- (3) Repeat steps (1) and (2) to select the remaining letters, and press **ENTER**.

- 6 Repeat steps 4 and 5 to caption other channels.

- 7 Press **MENU** to return to the original screen.

After you customize the channel, the channel caption appears green.

To erase a caption
 In step 5, press **RESET**.

Notes

- If the **CHANNEL CAPTION** menu appears in gray, the projection TV is set to a video input, and you cannot select **CHANNEL CAPTION**. Press **TV** (black button) so that a channel number appears.
- If more than 90 seconds elapse after you press a button, the menu disappears automatically.
- The channel caption feature is not available for the AUX input.

[REDACTED]
 [REDACTED]

Diagram of the control panel showing the RESET button and the MENU button.

-
- The diagram shows two identical circular control panels. Each panel has a central cross-shaped button, four rectangular buttons around the perimeter, and four small circular buttons at the top and bottom. In the left panel, a hand points to the top-left rectangular button. In the right panel, a hand points to the central cross-shaped button.

-

-

- 2
BLOCKED

32-EN | Operations

Setting your favorite channels



-

-

FAVORITE CHANNEL

► **MODE: AUTO**

1 **max**

4 **max**


4 **max**

8 **max**


► **MENU**

Use **[OK]** **[CD]** Exit **[EXIT]**

FAVORITE CHANNEL
► MODE: MANUAL
 1.
 2.
 3.
 4.
 5.
MENU
 Select a position.
 Use **Exit**




-



- ### Notes
- If the **FAVORITE CHANNEL** menu appears in gray, the projection TV is set to a video input and you cannot select **FAVORITE CHANNEL**.
 - If more than 90 seconds elapse after you press another button, the menu disappears automatically.
 - The favorite channel feature is not available for the AUX input.

A diagram of a control panel. It features a central oval button with a crosshair. Above it are three small circular buttons. To the left are two small rectangular buttons. To the right are two small rectangular buttons, one of which is labeled 'MENU'. Below the central button are two small rectangular buttons, each with a crosshair.

- 



-

Operations | 33-EN

[The following text is extremely faint and largely illegible due to poor scan quality. It appears to be a list or index of items.]

-



-



-



Each time you press \blacktriangle or \blacktriangledown , the label changes as follows:

VIDEO 1 (for all models)

VIDEO 1 \leftrightarrow VHS \leftrightarrow 8 mm \leftrightarrow BETA
 \uparrow
 DBS \leftrightarrow DVD \leftrightarrow S VIDEO \leftrightarrow LD

VIDEO 2 (for KP-46C36 only)

VIDEO 2 \leftrightarrow VHS \leftrightarrow 8 mm \leftrightarrow BETA
 \uparrow
 DBS \leftrightarrow DVD \leftrightarrow S VIDEO \leftrightarrow LD

VIDEO 3 (for KP-48S35/53S35/61S35 only)

VIDEO 3 \leftrightarrow VHS \leftrightarrow 8 mm \leftrightarrow BETA
 \uparrow
 DBS \leftrightarrow DVD \leftrightarrow LD

VIDEO 3 (for KP-46C36 only)

VIDEO 3 \leftrightarrow VHS \leftrightarrow 8 mm \leftrightarrow BETA
 \uparrow
 DBS \leftrightarrow DVD \leftrightarrow LD


6 Repeat steps 4 and 5 to label other input modes.

Note

- If more than 90 seconds elapse before you press another button, the menu disappears automatically

Setting Caption Vision (CAPTION VISION)

Some programs are broadcast with Caption Vision. To display Caption Vision, select either CC1, CC2, CC3, CC4, TEXT1, TEXT2, TEXT3, or TEXT4 from the menu. CC1, CC2, CC3, or CC4 shows you on-screen version of the dialogue or sound effects of a program. (The mode should be set to CC1 for most programs.) TEXT1, TEXT2, TEXT3, or TEXT4 shows you on-screen information presented using either half or the whole screen. It is not usually related to the program.



1 Press MENU.

2 Press \blacktriangle or \blacktriangledown to select CV , and press \blacktriangle .



3 Press \blacktriangle or \blacktriangledown to select the caption type, and press \blacktriangle .



4 Press MENU to return to the original screen.

To display Caption Vision

Press DISPLAY. (See page 20 for details.)


Notes

- Poor reception of TV programs can cause errors in Caption Vision and XDS.
- Captions may appear with a white box or other errors instead of a certain word.
- XDS, Caption Vision, and the status display cannot be used at the same time.
- For details on XDS, see page 20.

Operating video equipment

You can use the supplied remote control to operate Sony or non-Sony video equipment that has an infrared remote sensor. For this operation, set the manufacturer's code number.

Setting the manufacturer's code



Press the CODE SET, VTR (FUNCTION), and 0-9 buttons to enter the manufacturer's code number (see the chart on page 35-36), then press ENTER.

For example, to operate a Sony 8 mm VCR, press CODE SET, VTR (FUNCTION), 3, 0, 2, and ENTER.



VCR manufacturer code numbers

Manufacturer	Code number
Sony	301, 302, 303
Aiwa	338
Audio Dynamac	314, 337
Bell & Howell (M. Wards)	330, 343
Brocsonic	319
Canon	309, 308
Citizen	332
Craig	315, 302, 332
Curtis Mathus	304, 338, 309
Daewoo	341, 312, 309
DBX	314, 336, 337
Dimensia	304
Emerson	319, 320, 316, 317, 318
Fisher	330, 334, 335, 333
Funai	338
General Electric	329, 304, 309
Goldstar	332
Hitachi	306, 304, 305
Instant Replay	309, 308
JC Penney	309, 305, 304, 330, 314, 336, 337
JVC	314, 336, 337
Kenwood	314, 336, 332, 337
LXI (Sears)	332, 305, 333, 334, 330, 335
Magnavox	308, 309
Marantz	314, 336, 337
Marta	332
Memorex	309, 335
Minolta	305, 304
Mitsubishi/MCA	323, 324, 325, 326
Multitech	325, 338, 321
NEC	314, 336, 337
Olympic	309, 308
Parasonic	308, 309, 306, 307
Pentax	305, 304
Philco	308, 309
Philips	308, 309
Pioneer	308
Quasar	308, 309
RCA/PROSCAN	304, 305, 308, 309, 311, 312, 313
Realistic	309, 330, 328, 335, 324, 338
Sansui	314
Singer	315
Samsung	322, 313, 321
Sanyo	330, 335
Scott	312, 313, 321, 335, 323, 324, 325, 326
Sharp	327, 328
Shuntom	315
Signature 2000 (M. Wards)	338, 327
Sylvania	308, 309, 338
Symphonic	338
Tashiro	332
Tatung	314, 336, 337
Teac	314, 336, 338, 337
Techtrics	309, 308
Toshiba	312, 311
Wards	327, 328, 335, 331, 332
Yamaha	330, 314, 336, 337
Zeruth	331


MDP manufacturer code numbers

Manufacturer	Code number
Sony	701
Kenwood	707
Magnavox	703
Marantz	702
Mitsubishi	702
Panasonic	704
Philips	703
Pioneer	702
RCA	702
Sanyo	706
Sharp	705
Yamaha	703

Notes

- If more than one code number is listed, try entering them one by one, until you come to the correct code for your equipment.
- In some rare cases, you may not be able to operate your non-Sony video equipment with the supplied remote control. This is because your equipment may use a code that is not included with this remote control. In this case, please use the equipment's own remote control unit.
- The code numbers for Sony equipment are assigned at the factory as follows:
VHS VCR 301 (preset code for the supplied remote control)
8 mm VCR 302
Beta, ED Beta VCRs 303
- Whenever you remove the batteries — to replace them, for example — if too much time is taken, the code number may revert to the factory setting and must be reset.

Operating video equipment



Use the video operating buttons on the remote control to operate the video equipment. Press VTR (FUNCTION) before operating the video equipment.

Operating a VCR	Buttons on the remote control
To turn on or off	Press VTR (POWER).
To select a channel directly	Press the 0-9 buttons.
To change channels	Press CH +/-.
To record	Press while pressing . First release , then release .
To play	Press .
To stop	Press .
To fast forward	Press .
To rewind the tape	Press .
To pause	Press .
To resume normal playback, press again.	Press .
To search the picture forward or backward	Press or during playback. To resume normal playback, release the button.
To change input mode	Press TV/VTR.


Operating an MDP	Buttons on the remote control
To turn on or off	Press VTR (POWER).
To play	Press .
To stop	Press .
To pause	Press .
To resume normal playback, press again.	Press .
To search the picture forward or backward	Keep pressing or during playback. To resume normal playback, release the button.
To search the chapter forward and backward	Press CH +/-.

Note

- If the video equipment does not have a certain function, the corresponding button on this remote control will not operate.

Operating a cable box or DBS receiver


You can program the supplied remote control to operate a cable box or DBS receiver. Follow the procedures below to set the manufacturer's code number in the remote control.



* The TV/DBS, GUIDE, DISPLAY, , , and MENU buttons can be used only with a DBS receiver.

1 Turn off the equipment you want to set up, and press DBS/CABLE (FUNCTION).

2 Press the CODE SET, DBS/CABLE (FUNCTION), and 0-9 buttons to enter the manufacturer's code number (see the chart on the right column), then press ENTER. For example, to program your remote control to operate a Sony DBS receiver, press CODE SET, DBS/CABLE (FUNCTION), 8, 0, 1, and ENTER.



3 Press DBS/CABLE (POWER) to turn on the cable box or DBS receiver.



4 Use the cable box/DBS control buttons to check if the code number works.

For example, to operate a cable box or DBS receiver, you can use the DBS/CABLE (POWER), JUMP, CH +/-, 0-9 and ENTER buttons.

Note

- If the cable box or DBS receiver does not have a certain function, the corresponding button on this remote control will not operate.

To operate the projection TV

Press TV (FUNCTION). Then use the projection TV control buttons to control the projection TV.

For more details on operating the cable box or DBS receiver

Refer to the operating instructions that come with the equipment.

If the remote control doesn't work

- First, try repeating the setup procedures using the other codes listed for your equipment.

Manufacturer code numbers (cable box)

Manufacturer	Code number
Hamlin/Regal	222, 223, 224, 225, 226
Jerrold/G. I.	201, 202, 203, 204, 205, 206, 207, 208, 218
Oak	227, 228, 229
Panasonic	219, 220, 221
Pioneer	214, 215
Scientific Atlanta	209, 210, 211
Tocom	216, 217
Zenith	212, 213

Manufacturer code numbers (DBS receiver)

Manufacturer	Code number
Sony	801 (preset code for the supplied remote control)
RCA	802

Notes

- If more than one code number is listed, try entering them one by one until you come to the correct code for your equipment.
- If you enter a new code number, the code number you previously entered at that setting is erased.
- In some rare cases, your equipment may use a code that is not provided with this remote control and you may not be able to operate your equipment with the supplied remote control. In this case, use the equipment's own remote control unit.
- Whenever you remove the batteries — to replace them, for example — if too much time is taken, the code numbers may revert to the factory setting and must be reset.

Troubleshooting

If the problem persists after trying the methods below, contact your nearest Sony dealer.

No picture (screen not lit), no sound

- Make sure the power cord is connected securely.
- Operate with the buttons on the projection TV.
- Insert the batteries in the remote control with the correct polarity.
- Replace the batteries with new ones if they are weak.
- Check to see if the TV/VIDEO setting is correct when watching TV, set to TV, and when watching video tapes, set to VIDEO1, 2, or 3 (for KP-41T35 only).
- Try another channel. It could be station trouble.
- Perform AUTO SET UP again using the SETUP button to return to the factory preset condition. (page 14)

Poor or no picture (screen lit), good sound

- Adjust PICTURE in the VIDEO menu. (page 23)
- Adjust BRIGHTNESS in the VIDEO menu. (page 23)
- Adjust convergence. (page 16)
- Check antenna/cable connections. (page 6)
- Perform AUTO SET UP again using the SETUP button to return to the factory preset condition. (page 14)
- Remove objects from the front of the projection TV.

Good picture, no sound

- Press MUTE so that "MUTING" disappears from the screen. (page 19)
- Check the MTS setting in the AUDIO menu. (page 27)
- Make sure SPEAKER is set to ON in the AUDIO menu. (page 27)
- Perform AUTO SET UP again using the SETUP button to return to the factory preset condition. (page 14)

No color

- Adjust the COLOR in the VIDEO menu. (page 23)
- Confirm that black and white program is not being broadcast.
- Perform AUTO SET UP again using the SETUP button to return to the factory preset condition. (page 14)

Only snow and noise appear on the screen

- Check the CABLE setting in the SET UP menu. (page 17)
- Check the antenna/cable connections. (page 6)
- Make sure the channel is broadcasting programs.
- Press TV (black button) to change the input mode. (page 20)

Dotted lines or stripes

- Adjust the antenna.
- Move the projection TV away from noise sources such as cars, neon signs, and hair-dryers.

Double images or ghosts

- Use a highly directional outdoor antenna or a cable (when the problem is caused by reflections from nearby mountains or tall buildings).

Cannot operate menu

- If the item you want to choose appears in gray, you cannot select it. Press TV/VIDEO correctly.
- Check the CABLE setting in the SET UP menu. (page 17)

Cannot receive upper channels (UHF) when using an antenna

- Make sure CABLE is OFF in the SET UP menu. (page 17)
- Use AUTO PROGRAM to add receivable channels that are not presently in projection TV memory. (pages 14, 18)

Cannot receive any channels when using cable TV

- Make sure CABLE is ON in the SET UP menu. (page 17)
- Use AUTO PROGRAM to add receivable channels that are not presently in projection TV memory. (pages 14, 18)

Remote control does not operate

- Batteries could be weak. Replace the batteries. (page 13)
- Make sure the projection TV's power cord is connected securely to the wall outlet.
- Press TV (FUNCTION) when operating your projection TV.
- Are fluorescent lights too close to the projection TV? Move them at least 3-4 feet away from the projection TV.

Cannot gain enough volume when using a cable box

- Increase the volume at the cable box. Then press TV (FUNCTION) and adjust the projection TV's volume.


The projection TV needs to be cleaned

- Clean the projection TV with a soft dry cloth. Never use strong solvents such as thinner or benzene, which might damage the finish of the cabinet.

Index to parts and controls

This section briefly describes the buttons and controls on the projection TV and on the Remote control. For more information, refer to the pages next to each description.

Projection TV — Front



1 TIMER/STANDBY indicator (pages 19, 30)

2 STEREO indicator (page 27)

3 Remote sensor

4 POWER switch (page 14)

5 CHANNEL +/- buttons (page 14)


6 VOLUME +/- buttons (page 14)

7 TV/VIDEO button (page 14, 15)

8 SETUP button (page 14)

9 S VIDEO/VIDEO 2 INPUT (VIDEO/AUDIO L(MONO)/R) jacks (for KP-46C36 only) (page 10)


Remote control




- | | |
|--|---|
| 1 VTR (POWER) switch (page 36) | 17 TV (FUNCTION) button (pages 15, 19) |
| 2 MUTING button (page 19) | 18 SWAP button (page 22) |
| 3 VTR (FUNCTION) button (page 35) | 19 PIP button (page 21) |
| 4 FREEZE button (page 22) | 20 TV/VIDEO button (yellow labelled button) (page 21) |
| 5 TV/VTR CH +/- buttons (Yellow labelled button) (page 21) | 21 AUDIO button (page 21) |
| 6 POSITION button (page 22) | 22 TV/VIDEO button (page 20) |
| 7 DISPLAY button (page 20) | 23 TV button (black button) (page 20) |
| 8 SLEEP button (page 20) | 24 0-9 buttons (page 16) |
| 9 JUMP button (page 19) | 25 ENTER button (page 16) |
| 10 TV/DBS Φ button (page 26, 37) | 26 MTS/GUIDE button (page 27, 37) |
| 11 RESET button (page 23) | 27 Menu operation buttons (page 15) |
| 12 VOL (volume) +/- buttons (page 19) | MENU button |
| 13 CODE SET button (page 35) | $\blacktriangle/\blacktriangle/\blacktriangle/\blacktriangle$ buttons |
| 14 DBS/CABLE (POWER) switch (page 37) | \odot button |
| 15 TV (POWER) switch (page 19) | 28 CH (channel) +/- buttons (pages 16, 19) |
| 16 DBS/CABLE (FUNCTION) button (page 37) | |

SECTION 2 DISASSEMBLY


2-1. REAR BOARD REMOVAL




2-2. CHASSIS ASSY REMOVAL




2-3. SERVICE POSITION




2-4-1. HA BOARD REMOVAL (KP-46C36)




2-4-2. HA BOARD REMOVAL (KP-48S35/53S35/61S35)




2-5-1. BEZNET ASSY REMOVAL (KP-46C36/48S35/53S35)




2-5-2. SCREEN FRAME ASSY REMOVAL (KP-61S35)



2-6-1. MIRROR COVER ASSY REMOVAL (KP-46C36/48S35/53S35)




2-6-2. REFLECTION MIRROR REMOVAL (KP-61S35)




2-7. HIGH-VOLTAGE CABLE INSTALLATION AND REMOVAL

(1) Remover




(2) Installation



2-8. PICTURE TUBE REMOVAL


CAUTION: Removing the arrow-marked screws is strictly inhibited.

If removed, it may cause liquid spill.




2-9-1. SERVICE STAY ASSY HOW TO USE AND CARRY BACK SERVICE STAY ASSY.

SERVICE STAY ASSY



2-9-2. PICTURE TUBE BRACKET ASSY REMOVAL


- Disassemble HA board and speaker cord.
- Disassemble all the harness from purse lock.



- Remove ① three screws (head tapping screw 4X20) and pull out ② chassis assy from cabinet assy.
- Remove ③ two screws (tapping screw 4X20) and remove ④ shield board.
- Remove ⑤ eight screws (head tapping screw 4X20) and release ⑥ picture tube bracket assy from cabinet assy.


- Remove ⑦ two screws (+BVTP 4X12) and remove ⑧ X-RAY shield (L).
 - Remove ⑨ two screws (+BVTP 4X12) and remove ⑩ X-RAY shield (R).
- except KP-61S35

2-9-3. SETTING OF SERVICE STAY ASSY. (KP-46C36/48S35/53S35)



- 1) Lift up picture tube bracket assy and fit the hook of ① side board (L) to the notch on the assy. Then fix then with ② six screws (+BVTP 4X12).
- 2) Lift up picture tube bracket assy and fit the hook of ③ side board (R) to the notch on the assy. Then fix then with ④ six screws (+BVTP 4X12).

2-9-4. INSTALL A CHASSIS ASSY







- 1) Put ① chassis assy on chassis stays.
- 2) Put ② HA board on ① chassis assy.
- 3) You can carry the chassis assy in this condition.

MEMO

This image shows a full page of dot grid paper. The background is white, and it is covered with a regular pattern of small, black dots. The dots are arranged in straight horizontal and vertical lines, creating a grid-like appearance. There are no margins, text, or other markings on the page.

SECTION 3 SET-UP ADJUSTMENTS

ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<p>SCREEN VOLTAGE ADJUSTMENT (ROUGH ALIGNMENT)</p> <ol style="list-style-type: none"> 1. Turn the red VR on the FOCUS block all the way to the left and then gradually turn it to the right until the point where you can see the retrace line. 2. Next gradually turn it to the left to the position where the retrace line disappears. <p>FOCUS LENS ADJUSTMENT</p> <ol style="list-style-type: none"> 1. Loosen the lens screw. 2. Set in service mode. 3. Use VP on the service mode menu to show only the green colour. 4. Press the Commander Menu button and select FEATURES and CONVERGENCE to display the test signal on the screen. 5. Rotate the green lens and align with the optimal focus point from the test signal. 6. Use RG-RH from the service mode menu to set to green and red. 7. Display the test signal and rotate the red lens to obtain the optimum focus at the point where the red and green spots overlap. 8. Use RG-BH from the service mode menu to set to red and blue. 9. Display the test signal and rotate the blue lens to obtain the optimum focus at the point where the blue and red spots overlap. 10. Tighten the lens screw. <p>SCREEN (G2) ADJUSTMENT</p> <ol style="list-style-type: none"> 1. Select VIDEO mode without signals. 2. Connect the G2 JIG between TP732 (200V) and TP733 (GND) on the CG Board. 3. Connect an oscilloscope to the TP701 (KR), TP702 (KG) and TP703 (KB) of CR board, CG board and CB board. 4. Adjust 170~173V (KR, KG, KB) by rotating screen VR on the focus block. 	<p>Monoscope Pattern</p>		<p>PICTUREminimum BRIGHTNESS50% SCREEN (G2)</p>	 <p style="text-align: center;">Lens</p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0; text-align: center;"> <p>CONVERGENCE</p>  </div>  

ELECTRICAL ADJUSTMENT BY REMOTE COMMANDER

By using Remote Commander (RM-Y136A), all circuit adjustments can be made.

NOTE : Test Equipment Required.


1. Pattern Generator
2. Frequency counter
3. Digital multimeter
4. Audio oscillator

1. METHOD OF SETTING THE SERVICE ADJUSTMENT MODE

SERVICE MODE PROCEDURE


1. Standby mode. (Power off)
2. **DISPLAY** → **5** → **VOL (+)** → **TV POWER** on the Remote Commander.
(**+** → **5** → **△** → **□**) (Press each button within a second.)

SERVICE MODE ADJUSTMENT



3. The CRT displays the item being adjusted.
4. Press **1** or **4** on the Remote Commander to select the adjustment item.
5. Press **3** or **6** on the Remote Commander to change the data.
6. Press **2** or **5** on the Remote Commander to select the category.
7. If you want to recover the latest values press **7** then **ENTER** to read the memory.
8. Press **MUTING** then **ENTER** to write into memory.

SERVICE ADJUSTMENT MODE MEMORY




8. Press **8** then **ENTER** on the Remote Commander to initialize.
9. Turn set off and on to exit.

2. MEMORY WRITE CONFIRMATION METHOD

1. After adjustment, remove the plug from AC outlet, and then replace the plug in AC outlet again.
2. Turn the power switch ON and set to Service Mode.
3. Call the adjusted items again and confirm they were adjusted.

3. ADJUST BUTTONS AND INDICATOR



4. SERVICE MODE LIST

VP

Category	Adjustment item	Standard data	Note	Device
VP	VPOS		V SHIFT	
	VSIZ		V SIZE	
	VCOM	0	HV-COMP-V	
	VLIN	7	V LIN	
	VSCO	7	S CORRECTION	
	HPOS	7	H SHIFT	
	HSIZ		H SIZE	
	PAMP		PIN AMP	

Category	Adjustment item	Standard data	Note	Device
VP	UPIN	7	UPPER CORNER PIN	
	LPIN	7	LOWER CORNER PIN	
	PPHA	7	H TRAPEZOID	
	AFC	2	AFC LOOP GAIN	
	VBOW	7	V BOW	
	VANG	7	V ANGLE	
	REF	3	AKB REFERENCE	
	GDRV		GREEN DRIVE	
	BDRV		BLUE DRIVE	
	GCUT		GREEN CUT OFF	
	BCUT		BLUE CUT OFF	
	SCON		SUB CONTRAST	
	SHUE		SUB HUE	
	SCOL		SUB COLOR	
	SBRT		SUB BRIGHTNESS	
	SSHP	7	SUB SHARPNESS	
	GMMA	1	GAMMA LEVEL	
	CDM2	0	COUNT DOWN MODE 2	
	DPIX	1	DYNAMIC PICTURE	
	Y-DC	1	DC TRANSMISSION RATIO	
	ABLM	1	ABL MODE	
	AXIS	0	R-Y, G-Y AXIS	
	NOTC	0	C TRAP	
	CROM	7	C TRAP F0	
	TOT	0	C TOT FILTER	
	PREL	3	PRE/OVER LEVEL	
	SHPF	1	SHARPNESS F0	
	RON		RED ON/OFF	
	GON		GREEN ON/OFF	
	BON		BLUE ON/OFF	
	DCOL		DYNAMIC COLOR	
	CDMD	0	V COUNT DOWN	
	LBLK	13	H BLK WIDTH LEFT SIDE	
	RBLK	13	H BLK WIDTH RIGHT SIDE	

AP

Category	Adjustment item	Standard data	Note	Device
AP	SVOL	0	SUB VOLUME	
	SBAL	0	SUB BLANCE	
	SBAS	7	SUB BASS	
	STRE	7	SUB TREBLE	

RG

Category	Adjustment item	Standard data	Note	Device
RG	GH CENT		GREEN H SENT	
	GH SKEW		GREEN H SKEW	
	GH BOW		GREEN H BOW	
	GH 4BOW		GREEN H 4TH BOW	
	GH SIZE		GREEN H SIZE	
	GH LIN		GREEN H LINEARITY	
	GH MSIZ		GREEN H MID SIZE	
	GH MLIN		GREEN H MID LINEARITY	
	GH KEY		GREEN H KEY	
	GH SSKW		GREEN H SUB SKEW	
	GH MPIN		GREEN H MID PIN	
	GH PIN		GREEN H PIN	
	GH SBOW		GREEN H SUB BOW	
	GH MBOW		GREEN H MID BOW	
	GH 4PIN		GREEN H 4TH PIN	
	GH 4BOW		GREEN H 4TH BOW	
	GV CENT		GREEN V CENT	
	GV SKEW		GREEN V SKEW	
	GV BOW		GREEN V BOW	
	GV SIZE		GREEN V SIZE	
	GV LIN		GREEN V LINEARITY	
	GV MSIZ		GREEN V MID SIZE	
	GV MKEY		GREEN V MID KEY	
	GV KEY		GREEN V KEY	
	GV SSKW		GREEN V SUB SKEW	
	GV MPIN		GREEN V MID PIN	
	GV PIN		GREEN V PIN	
	GV SBOW		GREEN V SUB BOW	
	GV WAVE		GREEN V WAVE	
	GV 4PIN		GREEN V 4TH PIN	
	RH CENT		RED H CENT	
	RH SKEW		RED H SKEW	
	RH BOW		RED H BOW	
	RH 4BOW		RED H 4TH BOW	
	RH SIZE		RED H SIZE	
	RH LIN		RED H LINEARITY	
	RH MSIZ		RED H MID SIZE	
	RH MLIN		RED H MID LINEARITY	
	RH KEY		RED H KEY	
	RH SSKW		RED H SUB SKEW	
	RH MPIN		RED H MID PIN	
	RH PIN		RED H PIN	
	RH SBOW		RED H SUB BOW	
	RH MBOW		RED H MID BOW	

Category	Adjustment item	Standard data	Note	Device
RG	RH 4PIN		RED H 4TH PIN	
	RH 4BOW		RED H 4TH BOW	
	RV CENT		RED V CEVT	
	RV SKEW		RED V SKEW	
	RV BOW		RED V BOW	
	RV SIZE		RED V SIZE	
	RV LIN		RED V LINEARITY	
	RV MSIZ		RED V MID SIZE	
	RV MKEY		RED V MID KEY	
	RV KEY		RED V KEY	
	RV SSKW		RED V SUB SKEW	
	RV MPIN		RED V MID PIN	
	RV PIN		RED V PIN	
	RV SBOW		RED V SUB BOW	
	RV WAVE		RED V WAVE	
	RV 4PIN		RED V 4TH PIN	
	RV WING		RED V WING	
	BH CENT		BLUE H CENT	
	BH SKEW		BLUE H SKEW	
	BH BOW		BLUE H BOW	
	BH 4BOW		BLUE H 4TH BOW	
	BH SIZE		BLUE H SIZE	
	BH LIN		BLUE H LINEARITY	
	BH MSIZ		BLUE H MID SIZE	
	BH MLIN		BLUE H MID LINEARITY	
	BH KEY		BLUE H KEY	
	BH SSKW		BLUE H SUB SKEW	
	BH MPIN		BLUE H MID PIN	
	BH PIN		BLUE H PIN	
	BH SBOW		BLUE H SUB BOW	
	BH MBOW		BLUE H MID BOW	
	BH 4PIN		BLUE H 4TH PIN	
	BH 4BOW		BLUE H 4TH BOW	
	BV CENT		BLUE V CENT	
	BV SKEW		BLUE V SKEW	
	BV BOW		BLUE V BOW	
	BV SIZE		BLUE V SIZE	
	BV LIN		BLUE V LINEARITY	
	BV MSIZ		BLUE V MID SIZE	
	BV MKEY		BLUE V MID KEY	
	BV KEY		BLUE V KEY	
	BV SSKW		BLUE V SUB SKEW	
	BV MPIN		BLUE V MID PIN	
	BV PIN		BLUE V PIN	

Category	Adjustment item	Standard data	Note	Device
RG	BV SBOW		BLUE V SUB BOW	
	BV WAVE		BLUE V WAVE	
	BV 4PIN		BLUE V 4TH PIN	
	BV WING		BLUE V WING	

CC

Category	Adjustment item	Standard data	Note	Device
CC	CRIH	9	CRI COUNT HIGH	
	CRIL	2	CRI COUNT LOW	
	CR2L	2	CRI COUNT LOW(F2)	
	CCDI	3	NO CCD INT COMPARE	
	CRIP	7	CRI & PARITY ERROR	
	CRIT	0	CRI TIME CONSTANT	
	CSB1	2	SYNC SLICE BIAS 1	
	CSB2	5	SYNC SLICE BIAS 2	
	CCBD	4	C SYNC BACKPORCH DET	
	CCFD	7	C SYNC FRONTPORCH DET	
	CREP	136	CRI SIGNAL END POSITION	
	CSEP	176	START BIT END POSITION	
	CRBD	8	CRI BACKPORCH DET	
	CRFD	9	CRI FRONTPORCH DET	
	CSSD	3	STROBE WINDOW ST DLY	
	CSED	9	STROBE WINDOW ED DLY	
	CSBS	12	START BIT THRESHOLD	
	CDSD	8	DATA START DELAY	
	CCDS	9	CAPTION DT THRESHOLD	
	CHMK	38	H SYNC MASK WIDTH	
	CHSY	144	H SYNC VCO COUNT	

OP

Category	Adjustment item	Standard data	Note	Device
OP	DISP		OSD POSITION	

ID

Category	Adjustment item	Standard data		Note	Device
		S	46C		
ID	ID0	25	25	MODEL ID#0	
	ID1	21	55	MODEL ID#1	
	ID2	31	31	MODEL ID#2	

Category	Adjustment item	Standard data		Note	Device
		S	46C		
ID	ID3	00	00	MODEL ID#3	
	ID4	155	155	MODEL ID#4	
	ID5	177	177	MODEL ID#5	
	ID6	198	198	MODEL ID#6	
	ID7	66	66	MODEL ID#7	

PP

Category	Adjustment item	Standard data	Note	Device
PP	BCHP	-	PIP H POSITION	
	BGVP	-	PIP V POSITION	
	MAHP	-	P&P MAIN H AQUISITION	
	MAVP	-	P&P MAIN V AQUISITION	
	SAHP	-	P&P SUB H AQUISITION	
	SAVP	-	P&P SUB V AQUISITION	
	DECS	-	S DECODER REGISTERS	
	DECM	-	M DECODER REGISTERS	
	DIS	-	DISPLAY SETTING	
	BHSZ	-	BORDER H SIZE	
	BVSZ	-	BORDER V SIZE	
	VPED	-	V OFFSET	
	UPED	-	U OFFSET	

PS

Category	Adjustment item	Standard data	Note	Device
PS	PIPH		PIP H POSITION	
	PIPV		PIP V POSITION	
	PMVD	16	PIP V PULSE DELAY(M)	
	PVD	22	PIP V PULSE DELAY(I)	
	PCON		PIP CONTRAST(I)	
	FRMY	7	PIP FRAME Y LEVEL	
	IPER	0	PIP PEDESTAL R-Y(I)	
	IPEB	0	PIP PEDESTAL B-Y(I)	
	IHUE		PIP SUB HUE	
	ICOL		PIP SUB COLOR	
	PHDL	3	PIP H PULSE DELAY	
	PYSD	0	PIP SELECT DELAY	
	PYDL	0	PIP Y DELAY	
	PCPS	0	PIP CLP	
	PCPF	0	PIP CLP CYCLES	
	PSEL	0	PIP SELDOWN	





Category	Adjustment item	Standard data	Note	Device
PS	PPLL	0	PIP PLL	
	CHRI	1	PIP INPUT POLARITY	
	CHRO	0	PIP OUTPUT POLARITY	

MC


Category	Adjustment item	Standard data	Note	Device
MC	MSCN	-	P&P MAIN SUB CONTRAST	
	MSHU	-	P&P MAIN SUB HUE	
	MSCL	-	P&P MAIN SUB COLOR	
	MUPD	-	P&P MAIN U OFFSET	
	MVPD	-	P&P MAIN V OFFSET	
	MDLY	-	P&P MAIN Y DELAY	
	MBGR	-	P&P MAIN SCP CONTROL(1)	
	MBGF	-	P&P MAIN SCP CONTROL(2)	


IC



Category	Adjustment item	Standard data	Note	Device
IC	SSCN	-	P&P SUB SUB CONTRAST	
	SSHU	-	P&P SUB SUB HUE	
	SSCL	-	P&P SUB SUB COLOR	
	SUPD	-	P&P SUB U OFFSET	
	SVPD	-	P&P SUB V OFFSET	
	SDLY	-	P&P SUB Y DELAY	
	SBGR	-	P&P SUB SCP CONTROL(1)	
	SBGF	-	P&P SUB SCP CONTROL(2)	
	PAFC	-	PIP ARC LOOP GAIN	
	PTOT	-	PIP CHROMA TOT FILTER	
	PYDR	-	PIP Y DRIVE	
	PYDC	-	PIP DC TRAN	
	PSHP	-	PIP SHARPNESS F0	
	PDM	-	PIP DYNAMIC PICTURE	
	PSYS	-	PIP COLOR SYSTEM	
	PXTL	-	PIP X' TAL	
	FLOP	-	PIP COLOR LOOP	



ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<p>CONVERGENCE ADJUSTMENT</p> <p>● When replacing the deflection yoke, always perform “DEFLECTION YOKE TILT ADJUSTMENT” before adjusting the convergence.</p> <p>Adjustment procedure</p> <pre> graph TD A[VP MAIN] --> B[RG GH (SUB), RG GV (SUB)] B --> A B --> C[RG RH(SUB), RG RV (SUB)] C --> D[RG BH (SUB), RG BV (SUB)] </pre> <p>• GREEN REGISTRATION ADJUSTMENT</p> <ul style="list-style-type: none"> • V-SHIFT adjustment • V-LINEARITY adjustment • V-SIZE, V-CORRECTION adjustment While tracking, adjust so that the lattice intervals for VSIZ and VSCO are equal. 	<p>Monoscope pattern or Crosshatch pattern</p>		<p><VP MENU> VP VPOS</p> <p>VP VSIZ</p> <p>VP VLIN VP VSCO</p>	<p>VPOS</p>  <p>VSIZ</p>  <p>VLIN</p>  <p>VSCO</p> 



ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<ul style="list-style-type: none"> • H-SHIFT adjustment 			VP HPOS	<p>HPOS</p>
<ul style="list-style-type: none"> • H-SIZE adjustment Finely adjust with SUB MSIZ. 			VP HSIZ	<p>HSIZ</p>
<ul style="list-style-type: none"> • PIN-AMP adjustment Finely adjust with SUB MPIN. 			VP PAMP	<p>PAMP</p>
<ul style="list-style-type: none"> • UPPER/LOWER-CORNER PIN adjustment Correct the screens top and bottom bow line. However, if this adjustment is overdone, distortion may occur with the PIN-AMP adjustment that can not be re-adjusted. 			VP UPIN	<p>UPIN</p>
<p>Note : The PIN-AMP adjusts the overall screen from top to bottom, but the UPPER/LOWER-CORNER PIN adjustments have large movement in the top and bottom sections, so be careful.</p>			VP LPIN	<p>LPIN</p>
<ul style="list-style-type: none"> • V-BOW, V-ANGLE adjustment Correct the tilt and bow of the vertical line at the center of the screen. 			VP VBOW	<p>VBOW</p>
			VP VANG	<p>VANG</p>






ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<p>SCREEN CENTER SECTION GREEN HORIZONTAL LINE ADJUSTMENT</p> <p>1. Finely adjust the center position of the vertical line at the center of the screen with GV CENT.</p> <p>2. Correct the tilt and bow of the horizontal line at the center of the screen with GV SKEW and GV BOW.</p> <p>GREEN SIZE AND LINEARITY ADJUSTMENT</p> <p>1. Balance the sizes at both sides of the center section of the screen with GH MLIN.</p> <p>2. Balance the sizes on both end sections of the screen with GH LIN.</p> <p>3. While tracking, adjust with GH MLIN and GH LIN so that the sizes of the horizontal line at the center of the screen are symmetrical left and right.</p>			<p><RG-GV MENU></p> <p>GV CENT</p> <p>GV SKEW GV BOW</p> <p><RG-RH MENU></p> <p>GH MLIN GH LIN</p>	 <p>Watch the horizontal center line.</p> <p>Watch out only for the RGV CENT center point.</p> <p>GV CENT</p> <p>GV SKEW</p> <p>GV BOW</p> <p>MLIN</p> <p>LIN</p>

ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<p>GREEN HORIZONTAL SIZE ADJUSTMENT</p> <ol style="list-style-type: none"> 1. Adjust with GH MSIZE so that the sizes of both ends and of both sides of the center section of the screen are equal. 2. Adjust with GH SIZE so that the horizontal sizes of both ends and of both sides of the center section of the screen are equal. 3. While tracking, adjust with GH MSIZ and GH SIZE so that the lattice intervals for the horizontal line section of the center section of the screen are equal and so that the horizontal size is the prescribed value. 4. If M LIN is changed when the GH MSIZ and GH SIZE adjustment is complete, adjust again while tracking. <p>●With just the H SIZE adjustment in MAIN, if there is no need to adjust GH SIZE in SUB this can save power.</p> <p>GREEN VERTICAL LINEARITY ADJUSTMENT</p> <ol style="list-style-type: none"> 1. Adjust GV LIN so that the vertical lines at the top and bottom of the screen are symmetrical. 			<p><RG-GH MENU> GH MSIZ GH SIZE</p> <p><RG-GV MENU> GV LIN</p>	 <p>The illustration contains two diagrams. The top diagram shows the 'GREEN HORIZONTAL SIZE ADJUSTMENT' process. It features two rectangular screens. The top screen is divided into vertical sections by dashed lines, with labels 'MSIZ' and 'SIZE' pointing to the left and right sections respectively. Arrows indicate adjustment between these sections. Below this is a circular diagram showing four boxes labeled 'GH MSIZ', 'GH SIZE', 'GH LIN', and 'GH MLIN' arranged in a circle, with arrows indicating a clockwise adjustment cycle. The bottom diagram shows the 'GREEN VERTICAL LINEARITY ADJUSTMENT' process. It features a square screen with a circle inside, divided into four quadrants by a horizontal and vertical line. Arrows point to the top and bottom edges of the circle, indicating adjustment for vertical symmetry.</p>

ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<p>GREEN VERTICAL SIZE ADJUSTMENT</p> <ol style="list-style-type: none"> 1. Adjust with GV MSIZE so that the sizes for the top and bottom sections of the screen and for both sides of the center section of the screen are equal. 2. Set the vertical size to the prescribed value with GV SIZE. 3. Adjust GV MSIZ and GV SIZE watching the vertical line at the center section of the screen. 4. While tracking, adjust with GV MSIZ and GV SIZE so that the lattice intervals for the vertical line section of the center section of the screen are equal and so that the vertical size is the regulation value. 5. If GV LIN is out of place when the GV MSIZ and GV SIZE adjustment is complete, adjust again while tracking. <p>●If there is no need to adjust GV SIZE in SUB with just the V SIZE adjustment in MAIN, this can save power.</p>			<p><RG-GV MENU> GV MSIZ</p> <p>GV SIZE</p>	
<p>GREEN HORIZONTAL TRAPEZOIDAL DISTORTION ADJUSTMENT</p> <ol style="list-style-type: none"> 1. Adjust with GH SSKW so that the tilt of the vertical lines at both ends of the screen is symmetrical left and right. 2. Adjust with GH KEY so that there is no tilt in the vertical lines at both ends of the screen. 3. If there is a tilt on either the left or right after the GH KEY adjustment, adjust while tracking. 			<p><RG-GH MENU> GH SSKW</p> <p>GH KEY</p>	

ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<p>GREEN HORIZONTAL QUATERNARY ADJUSTMENT</p> <ol style="list-style-type: none"> 1. Correct the quaternary distortion with GH 4PIN. 2. While balancing, correct the quaternary distortion of both end sections of the screen with GH 4SBO. 3. While tracking, adjust with GH 4PIN and GH 4SBO. 			<p><RG-GH MENU></p> <p>GH 4PIN GH 4BOW</p>	
<p>GREEN HORIZONTAL ASYMMETRICAL PIN DISTORTION ADJUSTMENT</p> <ol style="list-style-type: none"> 1. Adjust with GH MBOW so that the pin asymmetry at both sides of the center section of screen is symmetrical. 2. Adjust with GH SBOW so that the bow at both end sections of the screen is symmetrical left and right. 3. While tracking, adjust with GH MBOW and GH SBOW so that the bow of vertical lines on the entire screen is symmetrical left and right. 			<p><RG-GH MENU></p> <p>GH MBOW GH SBOW</p>	






ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<p>GREEN HORIZONTAL SYMMETRICAL PIN DISTORTION ADJUSTMENT</p> <p>1. Adjust the pin distortion at both sides of the center section of the screen with GH MPIN.</p> <p>2. Adjust the pin distortion at both end sections of the screen with GH PIN.</p> <p>3. While tracking, adjust with GH MPIN and GH PIN so that the PIN of vertical lines on the entire screen have no bowing.</p> <p>4. If there is asymmetrical pin distortion after the GH MPIN and GH PIN adjustments, adjust with GH MBOW and GH SBOW while tracking.</p> <p>●With just the PIN AMP adjustment in MAIN, if there is no need to adjust GV PIN in SUB, this can save power.</p>			<p><RG-GH MENU></p> <p>GH MPIN</p> <p>GH PIN</p> <p>GH MBOW GH SBOW</p>	
<p>GREEN VERTICAL WAVE (TERTIARY DISTORTION) ADJUSTMENT</p> <p>1. Take the screen top and bottom horizontal lines with GV WAVW and find the secondary and quaternary waveform.</p> <p>2. There is KEY distortion after the GV WAVW adjustment, so adjust with GV WAVW and GV KEY while tracking.</p>			<p><RG-GV MENU></p> <p>GV WAVE</p> <p>GV KEY</p>	


ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<p>GREEN VERTICAL QUATERNARY DISTORTION ADJUSTMENT</p> <ol style="list-style-type: none"> 1. Correct the quaternary distortion of the horizontal lines at the top and bottom sections of the screen with RGV 4PIN. 1) Since there is no 4SBOW for vertical correction, there will be a slight imbalance, but adjust to eliminate the distortion from the horizontal line at either the top or the bottom of the screen. 2) In many cases, the horizontal lines at the top and bottom sections of the screen are not straight lines after the adjustment. As long as the secondary distortion is mild enough that it can be corrected with the PIN adjustment, this is OK. <p>GREEN VERTICAL TRAPEZOIDAL DISTORTION ADJUSTMENT</p> <ol style="list-style-type: none"> 1. Adjust with GV SSKW so that the tilt of the horizontal lines at the top and bottom sections of the screen is symmetrical about the center position horizontal line. 2. Adjust with GV MKEY so that there is no tilt for the line sections at both sides of the horizontal lines at the center section of the stream. 3. Adjust with GV KEY so that there is no tilt for the horizontal lines at the top and bottom sections of the screen. 4. While tracking, adjust with GV MKEY and GV KEY so that there is no tilt for the horizontal lines on the entire screen. 5. If the tilt is unbalanced after the GV MKEY and GV KEY adjustment, adjust again with GV SSKW. 			<p><RG-GV MENU></p> <p>GV 4PIN</p> <p><RG-GV MENU></p> <p>GV SSKW</p> <p>GV MKEY</p> <p>GV KEY</p> <p>GV SSKW</p>	<p>GV 4PIN</p>  <p>GV SSKW</p>  <p>GV MKEY</p>  <p>MKEY</p>  <p>KEY</p> 


ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
GREEN AND RED REGISTRATION ADJUSTMENT (RRH, RRV) 1. Receive a cross-hatch signal. 2. Adjust so that the red lines lay on the green lines. Adjust with the same procedure as the GREEN SUBadjustment. Notes : 1. The main correction is not carried out during red registration adjustment. 2. Beware. The green adjustment items can be changed by mistake. 3. Unlike for green, adjust within the range -127 ~ +128.	Cross-hatch pattern			
GREEN AND BLUE REGISTRATION ADJUSTMENT (RBH, RBV) 1. Receive a cross-hatch signal. 2. Adjust so that the blue and green lines are on top of each other. Notes : 1. The main correction is not carried out during RED registration adjustment. 2. Beware. The GREEN and RED adjustment items can be changed by mistake.	Cross-hatch pattern			

ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<div>AGC ADJUSTMENT</div> <ol style="list-style-type: none"> 1. Receive an off-air signal. 2. Adjust the AGC VR (TU 1001) so that there is no snow noise and cross-modulation. <div>WHITE BALANCE ADJUSTMENT</div> <ol style="list-style-type: none"> 1. Receive the monoscope pattern signal and adjust the picture quality with the menu. 2. Adjust service mode SBRT so that the signal 10 IRE section barely glows. 3. Receive the all-white pattern signal. 4. Adjust the white balance with service mode GCUT and BCUT. 5. Adjust service mode SBRT so that the signal 100 IRE section barely glows. 6. Adjust the white balance with service mode GDRV and BDRV. 7. Repeatedly adjust the white balance for the minimum and maximum picture settings. 	<div>Monoscope pattern</div> <div>All White pattern</div>		<div>PICTURE</div> <div>.....minimun</div> <div><RGB MENU></div> <div>RGB SBRT</div> <div>RGB GCUT</div> <div>RGB BCUT</div> <div>PICTURE</div> <div>.....minimun</div> <div>RGB GDRV</div> <div>RGB BDRV</div> <div>PICTURE</div> <div>.....maximum</div>	


SECTION 4 SAFETY RELATED ADJUSTMENTS


ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<p>[G BOARD]</p> <p>HV REGULATION CIRCUIT CHECK AND ADJUSTMENT</p> <p>When replacing the following components marked with  on the schematic diagram always check HV regulation, and if necessary re-adjust.</p> <p>OPERATION CHECK</p> <ol style="list-style-type: none"> 1. Connect a HV static voltmeter to the unconnected plug of the high-voltage block. 2. Power on the set. 3. Receive dot signal pattern. (PICTURE and BRIGHT to minimum) 4. Check that the HV static voltmeter is reading $31.00 \pm 1.0 \text{ kVdc}$. <p>HV Regulation adjustment</p> <ol style="list-style-type: none"> 1. Connect a HV static voltmeter to the unconnected plug of the high-voltage block. 2. Power on the set. 3. Receive dot signal pattern. (PICTURE and BRIGHT to minimum) 4. If anode voltage is 32kV or higher, replace C514 of 390PF/2kV with that of 680PF/2kV, and check if the voltage is within the standard range. 5. If anode voltage is 30kV or lower, replace C514 of 390PF/2kV with that of 100PF/2kV, and check if the voltage is within the standard range. 		<p> marked parts C514, C516, C515, T502 (PMT), T503 (HLT), T504 (FBT), DEFLECTION YOKE, IC651</p>	<p> C514</p>	<div data-bbox="1556 305 1938 602">  <p>Remove the cap off from the unused terminal and connect a static voltmeter there.</p> </div> <div data-bbox="1530 792 1965 1084"> <p>G BOARD -COMPONENT SIDE-</p>  <p>The schematic diagram shows the following components and connections:</p> <ul style="list-style-type: none"> C514: A capacitor connected to a terminal marked with a square symbol and diagonal line. R561: A resistor connected to a terminal marked with a square symbol and diagonal line. R514: A resistor connected to a terminal marked with a square symbol and diagonal line. TP135V: A test point connected to R512. R512: A resistor connected to TP135V and CN505. CN505: A connector connected to R512. IC651: An integrated circuit with pins 5 and 1 labeled. </div>



ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<p>[G BOARD]</p> <div data-bbox="86 285 753 363" style="border: 1px solid black; padding: 5px;"> <p>HV HOLD DOWN CIRCUIT OPERATION CHECK AND ADJUSTMENT (☒ R514, R561)</p> </div> <p>When replacing the following components marked with ☒ on the schematic diagram, always check hold-down voltage and if necessary re-adjust.</p> <p>OPERATION CHECK</p> <ol style="list-style-type: none"> 1. Remove CN651 connector. 2. Short-circuit across TP-PROT (R692) and ground. 3. Connect a HV static voltmeter to the unconnected plug of the high-voltage block. 4. Connect a 220k variable resistor, across pin ③ and pin ⑤ of IC651 set to maximum value. 5. Power on the set. 6. Receive dot signal pattern. (PICTURE and BRIGHT to minimum) 7. Gradually lower the value of the variable resistor and check that the hold-down circuit operates at a static voltmeter reading of $33.5 \pm 1.0 \text{ kVdc}$ when the raster disappears. <p>HV HOLD-DOWN ADJUSTMENT</p> <ol style="list-style-type: none"> 1. Repeat steps ① ~ ⑦ as above. 2. If hold down voltage is 34.5kV or higher, remove R514, mount a resistor (390kΩ, 1/4W : RN) onto R561 instead, and check again if the hold-down voltage is within the standard range. 3. If hold-down voltage is 32.5kV or lower, mount a resistor (220kΩ, 1/4W : RN) onto R561, and check again if the hold-down voltage is within the standard range. <div data-bbox="86 1235 695 1291" style="border: 1px solid black; padding: 5px;"> <p>NOTE : Please finish the adjustment as soon as possible.</p> </div>		<p>☒ marked parts R502, R514, R516, R517, R539, R560, R561, C507, C513, D501, D504, D507, IC301, IC501, IC651, T502 (PMT), T503 (HLT), T504(FBT) DEFLECTION YOKE</p>	<p>☒ R514, 561</p>	<p>G BOARD -COMPONENT SIDE-</p> 


ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<p>[G BOARD]</p> <p>+B MAX VOLTAGE CONFIRMATION</p> <p>The following adjustments should always be performed when replacing IC651.</p> <ol style="list-style-type: none"> 1. Supply 130VAC to variable autotransformer. 2. Input dot signal. 3. Set the PICTURE control and the BRIGHTNESS controls to minimum. 4. Confirm if the voltage of G BOARD TP135V is less than 137.0 Vdc. 5. If step 4 is not satisfied, replace IC651 and repeat above steps. <p>+B OVP CONFIRMATION</p> <ol style="list-style-type: none"> 1. Remove CN651 connector. 2. Connect a voltmeter to TP135V, and TP (PROT) and ground. 3. Connect a 220kΩ variable resistor, across pin ③ and pin ⑤ of IC651, and set to maximum value. 4. Supply 120VAC to variable autotransformer. 5. Set PICTURE and the BRIGHTNESS controls to minimum. 6. Gradually turn the 220kΩ variable register, and check if OVP works properly when the voltage of TP135V is between 139.0~151.5V. 				<p>G BOARD -COMPONENT SIDE-</p> 


SECTION 5 CIRCUIT ADJUSTMENT

ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<div data-bbox="86 313 212 350" style="border: 1px solid black; padding: 2px;">RF AGC</div> <ol style="list-style-type: none"> 1. Input a color-bar signal. 2. Adjust AGC VR of TU1101 so that snow, noise, and cross-modulation disappear from the picture. 3. Verify picture quality on each channel. <div data-bbox="86 597 537 634" style="border: 1px solid black; padding: 2px;">BER DISPLAY ADJUSTMENT (DISP)</div> <ol style="list-style-type: none"> 1. Receive cross-hatch signal. 2. Set to Service mode. 3. Select "DISP", and adjust so that the blank spaces on the both sides of picture bar become equal. 4. Write the data into memory. <div data-bbox="121 808 359 841" style="border: 1px solid black; padding: 2px;">MUTING → ENTER</div> <div data-bbox="86 1003 583 1040" style="border: 1px solid black; padding: 2px;">SUB-CONTRAST ADJUSTMENT (SCON)</div> <ol style="list-style-type: none"> 1. Receive the color-bar signal. 2. PICTURE : maximum COLOR : minimum BRIGHTNESS : minimum RON---1 GON---0 BON---0 3. Set to service mode. 4. Connect an oscilloscope between ⑥ pin of CN004 (A Board) and ground. 5. Select "SCON" and adjust so that the wave from level is $1.50 \pm 0.1V_{p-p}$. 6. Write the data into memory <div data-bbox="121 1414 359 1446" style="border: 1px solid black; padding: 2px;">MUTING → ENTER</div> 				


ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<p>SUB-HUE AND SUB-COLOR ADJUSTMENT (SHUE, SCOL)</p> <ol style="list-style-type: none"> 1. Receive color-ber signal. 2. PICTURE : maximum COLOR : minimum BRIGHTNESS : minimum 3. Set to Service mode. 4. Connect an oscilloscope between ⑦ pin of CN004 (A Board) connector and ground. 5. Select "SHUE" and "SCOL", and adjust them to have VB1=VB4 and VB2=VB3 in the waveform levels. 6. Raise SCOL data 1 steps higher. 7. Write the data into memory. MUTING → ENTER 				


ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
P IN P POSITION ADJUSTMENT (PIPH, PIPV) <ol style="list-style-type: none"> 1. Receive monoscope pattern signal. 2. Set to P IN P mode, and to Service mode. 3. Check the SUB PICTURE position. 4. Select "PIPH" and "PIPV" and adjust H/V position to the specified level. 5. Write the data into memory MUTING → ENTER 				 <p>H : $7.00 \pm 0.25sq$ V : $5.25 \pm 0.25sq$</p>
P IN P SUB CONTRAST ADJUSTMENT (PCON) <ol style="list-style-type: none"> 1. Receive color-bar signal. 2. PICTURE : maximum COLOR : minimum BRIGHTNESS : minimum 3. Set to Service mode. 4. Connect an oscilloscope between ⑨ pin CN303 (A Board) and ground. 5. Select "P CON" and adjust so that waveform level is $1.4 \pm 0.05 Vp-p$. 6. Write the data into memory. MUTING → ENTER 				 <p>1.4 ± 0.05 BLACK GND</p>

ADJUSTMENT ITEM AND PROCEDURE	EQUIPMENT AND SIGNAL	MEASUREMENT POSITION	ADJUSTMENT LOCATION	ILLUSTRATION AND SHAPE AND NUMBER
<div data-bbox="100 207 802 243" data-label="Section-Header"> P IN P SUB HUE, SUB COLOR ADJUSTMENT (IHUE, ICOL) </div> <ol style="list-style-type: none"> 1. Receive the color-bar signal. 2. PICTURE : maximum COLOR : center BRIGHTNESS : center 3. Set to Service mode. 4. Connect an oscilloscope between ⑤ pin of CN303 (A Board) and ground. 5. Select "IHUE" and ICOL, adjust them to have VB1=VB4 and VB2=VB3 in the waveform levels. 6. Raise "ICOL" data 1 steps higher. 7. Write the data into memory. MUTING → ENTER 				









- | Reference information | |
|-----------------------|------------------------|
| RESISTOR | : RN METAL FILM |
| RC | SOLID |
| · FPRD | NONFRAMMABLE CARBON |
| · FUSE | NONFRAMMABLE FUSIBLE |
| · RW | NONFRAMMABLE WIREWOUND |







RB **NONFRAMMABLE CEMENT**

- | | |
|-----------|-------------------------|
| COIL | ADJUSTMENT RESISTOR |
| 1F-RL | MICRO INDICATOR |
| CAPACITOR | TANTALUM |
| TA | STYROL |
| PS | POLYPROPYLENE |
| PP | NYLON |
| PT | METALIZED POLYESTER |
| MMS | METALIZED POLYPROPYLENE |
| AMP | BIPOLAR |
| ALB | HIGH TEMPERATURE |
| ALT | HIGH RIPPLE |
| ALA | |

Terminal name of semiconductors in silk screen printed circuit (*)

Printed name ()

①	Transistor	T	Collector	T
---	------------	---	-----------	---







		 <small>Diagram 10-1000</small>	
②	Transistor	Collector Base Emitter	
③	Diode	 Cathode Anode	
④	Diode	 Cathode Anode (NC) Cathode	

- | | | | |
|---|-------|----------------------|--|
| ⑥ | Diode | Common Anode Cathode | |
| ⑦ | Diode | Common Anode Cathode | |
| ⑧ | Diode | Common Anode Cathode | |
| ⑨ | Diode | Common Anode Cathode | |
| ⑩ | Diode | Common Anode Cathode | |
| ⑪ | Diode | Common Anode Cathode | |

14 Transistor (FEET)



Source Drain Gate

The diagram shows a transistor symbol with three terminals: Source, Drain, and Gate. The Source terminal is connected to ground. The Drain terminal is connected to a positive supply voltage. The Gate terminal is connected to a positive supply voltage through a resistor.

Transistor			
Transformer			

17	Transistor		
----	------------	---	---

19	Transistor	
20	Transistor	


Discrete semiconductor		
------------------------	---	---



Chip semiconductors that are not actually used are included)

2 3 4 5 6 7 8 9

A BOARD

IC	Q409 Q410 Q411 Q412			
	Q410	Q411	Q412	Q413
IC001	F-7	Q1101	Q1102	Q1103
IC002	F-4	Q1501	F-3	Q1502
IC003	G-6	Q2105	E-3	Q2106
IC004	G-4	Q2106	E-4	Q2107
IC201	C-5	D001	E-5	D002
IC301	F-8	D003	E-5	D004
IC401	C-3	D005	E-5	D006
IC402	C-4	D007	E-5	D008
IC1501	F-2	D009	E-5	D010
IC1502	G-3	D011	E-5	D012
IC1601	D-1	D013	E-5	D014
IC1602	D-2	D015	E-5	D016
TRANSISTOR	D203 D204 D205 D206			
	D207	D208	D209	D210
Q001	F-5	D211	C-5	D212
Q002	F-6	D213	C-5	D214
Q003	F-6	D215	C-5	D216
Q004	E-5	D217	C-5	D218
Q005	E-5	D219	C-5	D220
Q006	E-5	D221	C-5	D222
Q007	E-5	D223	C-5	D224
Q008	E-5	D225	C-5	D226
Q009	E-5	D227	C-5	D228
Q010	E-5	D229	C-5	D230
Q011	E-5	D231	C-5	D232
Q012	E-5	D233	C-5	D234
Q013	E-5	D235	C-5	D236
Q014	E-5	D237	C-5	D238
Q015	E-5	D239	C-5	D240
Q016	E-5	D241	C-5	D242
Q017	E-5	D243	C-5	D244
Q018	E-5	D245	C-5	D246
Q019	E-5	D247	C-5	D248
Q020	E-5	D249	C-5	D250
Q021	E-5	D251	C-5	D252
Q022	E-5	D253	C-5	D254
Q023	E-5	D255	C-5	D256
Q024	E-5	D257	C-5	D258
Q025	E-5	D259	C-5	D260
Q026	E-5	D261	C-5	D262
Q027	E-5	D263	C-5	D264
Q028	E-5	D265	C-5	D266
Q029	E-5	D267	C-5	D268
Q030	E-5	D269	C-5	D270
Q031	E-5	D271	C-5	D272
Q032	E-5	D273	C-5	D274
Q033	E-5	D275	C-5	D276
Q034	E-5	D277	C-5	D278
Q035	E-5	D279	C-5	D280
Q036	E-5	D281	C-5	D282
Q037	E-5	D283	C-5	D284
Q038	E-5	D285	C-5	D286
Q039	E-5	D287	C-5	D288
Q040	E-5	D289	C-5	D290
Q041	E-5	D291	C-5	D292
Q042	E-5	D293	C-5	D294
Q043	E-5	D295	C-5	D296
Q044	E-5	D297	C-5	D298
Q045	E-5	D299	C-5	D300
Q046	E-5	D301	C-5	D302
Q047	E-5	D303	C-5	D304
Q048	E-5	D305	C-5	D306





HA BOARD * MARK LIST




REF.	Pin No.	VOLTAGE
IC1301	①	5.0
IC1301	②	5.0
IC1301	③	GND

HA BOARD

REF.	Pin No.	VOLTAGE
IC1301	①	5.0
IC1301	②	5.0
IC1301	③	GND

HA [IN/OUT SELECT]


HA BOARD




REF.	VOLTAGE
Q3301	6.3
Q3301	8.9
Q3301	6.9
Q3305	1.0
Q3305	GND
Q3305	0.4
Q3306	1.3
Q3306	GND
Q3306	0.7
Q3307	1.1
Q3307	GND
Q3307	0.5
Q3308	GND
Q3308	2.9
Q3308	0
Q3310	GND
Q3310	6.5
Q3310	-0.4
Q3312	0.6
Q3312	0
Q3312	0
Q3313	GND
Q3313	0
Q3313	0.8

REF.	Pin No.	VOLTAGE
IC3301	①	GND
IC3301	②	GND
IC3301	③	3.8
IC3301	④	6.6
IC3301	⑤	GND
IC3301	⑥	0.1
IC3301	⑦	0
IC3301	⑧	1.7
IC3301	⑨	0.3
IC3301	⑩	7.9
IC3301	⑪	4.3
IC3301	⑫	GND
IC3301	⑬	0
IC3301	⑭	0.1
IC3301	⑮	2.2
IC3301	⑯	4.2
IC3301	⑰	2.9
IC3301	⑱	2.8
IC3301	⑲	4.6
IC3301	⑳	GND
IC3301	㉑	2.7
IC3301	㉒	8.9
IC3301	㉓	GND
IC3301	㉔	5.1
IC3301	㉕	GND
IC3301	㉖	3.0
IC3301	㉗	2.4
IC3301	㉘	2.2
IC3301	㉙	5.0
IC3301	㉚	GND
IC3301	㉛	0.4
IC3301	㉜	0
IC3301	㉝	0.5
IC3301	㉞	5.0
IC3301	㉟	1.9
IC3301	㊱	0
IC3301	㊲	-2.9
IC3301	㊳	GND
IC3301	㊴	GND
IC3301	㊵	0.1
IC3301	㊶	0.7
IC3301	㊷	0.2
IC3301	㊸	4.8
IC3301	㊹	4.8
IC3301	㊺	GND
IC3301	㊻	GND
IC3301	㊼	1.4
IC3301	㊽	5.0
IC3301	㊾	2.3
IC3301	㊿	4.0
IC3301	1	2.3

— ZR BOARD —



— ZG BOARD —




NOTE:
The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.


REF.	VOLTAGE
Q1431 E	0.5
Q1431 C	67.2
Q1431 B	0.9
Q1432 E	138.4
Q1432 C	67.2
Q1432 B	134.4
Q1433 E	5.8
Q1433 C	GND
Q1433 B	5.7
Q1434 C	9.0
Q1434 B	5.7
Q1435 E	2.1
Q1435 C	5.7
Q1435 B	2.7
Q1436 E	2.1
Q1436 C	9.0
Q1436 B	2.7

ZG BOARD

ZR
(VM, DY)




ZG
(VM, DY)



B-59443 <U> -> ZG.



G BOARD		
IC	D510	F-4
IC501	D511	F-2
IC801	D514	E-1
IC651	D517	G-1
IC652	D519	F-8
IC653	D520	G-2
IC655	D521	F-3
IC801	D524	F-8
IC802	D527	E-7
IC803	D528	E-7
IC804	D528	A-2
IC805	D602	A-2
IC806	D651	C-3
IC806	D652	C-3
IC808	D653	B-6
IC809	D654	B-6
IC810	D655	C-4
IC811	D656	B-5
	D657	A-5
	D658	B-5
	D659	D-3
TRANSISTOR		
Q501	D660	C-3
Q502	D661	D-5
Q503	D662	A-5
Q504	D664	A-5
Q505	D669	C-3
Q506	D670	A-5
Q507	D691	D-1
Q651	D692	D-2
Q652	D693	D-1
Q653	D801	E-11
Q654	D802	E-11
Q655	D803	E-11
Q656	D804	E-11
Q657	D820	D-11
Q658	D828	F-11
Q659	D829	G-11
Q660	D835	C-8
Q661	D840	G-10
Q662	D842	G-10
Q802	D845	G-10
Q803	D846	G-10
Q804	D847	F-9
Q805	D848	F-9
Q809	D849	F-9
Q810	D850	F-11
DIODE		
D501	D854	G-9
D502	D855	G-10
D504	D856	G-10
D507	D857	G-9
D508	D859	G-9
D509	D860	G-9

NOTE:
The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.



CR [a OUT]

— CR BOARD —





CR BOARD	
REF. No.	VOLTAGE
Q701	E 4.4
Q701	C 0
Q702	B 4.1
Q702	E 2.2
Q702	C GND
Q702	B 1.9

CR BOARD	
REF. No.	VOLTAGE
Q701	E 4.4
Q701	C 0
Q702	B 4.1
Q702	E 2.2
Q702	C GND
Q702	B 1.9

CG [a OUT]

— CG BOARD —





CG BOARD	
REF. No.	VOLTAGE
Q731	E 2.5
Q731	C GND
Q731	B 3.5
Q731	E 199.6
Q731	C 145.0
Q731	B 144.6

CG BOARD	
REF. No.	VOLTAGE
Q731	E 2.5
Q731	C GND
Q731	B 3.5
Q731	E 199.6
Q731	C 145.0
Q731	B 144.6

CB [a OUT]


— CB BOARD —



CB BOARD	
REF. No.	VOLTAGE
Q761	E 2.5
Q761	C GND
Q761	B 4.9
Q761	E 196.6
Q761	C 113.0
Q761	B 109.7


CB BOARD	
REF. No.	VOLTAGE
Q761	E 2.5
Q761	C GND
Q761	B 4.9
Q761	E 196.6
Q761	C 113.0
Q761	B 109.7

NOTE:
The circuit indicated as left contains high voltage of over 600 Vpp. Care must be paid to prevent an electric shock in inspection or repairing.




6-5. SEMICONDUCTORS


BH3856FS-E2
SDA9288X-A141




CA0007AD
NJM2058D
μPC339C




CA0007AM



CXA2025AS




CXP85112B-613S
CXP85856-005S



LM7805CT
MC7805CT
MC7812CT
PQ09RF21
TA7805S
TA7812S




MC7905CT




MM1313AD
PM0011AS




M5218AP
NJM4558D




NJM4558M-T2
ST24C04FM6TR
μPC4558G2
X24C04S8



PA0053B




PST9143NL



SBX1780-51



STK392-110




STV9379




TDA2009A



TDA6106Q



TDA6315T/N3A-T



DTA144EKA-T146
DTC143TKA-T146
DTC144EKA-T146
2SA1162G
2SB709A-QRS-TX
2SD601A-Q
2SD601A-QRS-TX




IRF614
IRF614-LF




MC780CT
2SA1837
2SC4793




MX0841-AB-F




2SA1175-HFE
2SA1309A-QRSTA
2SC2785-HFE
2SC3311A-QRSTA




2SC2688-LK




2SC4632LS-CB7




2SD2348 (LB SONY-1)



DTZ10B
UDZ-TE-17-10B




D1NL20
EL1Z
GP08D
GP08DPKG23
RGP02-20EL-6394
RGP10GPKG23




D1NS4

HZS9.1NB2
MTZJ-30A
MTZJ-33B
MTZJ-7.5B
MTZJ-T-77-10
MTZJ-T-77-10B
MTZJ-T-11
MTZJ-T-15
MTZJ-T-20A
MTZJ-T-24A
MTZJ-T-3.6
MTZJ-T-30
MTZJ-T-33B
MTZJ-T-39
MTZJ-T-5.1
MTZJ-T-5.1B
MTZJ-T-5.6
MTZJ-T-5.6B
MTZJ-T-7.5B
MTZJ-T-9.1B
RD10ESB2
RD11ES-B2
RD20ES-B2
RD24ES-B
RD3.6ES-B1
RD39ES-B2
RD5.1ES-B1
RD5.1ES-B2
RD5.6ESB2
11ES2



**D2S4MF
D2SMTA1**




**D4SBS4F
D10SBS4F
LN4SB60
RBA-402LLF-A**




D10SC4M




**ERC06-15S
1SS133T-77**



ERD29-08J



SLR-325VCT31



SECTION 7

EXPLODED VIEWS

NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.

- The construction parts of an assembled part are indicated with a collation number in the remark column.


- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

7-1. COVER (KP-46C36/48S35/53S35)


- : 7-685-648-79 +BVTP 3X12
- ▲ : 7-685-661-14 +BVTP 4X12
- ▼ : 7-685-661-79 +BVTP 4X12
- ◆ : 7-685-666-79 +BVTP 4X30



REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
1	X-4032-998-1	BEZEL ASSY (46C36)		12	* X-4032-619-1	COVER ASSY, MIRROR (46C36)	13
	X-4032-999-2	BEZEL ASSY (53S35)			* X-4032-620-1	COVER ASSY, MIRROR (53S35)	13
	X-4034-438-1	BEZEL ASSY (48S35)		13	4-048-150-01	CAP. HOLE (46C36/53S35)	
2	4-036-466-11	PLATE (L), DIFFUSION (53S35)		14	4-041-164-11	SCREW (4X20), TAPPING	
	4-037-360-11	PLATE (L), DIFFUSION (46C36)		15	4-057-597-01	GRILLE, SPEAKER (48S35/53S35)	
3	4-058-454-11	PLATE (L), DIFFUSION (48S35)		16	4-057-603-01	BUTTON, MULTI	
	4-036-469-11	PLATE (F), DIFFUSION (53S35)		17	4-057-604-01	GUIDE, LED / IR	
	4-057-324-11	PLATE (F), DIFFUSION (46C36)		18	* A-1372-304-A	HA BOARD, COMPLETE (46C36)	
	4-058-455-11	PLATE (F), DIFFUSION (48S35)					
4	* 4-048-152-01	HOLDER (S), SCREEN (46C36/48S35)		19	* A-1372-288-A	HA BOARD, COMPLETE (48S35/53S35)	
	* 4-048-152-11	HOLDER (S), SCREEN (53S35)		20	1-505-378-11	SPEAKER (10CM)	
5	* 4-048-159-01	HOLDER (L), SCREEN (46C36)		21	4-048-175-01	FOOT, PLASTIC	
	* 4-048-159-11	HOLDER (L), SCREEN (48S35/53S35)		22	4-040-755-01	CASTER (DIA. 30)	
6	* 4-051-790-02	HOLDER, MIRS (L)			* 4-057-844-01	BOARD (53), REAR (53S35)	
7	* 4-049-098-01	CUSHION					
8	* 4-051-789-02	HOLDER, MIRS (R)		23	* 4-058-556-01	BOARD (48), REAR (48S35)	
9	* 4-037-351-01	PROTECTOR, MIRROR		24	* 4-058-648-01	BOARD (46), REAR (46C36)	
10	4-033-775-41	MIRROR (53), REFLECTION (53S35)		25	X-4034-456-1	PANEL ASSY, CONTROL (46C36)	
11	4-048-181-01	MIRROR (46), REFLECTION (53S35)		26	4-057-605-11	DOOR, CONTROL (46C36)	
	4-048-182-01	MIRROR (46) (46C36)		27	4-843-806-00	STRIKE (46C36)	
12	4-058-545-01	MIRROR (48), REFLECTION (48S35)		28	X-4034-457-1	GRILLE ASSY, SPEAKER (46C36)	
	* 4-057-610-01	COVER, MIRROR (48S35)		29	4-838-438-00	LATCH (46C36)	
					4-057-608-01	SKIRT, FRONT (46C36)	
					4-058-745-01	VELCRO (46C36)	

7-2. COVER (KP-61S35)

● : 7-685-648-79 +BVTP 3X12



REF. NO.	PART NO.	DESCRIPTION	REMARK
51	X-4032-762-1	FRAME ASSY, SCREEN	
52	*4-040-122-01	HOLDER (S), SCREEN	
53	*4-040-120-01	HOLDER (L), SCREEN	
54	4-040-124-01	PLATE (L), DIFFUSION	
55	4-040-123-11	PLATE (F), DIFFUSION	
56	4-041-164-11	SCREW (4X20), TAPPING	
57	4-058-643-01	MIRROR, REFLECTION	
58	*4-049-098-01	CUSHION	
59	*4-058-642-01	BOARD, MIRROR	
60	*4-058-641-01	COVER, TOP REAR	


REF. NO.	PART NO.	DESCRIPTION	REMARK
61	4-057-602-01	GRILLE (61), SPEAKER	
62	4-057-603-01	BUTTON, MULTI	
63	4-057-604-01	GUIDE, LED / IR	
64	*A-1372-288-A	HA BOARD, COMPLETE	
65	1-505-378-11	SPEAKER (10CM)	
66	4-838-438-00	LATCH	
67	4-030-850-01	SOCKET, CASTER	
68	4-040-508-02	CASTER	
69	*4-058-640-01	BOARD, REAR	

7-3. CHASSIS

- : 7-685-648-79 +BVTP 3X12
- ▲ : 7-685-661-14 +BVTP 4X12

The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

Les composants identifiés par une trame et une marque ▲ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.




REF. NO.	PART NO.	DESCRIPTION	REMARK
101	▲ 1-223-925-12	RESISTOR ASSY (HIGH VOLTAGE)	
102	* 4-057-596-01	BRACKET, HV	
103	▲ 8-598-595-20	BLOCK ASSY, HIGH VOLTAGE	
104	4-373-137-01	CAP (Z), RUBBER	
105	* 4-057-594-01	BRACKET, MAIN	
106	4-052-894-01	SCREW (4X20), HEAD TAPPING	
107	* A-1316-295-A	G BOARD, COMPLETE (46C36/53S35)	
108	▲ 1-453-238-11	G BOARD, COMPLETE (48S35/61S35)	
109	▲ 1-769-837-11	TRANSFORMER ASSY, FLYBACK (NX-4007/IX4A4) CORD, POWER/WITH NOISE FILTER (7.0A/125V)	
110	* A-1297-946-A	A BOARD, COMPLETE (except 46C36)	111
111	* A-1298-009-A	A BOARD, COMPLETE (46C36 only)	111
112	* A-1195-103-A	P BOARD, COMPLETE	
113	▲ 8-598-339-00	TUNER BITE-1A02	
114	▲ 8-598-340-00	TUNER BITE-WA04	
115	* 1-557-056-41	CABLE, P-P	
116	1-556-945-21	CABLE, P-P	
117	8-598-414-00	ANTENNA SWITCH AS-2F	
	4-057-595-01	TERMINAL BOARD (48S35/53S35/61S35)	
	4-057-595-21	TERMINAL BOARD (46C36)	

7-4. PICTURE TUBE

▲ : 7-685-661-14 +BVTP 4X12

The components identified by shading and mark ▲ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une trame et une marque ▲ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.



REF. NO.	PART NO.	DESCRIPTION	REMARK
151	4-040-131-01	LENS (LINNIT POINT 6) (61S35)	
152	4-056-258-01	LENS (DELTA 78) (46C36/48S35/53S35)	
153	4-040-131-21	LENS (LINNIT POINT 6) (61S35)	
154	4-056-258-01	LENS (DELTA 78) (46C36/48S35/53S35)	
155	▲ 8-733-496-05	PICTURE TUBE 07MAC2(R) (LONG NECK)	(GA) (46C36)
156	▲ 8-733-498-05	PICTURE TUBE 07MAC3 (R) (LONG NECK)	(GA) (48S35/53S35)
157	▲ 8-733-508-05	PICTURE TUBE 07MAC4(R) (61S35)	(GA) (48S35/53S35)
158	▲ 8-733-518-05	PICTURE TUBE 07MAC3 (G) (GC LENS)	(GA) (46C36)
159	▲ 8-733-495-05	PICTURE TUBE 07MAC2(R) (LONG NECK)	(GA) (46C36)
160	▲ 8-733-497-05	PICTURE TUBE 07MAC3 (R) (LONG NECK)	(GA) (48S35/53S35)
161	155	156	157
162	158	159	160
163	161	162	163
164	164	165	166
165	166	167	168
166	167	168	169
167	168	169	
168	169		

REF. NO.	PART NO.	DESCRIPTION	REMARK
155	▲ 8-733-497-05	PICTURE TUBE 07MAC4(R) (61S35)	
156	4-048-142-01	SPRING, TENSION	
157	▲ 1-451-452-11	DEFLECTION YOKE (R) (G)	
158	▲ 1-451-455-21	DEFLECTION YOKE (B)	
159	* A-1390-682-A	ZR BOARD, COMPLETE	
160	* A-1390-683-A	ZG BOARD, COMPLETE	
161	1-452-909-11	MAGNET ASSY, 4 POLE	
162	* A-1331-667-A	CR BOARD, COMPLETE	
163	* A-1331-668-A	CG BOARD, COMPLETE	
164	* A-1331-669-A	CB BOARD, COMPLETE	
165	4-052-894-01	SCREW (4X20), HEAD TAPPING	
166	4-057-612-01	BOARD (L), SIDE (61S35)	
167	4-058-638-01	STAY, CHASSIS (61S35)	
168	4-057-613-01	BOARD (R), SIDE (61S35)	

SECTION 8

ELECTRICAL PARTS LIST

P

NOTE:

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

- The components identified by \blacksquare in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.

- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

When indicating parts by reference number, please include the board name.

- CAPACITORS
PF : μ F

- There are some cases the reference number on one board overlaps on the other board. Therefore, when ordering parts by the reference number, please include the board name.

- RESISTORS
- All resistors are in ohms
- F : nonflammable

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
* A-1195-103-A P BOARD, COMPLETE *****							
<CAPACTOR>							
C3301	1-163-017-00	CERAMIC CHIP 0.0047MF 10%	50V	L3301	1-408-413-00	INDUCTOR 22UH	
C3302	1-164-346-11	CERAMIC CHIP 1MF	16V	L3302	1-410-473-11	INDUCTOR 18UH	
C3303	1-163-038-91	CERAMIC CHIP 0.1MF	25V	L3303	1-408-418-00	INDUCTOR 56UH	
C3304	1-126-960-11	ELECT 1MF	50V	<COIL>			
C3305	1-163-038-91	CERAMIC CHIP 0.1MF	25V	<TRANSISTOR>			
C3306	1-126-967-11	ELECT 47MF	20%	Q3301	8-729-422-27	TRANSISTOR 2SP601A-QRS-TX	
C3307	1-163-038-91	CERAMIC CHIP 0.1MF	16V	Q3305	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
C3308	1-163-231-11	CERAMIC CHIP 15PF	25V	Q3306	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
C3309	1-163-017-00	CERAMIC CHIP 0.0047MF 10%	50V	Q3307	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
C3310	1-164-004-11	CERAMIC CHIP 0.1MF	25V	Q3308	8-729-422-27	TRANSISTOR 2SP601A-QRS-TX	
C3313	1-163-038-91	CERAMIC CHIP 0.1MF	25V	Q3310	8-729-422-27	TRANSISTOR 2SP601A-QRS-TX	
C3314	1-163-038-91	CERAMIC CHIP 0.1MF	25V	Q3312	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
C3315	1-164-346-11	CERAMIC CHIP 1MF	16V	Q3313	8-729-422-27	TRANSISTOR 2SP601A-QRS-TX	
C3319	1-163-031-11	CERAMIC CHIP 0.01MF	50V	<RESISTOR>			
C3320	1-126-960-11	ELECT 1MF	20%	R3301	1-216-075-00	METAL GLAZE 12K	5%
C3321	1-163-239-11	CERAMIC CHIP 33PF	50V	R3302	1-216-043-91	METAL GLAZE 560	5%
C3322	1-163-031-11	CERAMIC CHIP 33PF	50V	R3303	1-216-295-91	CONDUCTOR, CHIP	
C3323	1-163-031-11	CERAMIC CHIP 0.01MF	50V	R3304	1-216-043-91	METAL GLAZE 560	5%
C3324	1-126-967-11	ELECT 47MF	20%	R3306	1-215-882-00	METAL OXIDE 22	2W F
C3325	1-163-038-91	CERAMIC CHIP 0.1MF	25V	R3307	1-216-097-91	METAL GLAZE 100K	5%
C3326	1-163-038-91	CERAMIC CHIP 0.1MF	25V	R3308	1-216-051-00	METAL GLAZE 1.2K	5%
C3327	1-163-038-91	CERAMIC CHIP 0.1MF	25V	R3309	1-216-051-00	METAL GLAZE 1.2K	5%
C3328	1-126-967-11	ELECT 47MF	20%	R3310	1-216-689-11	METAL GLAZE 39K	5%
C3329	1-126-967-11	ELECT 47MF	16V	R3311	1-216-689-11	METAL GLAZE 39K	5%
C3330	1-163-031-11	CERAMIC CHIP 0.01MF	50V	R3312	1-216-037-00	METAL GLAZE 330	5%
C3331	1-126-967-11	ELECT 47MF	20%	R3313	1-216-041-00	METAL GLAZE 470	5%
C3332	1-104-664-11	ELECT 47MF	16V	R3314	1-216-041-00	METAL GLAZE 470	5%
C3333	1-164-695-11	CERAMIC CHIP 0.0022MF 5%	50V	R3315	1-216-041-00	METAL GLAZE 470	5%
C3334	1-163-031-11	CERAMIC CHIP 0.01MF	50V	R3316	1-216-053-00	METAL GLAZE 1.5K	5%
C3335	1-163-038-91	CERAMIC CHIP 0.1MF	25V	R3319	1-216-053-00	METAL GLAZE 1.5K	5%
C3336	1-163-038-91	CERAMIC CHIP 0.1MF	25V	R3321	1-216-053-00	METAL GLAZE 1.5K	5%
C3337	1-164-005-11	CERAMIC CHIP 0.47MF	25V	R3322	1-216-065-00	METAL GLAZE 4.7K	5%
C3338	1-163-141-00	CERAMIC CHIP 0.001MF	50V	R3323	1-216-065-00	METAL GLAZE 4.7K	5%
C3340	1-163-031-11	CERAMIC CHIP 0.01MF	50V	R3324	1-216-065-00	METAL GLAZE 4.7K	5%
C3346	1-163-251-11	CERAMIC CHIP 100PF	50V	R3326	1-216-037-00	METAL GLAZE 330	5%
C3347	1-126-960-11	ELECT 1MF	50V	R3327	1-216-031-00	METAL GLAZE 180	5%
C3348	1-126-967-11	ELECT 47MF	20%	R3328	1-216-037-00	METAL GLAZE 330	5%
C3349	1-163-121-00	CERAMIC CHIP 150PF	50V	R3329	1-216-069-00	METAL GLAZE 6.8K	5%
C3350	1-164-004-11	CERAMIC CHIP 0.1MF	25V	R3330	1-216-035-00	METAL GLAZE 270	5%
C3351	1-163-251-11	CERAMIC CHIP 100PF	50V	R3331	1-216-073-00	METAL GLAZE 10K	5%
<CONNECTOR>							
CN3301	*1-764-816-11	CONNECTOR, BOARD TO BOARD 20P		R3332	1-216-041-00	METAL GLAZE 470	5%
<IC>							
IC3301	8-759-366-24	IC TDA8315T/N3A-T		R3341	1-216-057-00	METAL GLAZE 2.2K	5%
IC3302	8-759-231-53	IC TA7805S		R3342	1-216-057-00	METAL GLAZE 2.2K	5%
IC3303	8-759-361-12	IC SDA9288X		R3343	1-216-049-91	METAL GLAZE 1K	5%
				R3346	1-216-049-91	METAL GLAZE 1K	5%
				R3351	1-216-295-91	CONDUCTOR, CHIP	

REF. NO.	PART NO.	DESCRIPTION	REMARK
R3352	1-216-049-91	METAL GLAZE 1K	5%
R3358	1-216-047-91	METAL GLAZE 820	5%
R3359	1-216-047-91	METAL GLAZE 820	5%
R3360	1-216-053-00	METAL GLAZE 1.5K	5%
R3361	1-216-053-00	METAL GLAZE 1.5K	5%
R3362	1-216-029-00	METAL GLAZE 150	5%
R3363	1-216-031-00	METAL GLAZE 180	5%
R3364	1-216-035-00	METAL GLAZE 270	5%
R3365	1-216-105-91	METAL GLAZE 220K	5%
R3366	1-216-105-91	METAL GLAZE 220K	5%
R3367	1-216-095-00	METAL GLAZE 82K	5%
R3368	1-216-103-00	METAL GLAZE 180K	5%
R3369	1-216-101-00	METAL GLAZE 150K	5%
R3370	1-216-041-00	METAL GLAZE 470	5%
R3371	1-216-095-00	METAL GLAZE 82K	5%
R3372	1-216-041-00	METAL GLAZE 470	5%
R3373	1-216-035-00	METAL GLAZE 270	5%

<CRYSTAL>

X3301	1-567-505-11	OSCILLATOR, CRYSTAL
X3302	1-760-095-21	VIBRATOR, CRYSTAL

* A-1297-946-A A BOARD, COMPLETE (except KP-46C36)

* A-1298-009-A A BOARD, COMPLETE (KP-46C36 only)

4-382-854-11 SCREW (M3X10), P, SW (+)

<CAPACITOR>

C001	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C002	1-126-964-11	ELECT 10MF	50V
C003	1-126-964-11	ELECT 10MF	50V
C004	1-126-933-11	ELECT 100MF	20%
C005	1-126-964-11	ELECT 10MF	20%
C017	1-163-809-11	CERAMIC CHIP 0.047MF	10%
C018	1-163-259-91	CERAMIC CHIP 220PF	5%
C019	1-126-960-11	ELECT 1MF	20%
C021	1-163-243-11	CERAMIC CHIP 47PF	5%
C024	1-164-004-11	CERAMIC CHIP 0.1MF	10%
C025	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C026	1-126-964-11	ELECT 10MF	20%
C027	1-126-935-11	ELECT 470MF	20%
C028	1-126-964-11	ELECT 10MF	20%
C032	1-164-004-11	CERAMIC CHIP 0.1MF	10%
C033	1-163-259-91	CERAMIC CHIP 220PF	5%
C034	1-163-809-11	CERAMIC CHIP 0.047MF	10%
C035	1-104-664-11	ELECT 47MF	25V
C036	1-163-231-11	CERAMIC CHIP 15PF	5%
C037	1-163-237-11	CERAMIC CHIP 27PF	5%
C038	1-126-960-11	ELECT 1MF	20%
C045	1-164-182-11	CERAMIC CHIP 0.0033MF	10%
C046	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C047	1-163-010-11	CERAMIC CHIP 0.0012MF	10%
C048	1-164-005-11	CERAMIC CHIP 0.47MF	25V
C054	1-163-033-91	CERAMIC CHIP 0.022MF	50V
C057	1-163-259-91	CERAMIC CHIP 220PF	5%
C060	1-163-038-91	CERAMIC CHIP 0.1MF	25V
C092	1-163-259-91	CERAMIC CHIP 220PF	5%
C107	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C108	1-104-664-11	ELECT 47MF	25V
C109	1-126-935-11	ELECT 470MF	20%
C110	1-163-231-11	CERAMIC CHIP 15PF	5%
C111	1-163-231-11	CERAMIC CHIP 15PF	5%

REF. NO.	PART NO.	DESCRIPTION	REMARK
C119	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V
C120	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V
C121	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V
C124	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C201	1-126-960-11	ELECT 1MF	20%
C203	1-126-935-11	ELECT 470MF	20%
C204	1-164-004-11	CERAMIC CHIP 0.1MF	10%
C206	1-164-004-11	CERAMIC CHIP 0.1MF	10%
C207	1-164-004-11	CERAMIC CHIP 0.1MF	10%
C208	1-164-004-11	CERAMIC CHIP 0.1MF	10%
C209	1-126-964-11	ELECT 10MF	20%
C210	1-126-964-11	ELECT 10MF	20%
C211	1-126-964-11	ELECT 10MF	20%
C212	1-126-964-11	ELECT 10MF	20%
C213	1-126-964-11	ELECT 10MF	20%
C216	1-126-964-11	ELECT 10MF	20%
C218	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C219	1-126-964-11	ELECT 10MF	20%
C220	1-126-964-11	ELECT 10MF	20%
C221	1-164-004-11	CERAMIC CHIP 0.1MF	10%
C223	1-126-964-11	ELECT 10MF	20%
C224	1-104-664-11	ELECT 47MF	25V
C226	1-126-964-11	ELECT 10MF	20%
C227	1-164-004-11	CERAMIC CHIP 0.1MF	10%
C228	1-104-664-11	ELECT 47MF	25V
C229	1-126-964-11	ELECT 10MF	20%
C230	1-126-964-11	ELECT 10MF	20%
C231	1-126-933-11	ELECT 100MF	20%
C232	1-164-004-11	CERAMIC CHIP 0.1MF	10%
C302	1-126-959-11	ELECT 0.47MF	20%
C303	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C304	1-126-964-11	ELECT 10MF	20%
C305	1-163-231-11	CERAMIC CHIP 15PF	5%
C308	1-164-004-11	CERAMIC CHIP 0.1MF	10%
C309	1-126-933-11	ELECT 100MF	20%
C310	1-163-133-00	CERAMIC CHIP 470PF	50V
C311	1-115-419-11	CERAMIC CHIP 3300PF	5%
C312	1-126-959-11	ELECT 0.47MF	20%
C313	1-137-399-11	FLM 0.1MF	5%
C314	1-137-399-11	FLM 0.1MF	5%
C315	1-137-399-11	FLM 0.1MF	5%
C316	1-164-232-11	CERAMIC CHIP 0.01MF	10%
C317	1-164-232-11	CERAMIC CHIP 0.01MF	10%
C318	1-164-232-11	CERAMIC CHIP 0.01MF	10%
C319	1-164-004-11	CERAMIC CHIP 0.1MF	10%
C320	1-164-004-11	CERAMIC CHIP 0.1MF	10%
C321	1-126-963-11	ELECT 4.7MF	20%
C322	1-130-495-00	MYLAR 0.1MF	5%
C323	1-137-581-11	FLM 0.1MF	5%
C324	1-164-182-11	CERAMIC CHIP 0.0033MF	10%
C325	1-126-959-11	ELECT 0.47MF	20%
C326	1-126-964-11	ELECT 10MF	20%
C327	1-163-141-00	CERAMIC CHIP 0.001MF	5%
C329	1-163-017-00	CERAMIC CHIP 0.0047MF	10%
C330	1-163-263-11	CERAMIC CHIP 330PF	5%
C331	1-126-959-11	ELECT 0.47MF	20%
C332	1-164-232-11	CERAMIC CHIP 0.01MF	10%
C333	1-164-232-11	CERAMIC CHIP 0.01MF	10%
C334	1-163-275-11	CERAMIC CHIP 0.001MF	5%
C335	1-126-935-11	ELECT 470MF	20%
C337	1-126-960-11	ELECT 1MF	20%
C338	1-126-961-11	ELECT 2.2MF	20%
C339	1-126-959-11	ELECT 0.47MF	20%
C342	1-137-399-11	FLM 0.1MF	5%
C344	1-163-251-11	CERAMIC CHIP 100PF	5%
C348	1-126-933-11	ELECT 100MF	20%
C349	1-163-245-11	CERAMIC CHIP 56PF	5%
C351	1-164-004-11	CERAMIC CHIP 0.1MF	10%

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
C401	1-126-964-11	ELECT	10MF 20% 50V	C1517	1-126-964-11	ELECT	10MF 20% 50V
C402	1-126-964-11	ELECT	10MF 20% 50V	C1518	1-126-933-11	ELECT	100MF 20% 16V
C403	1-137-367-11	FILM	0.0033MF 5% 50V	C1519	1-126-933-11	ELECT	100MF 20% 16V
C404	1-137-367-11	FILM	0.0033MF 5% 50V	C1520	1-126-964-11	ELECT	10MF 20% 50V
C405	1-137-399-11	FILM	0.1MF 5% 50V	C1521	1-164-161-11	CERAMIC CHIP 0.0022MF	10% 50V
C406	1-137-399-11	FILM	0.1MF 5% 50V	C1522	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C407	1-126-960-11	ELECT	1MF 20% 50V	C1523	1-163-005-11	CERAMIC CHIP 470PF	10% 50V
C408	1-137-367-11	FILM	0.0033MF 5% 50V	C1524	1-137-150-11	MYLAR	10% 100V
C409	1-137-367-11	FILM	0.0033MF 5% 50V	C1601	1-126-933-11	ELECT	100MF 20% 16V
C410	1-137-399-11	FILM	0.1MF 5% 50V	C1602	1-126-964-11	ELECT	10MF 20% 50V
C411	1-137-399-11	FILM	0.1MF 5% 50V	C1603	1-126-916-11	ELECT	1000MF 20% 6.3V
C412	1-126-933-11	ELECT	100MF 20% 16V	C1604	1-126-934-11	ELECT	220MF 20% 16V
C413	1-128-551-11	ELECT	22MF 20% 25V	C1605	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C414	1-163-038-91	CERAMIC CHIP 0.1MF	25V	C1606	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C415	1-126-964-11	ELECT	10MF 20% 50V	C1607	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C416	1-126-964-11	ELECT	10MF 20% 50V	C1608	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C417	1-126-964-11	ELECT	10MF 20% 50V	C1609	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C418	1-104-664-11	ELECT	47MF 20% 25V	C1610	1-126-933-11	ELECT	100MF 20% 16V
C419	1-126-964-11	ELECT	10MF 20% 50V	C1611	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C420	1-126-964-11	ELECT	10MF 20% 50V	<FILTER BLOCKS>			
C422	1-104-664-11	ELECT	47MF 20% 25V	CM301	1-466-162-81	FILTER BLOCK, COM (CFB-4)	
C424	1-126-961-11	ELECT	2.2MF 20% 50V	<CONNECTOR>			
C425	1-126-935-11	ELECT	470MF 20% 16V	CN001	*1-564-507-11	PLUG, CONNECTOR 4P	
C426	1-126-964-11	ELECT	10MF 20% 50V	CN002	*1-564-511-11	PLUG, CONNECTOR 8P	
C427	1-126-933-11	ELECT	100MF 20% 16V	CN003	*1-774-183-11	CONNECTOR, BOARD TOBOARD10P	
C428	1-126-969-11	ELECT	220MF 20% 50V	CN004	1-573-979-21	CONNECTOR, BOARD TOBOARD 11P	
C429	1-126-967-11	ELECT	47MF 20% 50V	CN301	*1-774-183-11	CONNECTOR, BOARD TOBOARD10P	
C430	1-126-964-11	ELECT	10MF 20% 50V	CN302	*1-564-508-11	PLUG, CONNECTOR 5P	
C431	1-126-969-11	ELECT	220MF 20% 50V	CN303	*1-564-512-11	PLUG, CONNECTOR 9P	
C432	1-136-173-00	FILM	0.47MF 5% 50V	CN305	*1-573-298-21	CONNECTOR, BOARD TO BOARD 20P	
C433	1-137-399-11	FILM	0.1MF 5% 50V	CN401	*1-564-507-11	PLUG, CONNECTOR 4P	
C434	1-128-550-11	ELECT	220MF 20% 50V	CN402	*1-564-506-11	PLUG, CONNECTOR 3P (46C36 only)	
C435	1-137-399-11	FILM	0.1MF 5% 50V	<DIODES>			
C436	1-126-943-11	ELECT	2200MF 20% 25V	D001	8-719-991-33	DIODE 1SS133T-77	
C437	1-126-943-11	ELECT	2200MF 20% 25V	D002	8-719-991-33	DIODE 1SS133T-77	
C440	1-126-964-11	ELECT	10MF 20% 50V	D003	8-719-991-33	DIODE 1SS133T-77	
C441	1-126-964-11	ELECT	10MF 20% 50V	D004	8-719-991-33	DIODE 1SS133T-77	
C1101	1-163-031-11	CERAMIC CHIP 0.01MF	50V	D007	8-719-109-89	DIODE RD5,6ESB2	
C1102	1-163-031-11	CERAMIC CHIP 0.01MF	50V	D010	8-719-109-89	DIODE RD5,6ESB2	
C1103	1-126-933-11	ELECT	100MF 20% 16V	D202	8-719-110-17	DIODE RD10ESB2	
C1104	1-164-161-11	CERAMIC CHIP 0.0022MF	10% 50V	D203	8-719-109-89	DIODE RD5,6ESB2	
C1105	1-126-960-11	ELECT	1MF 20% 50V	D206	8-719-977-28	DIODE DTZ10B	
C1106	1-126-933-11	ELECT	100MF 20% 16V	D207	8-719-977-28	DIODE DTZ10B	
C1107	1-104-664-11	ELECT	47MF 20% 25V	D208	8-719-977-28	DIODE DTZ10B	
C1108	1-126-964-11	ELECT	10MF 20% 50V	D209	8-719-977-28	DIODE DTZ10B	
C1109	1-126-933-11	ELECT	100MF 20% 16V	D210	8-719-977-28	DIODE DTZ10B	
C1110	1-164-161-11	CERAMIC CHIP 0.0022MF	10% 50V	D211	8-719-977-28	DIODE DTZ10B	
C1111	1-126-960-11	ELECT	1MF 20% 50V	D212	8-719-977-28	DIODE DTZ10B	
C1112	1-163-031-11	CERAMIC CHIP 0.01MF	50V	D213	8-719-977-28	DIODE DTZ10B	
C1113	1-126-964-11	ELECT	10MF 20% 50V	D214	8-719-110-17	DIODE RD10ESB2	
C1114	1-163-031-11	CERAMIC CHIP 0.01MF	50V	D215	8-719-110-17	DIODE RD10ESB2	
C1115	1-163-031-11	CERAMIC CHIP 0.01MF	50V	D216	8-719-110-17	DIODE RD10ESB2	
C1116	1-163-031-11	CERAMIC CHIP 0.01MF	50V	D217	8-719-110-17	DIODE RD10ESB2	
C1117	1-163-031-11	CERAMIC CHIP 0.01MF	50V	D218	8-719-110-17	DIODE RD10ESB2	
C1118	1-163-031-11	CERAMIC CHIP 0.01MF	50V	D219	8-719-110-17	DIODE RD10ESB2	
C1119	1-126-968-11	ELECT	100MF 20% 50V	D220	8-719-110-17	DIODE RD10ESB2	
C1120	1-126-933-11	ELECT	100MF 20% 16V	D221	8-719-110-17	DIODE RD10ESB2	
C1501	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V	D222	8-719-110-17	DIODE RD10ESB2	
C1502	1-107-504-11	CERAMIC	10PF 0.5PF 500V	D225	8-719-110-17	DIODE RD10ESB2	
C1503	1-136-177-00	FILM	1MF 5% 50V				
C1506	1-126-969-11	ELECT	220MF 20% 50V				
C1507	1-163-243-11	CERAMIC CHIP 47PF	5% 50V				
C1508	1-137-378-11	FILM	0.22MF 5% 50V				
C1509	1-163-251-11	CERAMIC CHIP 100PF	5% 50V				
C1510	1-126-942-61	ELECT	1000MF 20% 25V				
C1511	1-126-942-61	ELECT	1000MF 20% 25V				
C1513	1-163-031-11	CERAMIC CHIP 0.01MF	50V				
C1514	1-163-031-11	CERAMIC CHIP 0.01MF	50V				

A

REF. NO.	PART NO.	DESCRIPTION	REMARK
D226	8-719-110-17	DIODE RD10ESB2	
D232	8-719-982-26	DIODE MTZ2-33B	
D236	8-719-110-17	DIODE RD10ESB2	
D237	8-719-110-17	DIODE RD10ESB2	
D238	8-719-110-17	DIODE RD10ESB2	
D239	8-719-991-33	DIODE ISS133T-77	
D240	8-719-991-33	DIODE ISS133T-77	
D241	8-719-991-33	DIODE ISS133T-77	
D303	8-719-991-33	DIODE ISS133T-77	
D305	8-719-110-17	DIODE RD10ESB2	
D401	8-719-991-33	DIODE ISS133T-77	
D402	8-719-991-33	DIODE ISS133T-77	
D403	8-719-982-26	DIODE MTZ1-33B	
D405	8-719-991-33	DIODE ISS133T-77	
D406	8-719-991-33	DIODE ISS133T-77	
D408	8-719-991-33	DIODE ISS133T-77	
D410	8-719-982-26	DIODE MTZ1-33B	
D1101	8-719-982-26	DIODE MTZ1-33B	
D1102	8-719-977-28	DIODE DTZ10B (46C36 only)	
D1103	8-719-977-28	DIODE DTZ10B (46C36 only)	
D1104	8-719-977-28	DIODE DTZ10B (46C36 only)	
D1105	8-719-977-28	DIODE DTZ10B (46C36 only)	
D1106	8-719-977-28	DIODE DTZ10B (46C36 only)	
D1107	8-719-977-28	DIODE DTZ10B (46C36 only)	
D1501	8-719-109-89	DIODE RD5.6ESB2	
D1502	8-719-908-03	DIODE GP08D	
<FERRITE BEAD>			
FB1102	1-414-135-11	INDUCTOR CHIP 00UH	
<IC>			
IC001	8-752-874-82	IC CXP85856-008S	
IC002	8-752-861-57	IC CXP85112B-613S	
IC003	8-759-352-91	IC PST9143NL	
IC004	8-759-352-91	IC PST9143NL	
IC007	8-759-518-23	IC X24C04S8	
IC201	8-759-366-78	IC MM1313AD	
IC301	8-752-076-76	IC CXA2025AS	
IC401	8-759-369-39	IC BH3586FS-E2	
IC402	8-759-100-96	IC uPC4586G2	
IC403	8-759-089-13	IC TDA7262	
IC1501	8-759-192-71	IC STV9379	
IC1502	8-759-251-31	IC CA0007AM	
IC1601	8-759-198-03	IC PQ09RF21	
IC1602	8-759-231-53	IC TA7805S	
<JACK>			
J203	1-507-667-00	JACK MIC	
J205	1-774-750-11	JACK BLOCK, PIN	
J206	1-774-749-11	JACK BLOCK, PIN	
J208	1-774-749-11	JACK BLOCK, PIN	
J209	1-774-751-11	TERMINAL BLOCK, S	
<COIL>			
L002	1-410-482-31	INDUCTOR 100UH	
L003	1-410-482-31	INDUCTOR 100UH	
L004	1-216-295-91	CONDUCTOR, CHIP	
L005	1-216-295-91	CONDUCTOR, CHIP	
L006	1-410-470-11	INDUCTOR 100H	
L007	1-410-482-31	INDUCTOR 100UH	
L201	1-410-478-11	INDUCTOR 47UH	
L302	1-410-482-31	INDUCTOR 100UH	
L303	1-410-470-11	INDUCTOR 100H	
L1101	1-410-478-11	INDUCTOR 47UH	
L1103	1-410-478-11	INDUCTOR 47UH	

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK
L1104	1-410-478-11	INDUCTOR 47UH	
L1105	1-410-470-11	INDUCTOR 10UH	
L1106	1-410-478-11	INDUCTOR 47UH	
L1501	1-412-524-11	INDUCTOR 8.2UH	
L1502	1-412-533-21	INDUCTOR 47UH	
L1503	1-412-533-21	INDUCTOR 47UH	
<NEON LAMP>			
NL1501	1-519-108-99	LAMP, NEON	
<IC LINK>			
PS401	1-532-984-11	LINK, IC (2A/90V)	
<TRANSISTOR>			
Q001	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q002	8-729-027-38	TRANSISTOR DTA144EK-A-T146	
Q003	8-729-027-38	TRANSISTOR DTA144EK-A-T146	
Q004	8-729-216-22	TRANSISTOR 2SA1162-G	
Q005	8-729-216-22	TRANSISTOR 2SA1162-G	
Q006	8-729-027-38	TRANSISTOR DTA144EK-A-T146	
Q007	8-729-027-59	TRANSISTOR DTC143TKA-T146	
Q008	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q009	8-729-027-38	TRANSISTOR DTA144EK-A-T146	
Q013	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q015	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q016	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q017	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q201	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q206	8-729-027-56	TRANSISTOR DTC143TKA-T146	
Q207	8-729-027-59	TRANSISTOR DTC144EK-A-T146	
Q209	8-729-027-56	TRANSISTOR DTC143TKA-T146	
Q213	8-729-216-22	TRANSISTOR 2SA1162-G	
Q214	8-729-216-22	TRANSISTOR 2SA1162-G	
Q216	8-729-027-56	TRANSISTOR DTC143TKA-T146	
Q217	8-729-027-56	TRANSISTOR DTC143TKA-T146	
Q218	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q219	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q220	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q226	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q301	8-729-216-22	TRANSISTOR 2SA1162-G	
Q302	8-729-216-22	TRANSISTOR 2SA1162-G	
Q303	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q304	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q305	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q306	8-729-216-22	TRANSISTOR 2SA1162-G	
Q307	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q308	8-729-216-22	TRANSISTOR 2SA1162-G	
Q311	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q312	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q313	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q314	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q402	8-729-027-59	TRANSISTOR DTC144EK-A-T146	
Q403	8-729-027-38	TRANSISTOR DTA144EK-A-T146	
Q405	8-729-216-22	TRANSISTOR 2SA1162-G	
Q406	8-729-216-22	TRANSISTOR 2SA1162-G	
Q408	8-729-027-56	TRANSISTOR DTC143TKA-T146	
Q409	8-729-027-56	TRANSISTOR DTC143TKA-T146	
Q410	8-729-027-56	TRANSISTOR DTC143TKA-T146	
Q411	8-729-027-56	TRANSISTOR DTC143TKA-T146	
Q1101	8-729-027-59	TRANSISTOR DTC144EK-A-T146	
Q1501	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q2105	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	
Q2106	8-729-422-27	TRANSISTOR 2SD601A-QRS-TX	



REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
		<RESISTOR>					
R003	1-216-295-91	CONDUCTOR, CHIP	5%	R074	1-216-049-91	METAL GLAZE 1K	5%
R004	1-216-033-00	METAL GLAZE 220	5%	R075	1-216-049-91	METAL GLAZE 1K	5%
R005	1-216-033-00	METAL GLAZE 220	5%	R076	1-216-033-00	METAL GLAZE 220	5%
R006	1-216-033-00	METAL GLAZE 220	5%				
R007	1-216-081-00	METAL GLAZE 22K	5%	R077	1-216-121-91	METAL GLAZE 1M	5%
				R078	1-216-097-91	METAL GLAZE 100K	5%
R008	1-216-073-00	METAL GLAZE 10K	5%	R080	1-216-073-00	METAL GLAZE 10K	5%
R009	1-216-033-00	METAL GLAZE 220	5%	R081	1-216-033-00	METAL GLAZE 220	5%
R010	1-216-033-00	METAL GLAZE 220	5%	R084	1-216-073-00	METAL GLAZE 10K	5%
R011	1-216-033-00	METAL GLAZE 220	5%				
R012	1-216-033-00	METAL GLAZE 220	5%	R085	1-216-097-91	METAL GLAZE 100K	5%
				R086	1-216-033-00	METAL GLAZE 220	5%
R013	1-216-033-00	METAL GLAZE 220	5%	R087	1-216-073-00	METAL GLAZE 10K	5%
R014	1-216-033-00	METAL GLAZE 220	5%	R088	1-216-065-00	METAL GLAZE 4.7K	5%
R015	1-216-025-91	METAL GLAZE 100	5%	R090	1-216-065-00	METAL GLAZE 4.7K	5%
R016	1-216-025-91	METAL GLAZE 100	5%				
R017	1-216-065-00	METAL GLAZE 4.7K	5%	R091	1-216-057-00	METAL GLAZE 2.2K	5%
				R092	1-216-057-00	METAL GLAZE 2.2K	5%
R018	1-216-065-00	METAL GLAZE 4.7K	5%	R099	1-216-037-00	METAL GLAZE 330	5%
R019	1-216-097-91	METAL GLAZE 100K	5%	R111	1-216-033-00	METAL GLAZE 220	5%
R020	1-216-057-00	METAL GLAZE 2.2K	5%	R112	1-216-033-00	METAL GLAZE 220	5%
R021	1-216-089-91	METAL GLAZE 4.7K	5%				
R023	1-216-065-00	METAL GLAZE 4.7K	5%	R113	1-216-033-00	METAL GLAZE 220	5%
				R115	1-216-033-00	METAL GLAZE 220	5%
R024	1-216-121-91	METAL GLAZE 1M	5%	R117	1-216-033-00	METAL GLAZE 220	5%
R025	1-216-097-91	METAL GLAZE 100K	5%	R118	1-216-033-00	METAL GLAZE 220	5%
R026	1-216-033-00	METAL GLAZE 220	5%	R119	1-216-033-00	METAL GLAZE 220	5%
R027	1-216-065-00	METAL GLAZE 4.7K	5%				
R028	1-216-065-00	METAL GLAZE 4.7K	5%	R120	1-216-033-00	METAL GLAZE 220	5%
				R121	1-216-033-00	METAL GLAZE 220	5%
R030	1-216-073-00	METAL GLAZE 10K	5%	R122	1-216-033-00	METAL GLAZE 220	5%
R031	1-216-065-00	METAL GLAZE 4.7K	5%	R124	1-216-033-00	METAL GLAZE 220	5%
R032	1-216-073-00	METAL GLAZE 10K	5%				
R033	1-216-065-00	METAL GLAZE 4.7K	5%	R125	1-216-033-00	METAL GLAZE 220	5%
R034	1-216-073-00	METAL GLAZE 10K	5%	R127	1-216-033-00	METAL GLAZE 220	5%
				R128	1-216-033-00	METAL GLAZE 220	5%
R035	1-216-065-00	METAL GLAZE 4.7K	5%	R131	1-216-065-00	METAL GLAZE 4.7K	5%
R036	1-216-033-00	METAL GLAZE 220	5%	R132	1-216-065-00	METAL GLAZE 4.7K	5%
R037	1-216-033-00	METAL GLAZE 220	5%				
R038	1-216-089-91	METAL GLAZE 4.7K	5%	R133	1-216-065-00	METAL GLAZE 4.7K	5%
R039	1-216-089-91	METAL GLAZE 4.7K	5%	R147	1-216-057-00	METAL GLAZE 2.2K	5%
				R148	1-216-057-00	METAL GLAZE 2.2K	5%
R040	1-216-065-00	METAL GLAZE 4.7K	5%	R149	1-216-057-00	METAL GLAZE 2.2K	5%
R041	1-216-025-91	METAL GLAZE 100	5%	R154	1-216-025-91	METAL GLAZE 100	5%
R042	1-216-089-91	METAL GLAZE 4.7K	5%				
R043	1-216-065-00	METAL GLAZE 4.7K	5%	R155	1-216-025-91	METAL GLAZE 100	5%
R044	1-216-073-00	METAL GLAZE 10K	5%	R156	1-216-113-00	METAL GLAZE 470K	5%
				R157	1-216-017-91	METAL GLAZE 47	5%
R045	1-216-073-00	METAL GLAZE 10K	5%	R158	1-216-113-00	METAL GLAZE 470K	5%
R046	1-216-049-91	METAL GLAZE 1K	5%	R159	1-216-017-91	METAL GLAZE 47	5%
R047	1-216-057-00	METAL GLAZE 2.2K	5%				
R048	1-216-065-00	METAL GLAZE 4.7K	5%	R160	1-216-113-00	METAL GLAZE 470K	5%
R049	1-216-089-91	METAL GLAZE 4.7K	5%	R161	1-216-017-91	METAL GLAZE 47	5%
				R163	1-216-033-00	METAL GLAZE 220	5%
R050	1-216-073-00	METAL GLAZE 10K	5%	R164	1-216-033-00	METAL GLAZE 220	5%
R051	1-247-807-31	CARBON 100	5%	R165	1-216-033-00	METAL GLAZE 220	5%
R052	1-247-815-91	CARBON 220	5%				
R053	1-216-049-91	METAL GLAZE 1K	5%	R171	1-216-035-00	METAL GLAZE 270	5%
R054	1-216-033-00	METAL GLAZE 220	5%	R172	1-216-035-00	METAL GLAZE 270	5%
				R173	1-216-035-00	METAL GLAZE 270	5%
R055	1-216-033-00	METAL GLAZE 220	5%	R204	1-249-377-11	CARBON 0.47	5%
R056	1-216-121-91	METAL GLAZE 1M	5%	R206	1-216-022-00	METAL GLAZE 75	5%
R057	1-216-049-91	METAL GLAZE 1K	5%				
R058	1-216-049-91	METAL GLAZE 1K	5%	R213	1-216-113-00	METAL GLAZE 470K	5%
R059	1-216-033-00	METAL GLAZE 220	5%	R214	1-216-113-00	METAL GLAZE 470K	5%
				R215	1-216-113-00	METAL GLAZE 470K	5%
R060	1-216-033-00	METAL GLAZE 220	5%	R216	1-216-113-00	METAL GLAZE 470K	5%
R061	1-216-049-91	METAL GLAZE 1K	5%	R217	1-216-113-00	METAL GLAZE 470K	5%
R063	1-216-073-00	METAL GLAZE 10K	5%				
R064	1-216-049-91	METAL GLAZE 1K	5%	R218	1-216-022-00	METAL GLAZE 75	5%
R065	1-216-049-91	METAL GLAZE 1K	5%	R219	1-216-113-00	METAL GLAZE 470K	5%
				R220	1-216-113-00	METAL GLAZE 470K	5%
R066	1-216-049-91	METAL GLAZE 1K	5%	R221	1-216-022-00	METAL GLAZE 75	5%
R067	1-216-033-00	METAL GLAZE 220	5%	R222	1-216-022-00	METAL GLAZE 75	5%
R068	1-216-033-00	METAL GLAZE 220	5%				
R070	1-216-033-00	METAL GLAZE 220	5%	R223	1-216-022-00	METAL GLAZE 75	5%
R071	1-216-033-00	METAL GLAZE 220	5%	R224	1-216-017-91	METAL GLAZE 47	5%
				R225	1-216-057-00	METAL GLAZE 2.2K	5%
R072	1-216-033-00	METAL GLAZE 220	5%	R227	1-216-019-00	METAL GLAZE 56	5%
R073	1-216-033-00	METAL GLAZE 220	5%	R229	1-216-049-91	METAL GLAZE 1K	5%

F



REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
R230	1-216-113-00	METAL GLAZE 470K	5% 1/10W	R333	1-208-810-11	METAL GLAZE 15K	0.50% 1/10W
R231	1-216-113-00	METAL GLAZE 470K	5% 1/10W	R334	1-216-043-91	METAL GLAZE 560	5% 1/10W
R235	1-216-041-00	METAL GLAZE 470	5% 1/10W	R335	1-216-033-00	METAL GLAZE 220	5% 1/10W
R236	1-216-041-00	METAL GLAZE 470	5% 1/10W	R337	1-216-033-00	METAL GLAZE 220	5% 1/10W
R241	1-216-041-00	METAL GLAZE 470	5% 1/10W	R338	1-216-033-00	METAL GLAZE 220	5% 1/10W
R245	1-216-041-00	METAL GLAZE 470	5% 1/10W	R339	1-216-033-00	METAL GLAZE 220	5% 1/10W
R255	1-216-073-00	METAL GLAZE 10K	5% 1/10W	R340	1-216-025-91	METAL GLAZE 100	5% 1/10W
R258	1-216-089-91	METAL GLAZE 47K	5% 1/10W	R342	1-216-025-91	METAL GLAZE 100	5% 1/10W
R260	1-216-073-00	METAL GLAZE 10K	5% 1/10W	R343	1-216-073-00	METAL GLAZE 10K	5% 1/10W
R261	1-216-065-00	METAL GLAZE 4.7K	5% 1/10W	R344	1-216-067-00	METAL GLAZE 5.6K	5% 1/10W
R262	1-216-095-00	METAL GLAZE 82K	5% 1/10W	R345	1-216-109-00	METAL GLAZE 330K	5% 1/10W
R263	1-216-095-00	METAL GLAZE 82K	5% (46C36 only) 1/10W	R346	1-216-053-00	METAL GLAZE 1.5K	5% 1/10W
R264	1-216-089-91	METAL GLAZE 47K	5% 1/10W	R347	1-216-049-91	METAL GLAZE 1K	5% 1/10W
R265	1-216-097-91	METAL GLAZE 100K	5% 1/10W	R348	1-216-133-00	METAL GLAZE 3.3M	5% 1/10W
R266	1-216-057-00	METAL GLAZE 2.2K	5% 1/10W	R349	1-216-049-91	METAL GLAZE 1K	5% 1/10W
R268	1-216-105-91	METAL GLAZE 220K	5% 1/10W	R350	1-216-049-91	METAL GLAZE 1K	5% 1/10W
R274	1-216-019-00	METAL GLAZE 56	5% 1/10W	R351	1-216-061-00	METAL GLAZE 3.3K	5% 1/10W
R275	1-216-033-00	METAL GLAZE 220	5% 1/10W	R352	1-216-059-00	METAL GLAZE 2.7K	5% 1/10W
R276	1-216-033-00	METAL GLAZE 220	5% 1/10W	R353	1-216-059-00	METAL GLAZE 2.7K	5% 1/10W
R277	1-216-025-91	METAL GLAZE 100	5% 1/10W	R354	1-216-073-00	METAL GLAZE 10K	5% 1/10W
R278	1-216-025-91	METAL GLAZE 100	5% 1/10W	R355	1-216-089-91	METAL GLAZE 47K	5% 1/10W
R279	1-216-025-91	METAL GLAZE 100	5% 1/10W	R356	1-216-025-91	METAL GLAZE 100	5% 1/10W
R280	1-216-041-00	METAL GLAZE 470	5% 1/10W	R357	1-216-049-91	METAL GLAZE 1K	5% 1/10W
R281	1-216-041-00	METAL GLAZE 470	5% (46C36 only) 1/10W	R358	1-216-049-91	METAL GLAZE 1K	5% 1/10W
R282	1-216-041-00	METAL GLAZE 470	5% (46C36 only) 1/10W	R359	1-216-049-91	METAL GLAZE 1K	5% 1/10W
R283	1-216-041-00	METAL GLAZE 470	5% (46C36 only) 1/10W	R360	1-216-065-00	METAL GLAZE 4.7K	5% 1/10W
R284	1-216-041-00	METAL GLAZE 470	5% (46C36 only) 1/10W	R361	1-216-041-00	METAL GLAZE 470	5% 1/10W
R285	1-216-041-00	METAL GLAZE 470	5% (46C36 only) 1/10W	R362	1-216-049-91	METAL GLAZE 1K	5% 1/10W
R286	1-216-025-91	METAL GLAZE 100	5% 1/10W	R363	1-216-077-00	METAL GLAZE 15K	5% 1/10W
R287	1-216-025-91	METAL GLAZE 100	5% 1/10W	R364	1-208-783-11	METAL GLAZE 1.1K	0.50% 1/10W
R288	1-216-025-91	METAL GLAZE 100	5% 1/10W	R365	1-216-081-00	METAL GLAZE 22K	5% 1/10W
R289	1-216-025-91	METAL GLAZE 100	5% 1/10W	R366	1-216-017-91	METAL GLAZE 47	5% 1/10W
R290	1-216-025-91	METAL GLAZE 100	5% 1/10W	R367	1-216-081-00	METAL GLAZE 22K	5% 1/10W
R291	1-216-025-91	METAL GLAZE 100	5% 1/10W	R368	1-216-065-00	METAL GLAZE 4.7K	5% 1/10W
R294	1-216-043-91	METAL GLAZE 560	5% 1/10W	R369	1-216-073-00	METAL GLAZE 10K	5% 1/10W
R295	1-216-073-00	METAL GLAZE 10K	5% 1/10W	R370	1-216-083-00	METAL GLAZE 27K	5% 1/10W
R296	1-216-025-91	METAL GLAZE 100	5% 1/10W	R371	1-216-077-00	METAL GLAZE 15K	5% 1/10W
R297	1-216-093-00	METAL GLAZE 68K	5% 1/10W	R372	1-216-065-00	METAL GLAZE 4.7K	5% 1/10W
R299	1-216-041-00	METAL GLAZE 470	5% 1/10W	R373	1-216-079-00	METAL GLAZE 18K	5% 1/10W
R301	1-216-041-00	METAL GLAZE 470	5% 1/10W	R374	1-216-049-91	METAL GLAZE 1K	5% 1/10W
R302	1-216-049-91	METAL GLAZE 1K	5% 1/10W	R375	1-216-101-00	METAL GLAZE 150K	5% 1/10W
R303	1-216-049-91	METAL GLAZE 1K	5% 1/10W	R376	1-216-097-91	METAL GLAZE 100K	5% 1/10W
R304	1-216-049-91	METAL GLAZE 1K	5% 1/10W	R377	1-216-073-00	METAL GLAZE 10K	5% 1/10W
R305	1-216-033-00	METAL GLAZE 220	5% 1/10W	R378	1-216-057-00	METAL GLAZE 2.2K	5% 1/10W
R306	1-216-041-00	METAL GLAZE 470	5% 1/10W	R379	1-216-073-00	METAL GLAZE 10K	5% 1/10W
R307	1-216-049-91	METAL GLAZE 1K	5% 1/10W	R380	1-216-089-91	METAL GLAZE 47K	5% 1/10W
R308	1-216-017-91	METAL GLAZE 47	5% 1/10W	R381	1-216-097-91	METAL GLAZE 100K	5% 1/10W
R309	1-216-017-91	METAL GLAZE 47	5% 1/10W	R384	1-249-377-11	CARBON	0.47 1/4W F
R310	1-216-017-91	METAL GLAZE 47	5% 1/10W	R401	1-249-377-11	CARBON	0.47 1/4W F
R314	1-216-033-00	METAL GLAZE 220	5% 1/10W	R406	1-216-073-00	METAL GLAZE 10K	5% 1/10W
R315	1-216-033-00	METAL GLAZE 220	5% 1/10W	R407	1-216-025-91	METAL GLAZE 100	5% 1/10W
R319	1-216-033-00	METAL GLAZE 220	5% 1/10W	R408	1-216-025-91	METAL GLAZE 100	5% 1/10W
R320	1-216-033-00	METAL GLAZE 220	5% 1/10W	R412	1-216-073-00	METAL GLAZE 10K	5% 1/10W
R322	1-216-025-91	METAL GLAZE 15K	5% 1/10W	R423	1-216-025-91	METAL GLAZE 100	5% 1/10W
R323	1-216-025-91	METAL GLAZE 100	5% 1/10W	R424	1-216-089-91	METAL GLAZE 47K	5% 1/10W
R324	1-216-025-91	METAL GLAZE 100	5% 1/10W	R425	1-216-041-00	METAL GLAZE 470	5% 1/10W
R325	1-216-025-91	METAL GLAZE 100	5% 1/10W	R427	1-216-053-00	METAL GLAZE 1.5K	5% 1/10W
R326	1-208-786-11	METAL GLAZE 1.5K	0.50% 1/10W	R428	1-216-049-91	METAL GLAZE 1K	5% 1/10W
R327	1-216-049-91	METAL GLAZE 1K	5% 1/10W	R429	1-216-049-91	METAL GLAZE 1K	5% 1/10W
R328	1-216-049-91	METAL GLAZE 1K	5% 1/10W	R430	1-216-053-00	METAL GLAZE 1.5K	5% 1/10W
R330	1-216-025-91	METAL GLAZE 100	5% 1/10W	R432	1-216-081-00	METAL GLAZE 22K	5% 1/10W
R331	1-216-025-91	METAL GLAZE 100	5% 1/10W	R433	1-216-011-00	METAL GLAZE 27	5% 1/10W
R332	1-216-035-00	METAL GLAZE 270	5% 1/10W	R434	1-216-075-00	METAL GLAZE 12K	5% 1/10W

The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

• The components identified by ☒ in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
R435	1-216-075-00	METAL GLAZE 12K	5%	1/10W	C502	1-126-959-11 ELECT	0.47MF 20% 50V
R436	1-216-011-00	METAL GLAZE 27	5%	1/10W	C504	1-102-116-00 CERAMIC	680PF 10% 50V
R437	1-249-418-11	CARBON 1.2K	5%	1/4W F	C505	1-130-471-00 MYLAR	0.001MF 5% 50V
R438	1-249-418-11	CARBON 1.2K	5%	1/4W F	C506	1-126-933-11 ELECT	100MF 20% 16V
R439	1-249-389-11	CARBON 4.7	5%	1/4W F	C507	1-126-965-11 ELECT	22MF 20% 50V
R440	1-249-389-11	CARBON 4.7	5%	1/4W F	C508	1-102-212-00 CERAMIC	820PF 10% 500V
R441	1-216-073-00	METAL GLAZE 10K	5%	1/10W	C509	1-106-383-00 MYLAR	0.047MF 10% 200V
R442	1-216-025-91	METAL GLAZE 100	5%	1/10W	C510	1-102-002-00 CERAMIC	680PF 10% 500V
R443	1-216-295-91	CONDUCTOR, CHIP			C511	1-130-475-00 MYLAR	0.0022MF 5% 50V
R444	1-216-295-91	CONDUCTOR, CHIP			C512	1-130-471-00 FILM	0.001MF 5% 50V
R1105	1-216-689-11	METAL GLAZE 39K	5%	1/10W	C513	1-126-965-11 ELECT	22MF 20% 50V
R1106	1-216-083-00	METAL GLAZE 27K	5%	1/10W	C514	Δ 1-136-334-91 CERAMIC	0.033MF 5% 2KV
R1107	1-216-065-00	METAL GLAZE 4.7K	5%	2W F	C515	Δ 1-136-334-91 FILM	0.0145MF 5% 630V
R1108	1-215-900-11	METAL OXIDE 22K	5%	2W F	C516	Δ 1-136-084-11 FILM	0.0145MF 5% 2KV
R1501	1-216-354-11	METAL OXIDE 2.7	5%	1W F	C518	1-130-495-00 MYLAR	0.1MF 5% 50V
R1502	1-216-073-00	METAL GLAZE 10K	5%	1/10W	C519	1-106-359-00 MYLAR	0.0047MF 10% 100V
R1504	1-216-073-00	METAL GLAZE 10K	5%	1/10W	C520	1-162-116-00 CERAMIC	680PF 10% 2KV
R1506	1-215-888-00	METAL OXIDE 220	5%	2W F	C521	1-162-116-00 CERAMIC	680PF 10% 2KV
R1507	1-216-081-00	METAL GLAZE 22K	5%	1/10W	C522	1-113-506-11 FILM	0.75MF 5% 200V
R1508	1-249-383-11	CARBON 1.5	5%	1/4W F	C524	1-106-359-00 MYLAR	0.0047MF 10% 100V
R1509	1-216-073-00	METAL GLAZE 10K	5%	1/10W	C526	1-102-228-00 CERAMIC	470PF 10% 500V
R1510	1-216-073-00	METAL GLAZE 10K	5%	1/10W	C527	1-126-967-11 ELECT	47MF 20% 50V
R1511	1-216-057-00	METAL GLAZE 2.2K	5%	1/10W	C528	1-107-649-11 ELECT	2.2MF 20% 250V
R1518	1-216-354-11	METAL OXIDE 2.7	5%	1W F	C529	1-136-541-11 FILM	1.5MF 5% 200V
R1520	1-216-089-91	METAL GLAZE 47K	5%	1/10W	C530	1-110-626-11 ELECT	330MF 20% 160V
R1522	1-216-089-91	METAL GLAZE 47K	5%	1/10W	C531	1-126-971-11 ELECT	470MF 20% 50V
R1523	1-216-073-00	METAL GLAZE 10K	5%	1/10W	C532	1-126-971-11 ELECT	470MF 20% 50V
R1524	1-216-097-91	METAL GLAZE 100K	5%	1/10W	C533	1-128-562-11 ELECT	47MF 20% 100V
R1525	1-215-456-00	METAL 30K	1%	1/4W	C535	1-106-387-00 MYLAR	0.068MF 10% 200V
R1526	1-215-456-00	METAL 30K	1%	1/4W	C536	1-137-374-11 FILM	0.047MF 5% 50V
R1527	1-216-097-91	METAL GLAZE 100K	5%	1/10W	C537	1-126-968-11 ELECT	100MF 20% 50V
R1528	1-216-089-91	METAL GLAZE 47K	5%	1/10W	C538	1-126-968-11 ELECT	100MF 20% 50V
R1529	1-216-025-91	METAL GLAZE 100	5%	1/10W	C539	1-162-114-00 CERAMIC	0.0047MF 2KV
R2106	1-216-025-91	METAL GLAZE 100	5%	1/10W	C540	1-130-487-00 MYLAR	0.022MF 5% 50V
R2109	1-216-041-00	METAL GLAZE 470	5%	1/10W	C541	1-130-489-00 MYLAR	0.033MF 5% 50V
R2110	1-216-073-00	METAL GLAZE 10K	5%	1/10W	C542	1-126-969-11 ELECT	220MF 20% 50V
R2111	1-216-089-91	METAL GLAZE 47K	5%	1/10W	C544	1-104-665-11 ELECT	100MF 20% 25V
R2112	1-216-065-00	METAL GLAZE 4.7K	5%	1/10W	C545	1-104-665-11 ELECT	100MF 20% 25V
R2201	1-216-041-00	METAL GLAZE 470	5%	1/10W	C546	1-107-637-11 ELECT	22MF 20% 160V
R2202	1-216-041-00	METAL GLAZE 470	5%	1/10W	C548	1-102-244-00 CERAMIC	220PF 10% 500V
R2203	1-216-025-91	METAL GLAZE 100	5%	1/10W	C550	1-126-935-11 ELECT	470MF 20% 16V
R2204	1-216-045-00	METAL GLAZE 680	5%	1/10W	C551	1-126-935-11 ELECT	470MF 20% 16V
R2205	1-216-041-00	METAL GLAZE 470	5%	1/10W	C554	1-136-557-11 FILM	0.0033MF 5% 630V
R2208	1-216-041-00	METAL GLAZE 470	5%	1/10W	C555	1-126-960-11 ELECT	1MF 20% 50V
R2209	1-216-041-00	METAL GLAZE 470	5%	1/10W	C556	1-130-495-00 MYLAR	0.1MF 5% 50V
<THERMISTOR>							
TH1501	1-800-193-00	THERMISTOR			C550	1-126-935-11 ELECT	470MF 20% 16V
<TUNER>							
TU1101	Δ 1-8-598-340-00	TUNER BTF-WA404			C602	Δ 1-113-890-51 CERAMIC	0.0022MF 20% 250V
TU1102	Δ 1-8-598-339-00	TUNER BTF-LA402			C603	1-102-228-00 CERAMIC	470PF 10% 500V
<CRYSTAL>							
X001	1-577-358-21	VIBRATOR, CERAMIC			C604	Δ 1-113-890-51 FILM	0.47MF 20% 125V
X002	1-578-774-11	VIBRATOR, CRYSTAL			C605	Δ 1-113-890-51 CERAMIC	0.0022MF 20% 250V
X301	1-567-505-11	OSCILLATOR, CRYSTAL			C606	Δ 1-136-311-51 FILM	0.47MF 20% 125V
X304	1-577-611-11	OSCILLATOR, CERAMIC			C607	1-125-692-11 ELECT(BLOCK)	820MF 20% 200V
					C608	1-125-692-11 ELECT(BLOCK)	820MF 20% 200V
					C612	1-164-646-11 CERAMIC	2200PF 10% 500V
					C615	1-136-173-00 FILM	0.47MF 5% 50V
					C616	1-136-173-00 FILM	0.47MF 5% 50V
					C617	1-136-169-00 FILM	0.22MF 5% 50V
					C618	1-136-169-00 FILM	0.22MF 5% 50V
					C621	1-129-719-00 FILM	0.027MF 5% 630V

*A-1316-295-A G BOARD, COMPLETE (KP-46C36/53S35)

*A-1316-304-A G BOARD, COMPLETE (KP-48S35/61S35)

*4-057-835-01 PLATE, TRANSFORMER SHIELD
4-382-854-11 SCREW (M3X10), P. SW (+)
7-682-952-09 SCREW +PSW 3X16

<CAPACITOR>



Les composants identifiés par une trame et une marque Δ sont critiqués pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
C651	1-126-804-11	ELECT	100MF	C854	1-126-933-11	ELECT	100MF
C652	1-123-024-21	ELECT	33MF	C857	1-126-933-11	ELECT	100MF
C653	1-104-652-11	ELECT	470MF	C858	1-104-665-11	ELECT	100MF
C654	1-104-652-11	ELECT	470MF	C860	1-126-933-11	ELECT	100MF
C655	1-126-943-11	ELECT	2200MF	C861	1-137-374-11	FILM	0.047MF
C656	1-126-943-11	ELECT	2200MF	C862	1-137-374-11	FILM	0.047MF
C657	1-126-943-11	ELECT	2200MF	C863	1-137-374-11	FILM	0.047MF
C658	1-128-550-11	ELECT	2200MF	C864	1-126-933-11	ELECT	100MF
C659	1-102-074-00	CERAMIC	0.001MF	C865	1-130-471-00	MYLAR	0.001MF
C660	1-126-235-11	ELECT	100MF	C866	1-136-177-00	FILM	1MF
C661	1-102-074-00	CERAMIC	0.001MF	C867	1-101-880-00	CERAMIC	47PF
C662	1-104-664-11	ELECT	47MF	C868	1-101-880-00	CERAMIC	47PF
C663	1-104-664-11	ELECT	47MF	C869	1-130-489-00	MYLAR	0.033MF
C664	1-104-664-11	ELECT	47MF	C871	1-101-880-00	CERAMIC	47PF
C665	1-104-666-11	ELECT	220MF	C872	1-101-880-00	CERAMIC	47PF
C666	1-126-960-11	ELECT	1MF	C873	1-101-880-00	CERAMIC	47PF
C671	1-104-664-11	ELECT	47MF	C880	1-126-961-11	ELECT	2.2MF
C672	1-126-971-11	ELECT	470MF	C881	1-102-973-00	CERAMIC	100PF
C673	1-164-644-11	CERAMIC	330PF	C882	1-102-973-00	CERAMIC	100PF
C675	1-104-665-11	ELECT	100MF	C883	1-102-973-00	CERAMIC	100PF
C676	1-126-960-11	ELECT	1MF	C884	1-104-665-11	ELECT	100MF
C801	1-104-665-11	ELECT	100MF	C885	1-126-961-11	ELECT	2.2MF
C802	1-104-665-11	ELECT	100MF	C886	1-102-973-00	CERAMIC	100PF
C803	1-126-934-11	ELECT	220MF	C887	1-102-973-00	CERAMIC	100PF
C804	1-126-934-11	ELECT	220MF	C888	1-102-973-00	CERAMIC	100PF
C805	1-126-934-11	ELECT	220MF	C889	1-104-665-11	ELECT	100MF
C806	1-126-934-11	ELECT	220MF	C897	1-104-665-11	ELECT	100MF
C807	1-137-374-11	FILM	0.047MF	<CONNECTOR>			
C808	1-137-374-11	FILM	0.047MF	CN501	*1-564-513-11	PLUG, CONNECTOR 10P	
C809	1-137-374-11	FILM	0.047MF	CN502	*1-580-689-11	PIN, CONNECTOR (PC BOARD) 4P	
C810	1-137-374-11	FILM	0.047MF	CN503	*1-580-689-11	PIN, CONNECTOR (PC BOARD) 4P	
C811	1-137-366-11	FILM	0.0022MF	CN504	*1-580-689-11	PIN, CONNECTOR (PC BOARD) 4P	
C812	1-136-169-00	FILM	0.22MF	CN505	*1-506-371-00	PIN, CONNECTOR 2P	
C813	1-137-374-11	FILM	0.047MF	CN506	*1-774-182-11	CONNECTOR, BOARD TO BOARD 10P	
C815	1-104-665-11	ELECT	100MF	CN507	*1-564-507-11	PLUG, CONNECTOR 4P	
C816	1-126-964-11	ELECT	100MF	CN601	*1-580-843-11	PIN, CONNECTOR (POWER)	
C818	1-126-933-11	ELECT	100MF	CN651	*1-774-182-11	CONNECTOR, BOARD TO BOARD 10P	
C819	1-126-964-11	ELECT	10MF	CN652	*1-774-182-11	CONNECTOR, BOARD TO BOARD 10P	
C820	1-102-114-00	CERAMIC	470PF	CN653	*1-573-963-11	PIN, CONNECTOR (PC BOARD) 3P	
C821	1-130-495-00	MYLAR	0.1MF	CN801	*1-564-507-11	PLUG, CONNECTOR 4P	
C823	1-101-880-00	CERAMIC	47PF	CN802	*1-564-507-11	PLUG, CONNECTOR 4P	
C825	1-104-665-11	ELECT	100MF	CN803	*1-564-507-11	PLUG, CONNECTOR 4P	
C826	1-136-165-00	FILM	0.1MF	CN804	*1-774-182-11	CONNECTOR, BOARD TO BOARD 10P	
C827	1-126-960-11	ELECT	1MF	CN805	*1-691-134-11	PIN, CONNECTOR (PC BOARD) 2P	
C828	1-137-366-11	FILM	0.0022MF	<DIODE>			
C829	1-126-959-11	ELECT	0.47MF	D501	8-719-991-33	DIODE 1SS133T-77	
C830	1-130-467-00	FILM	470PF	D502	8-719-991-33	DIODE 1SS133T-77	
C831	1-126-960-11	ELECT	1MF	D504	8-719-921-63	DIODE MT21-7.5B	
C832	1-126-960-11	ELECT	1MF	D507	Δ 8-719-302-43	DIODE EL1Z	
C833	1-126-960-11	ELECT	1MF	D508	8-719-900-26	DIODE ERD29-081	
C834	1-126-968-11	ELECT	100MF	D509	8-719-945-80	DIODE ERC06-15S	
C835	1-126-967-11	ELECT	47MF	D510	8-719-945-80	DIODE ERC06-15S	
C836	1-136-169-00	FILM	0.22MF	D511	8-719-302-43	DIODE EL1Z	
C837	1-126-963-11	ELECT	4.7MF	D513	8-719-302-43	DIODE EL1Z	
C838	1-104-665-11	ELECT	100MF	D514	8-719-908-03	DIODE GP08D	
C839	1-137-374-11	FILM	0.047MF	D515	8-719-908-03	DIODE GP08D	
C840	1-104-665-11	ELECT	100MF	D517	8-719-018-82	DIODE RGP02-20EL-6394	
C841	1-137-374-11	FILM	0.047MF	D519	8-719-991-33	DIODE 1SS133T-77	
C842	1-137-374-11	FILM	0.047MF	D520	8-719-302-43	DIODE EL1Z	
C843	1-126-968-11	ELECT	100MF	D521	8-719-302-43	DIODE EL1Z	
C844	1-126-933-11	ELECT	100MF	D524	8-719-991-33	DIODE 1SS133T-77	
C845	1-126-933-11	ELECT	100MF	D527	8-719-109-85	DIODE RDS 1ESB2	
C846	1-126-933-11	ELECT	100MF	D528	8-719-923-86	DIODE MT21-T-77-15	
C847	1-126-933-11	ELECT	100MF	D602	Δ 8-719-052-84	DIODE LNSB60	
C848	1-126-933-11	ELECT	100MF	D651	8-719-510-26	DIODE DINL20-TA	
C851	1-137-374-11	FILM	0.047MF				
C852	1-137-374-11	FILM	0.047MF				
C853	1-137-374-11	FILM	0.047MF				



The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

REF. NO.	PART NO.	DESCRIPTION	REMARK
D652	8-719-991-33	DIODE 1SS133T-77	
D653	8-719-510-02	DIODE D1NS4	
D654	8-719-022-97	DIODE D2SAMF	
D655	8-719-061-56	DIODE RBA-402L1F-A	
D656	8-719-052-92	DIODE D10SBS4F	
D657	8-719-052-91	DIODE D4SBS4F	
D658	8-719-510-12	DIODE D10SC4M	
D659	8-719-118-59	DIODE RD5,1F-T7B1	
D660	8-719-991-33	DIODE 1SS133T-77	
D661	8-719-200-82	DIODE 11ES2	
D662	8-719-991-33	DIODE 1SS133T-77	
D664	8-719-110-61	DIODE RD24ESB1	
D669	8-719-991-33	DIODE 1SS133T-77	
D670	8-719-921-86	DIODE MTZL-13	
D691	8-719-200-82	DIODE 11ES2	
D692	8-719-200-82	DIODE 11ES2	
D693	8-719-200-82	DIODE 11ES2	
D694	8-719-200-82	DIODE 11ES2	
D801	8-719-110-17	DIODE RD10ESB2	
D802	8-719-110-17	DIODE RD10ESB2	
D803	8-719-110-17	DIODE RD10ESB2	
D804	8-719-110-17	DIODE RD10ESB2	
D820	8-719-109-68	DIODE RD3,6ESB1	
D828	8-719-109-89	DIODE RD5,6ESB2	
D829	8-719-109-84	DIODE RD5,1ESB1	
D835	8-719-109-89	DIODE RD5,6ESB2	
D840	8-719-991-33	DIODE 1SS133T-77	
D842	8-719-991-33	DIODE 1SS133T-77	
D845	8-719-991-33	DIODE 1SS133T-77	
D846	8-719-991-33	DIODE 1SS133T-77	
D847	8-719-982-19	DIODE MTZL-30A	
D848	8-719-923-86	DIODE MTZL-T-77-15	
D849	8-719-110-22	DIODE RD11ESB2	
D850	8-719-109-89	DIODE RD5,6ESB2	
D852	8-719-923-86	DIODE MTZL-T-77-15	
D853	8-719-982-19	DIODE MTZL-30A	
D854	8-719-982-19	DIODE MTZL-30A	
D855	8-719-982-19	DIODE MTZL-30A	
D856	8-719-923-86	DIODE MTZL-T-77-15	
D857	8-719-982-19	DIODE MTZL-30A	
D859	8-719-923-86	DIODE MTZL-T-77-15	
D860	8-719-982-19	DIODE MTZL-30A	
<FUSE>			
F601	Δ 1-532-748-11 FUSE, GLASS TUBE 6.3A/125V		
1-533-223-11 CLIP, FUSE: F601			
<FERRITE BEAD>			
FB501	1-410-397-21	FERRITE BEAD INDUCTOR 1,1UH	
FB651	1-410-396-41	FERRITE BEAD INDUCTOR 0,45UH	
FB652	1-410-396-41	FERRITE BEAD INDUCTOR 0,45UH	
FB653	1-410-396-41	FERRITE BEAD INDUCTOR 0,45UH	
FB654	1-410-396-41	FERRITE BEAD INDUCTOR 0,45UH	
FB655	1-410-396-41	FERRITE BEAD INDUCTOR 0,45UH	
FB656	1-410-396-41	FERRITE BEAD INDUCTOR 0,45UH	
FB657	1-410-396-41	FERRITE BEAD INDUCTOR 0,45UH	
<IC>			
IC501	8-759-133-90	IC uPC339C	
IC601	Δ 8-729-041-12 TRANSISTOR MX0841AB-F		
IC651	Δ 1-810-051-11 POWER MODULE DM-48		
IC652	8-759-012-67	IC MC7905CT	
IC653	8-759-231-53	IC TA7805S	
IC655	8-759-231-58	IC TA7812S	
IC801	8-759-327-51	IC PA0053B	
IC802	8-759-327-51	IC PA0053B	

REF. NO.	PART NO.	DESCRIPTION	REMARK
IC803	8-759-183-37	IC CA0007AD	
IC804	8-759-464-79	IC PM0011AS	
IC805	8-759-711-28	IC NJM2058D	
IC806	8-759-464-79	IC PM0011AS	
IC808	8-759-464-79	IC PM0011AS	
IC809	8-749-012-97	IC STK392-110	
IC810	8-749-012-97	IC STK392-110	
IC811	8-759-634-51	IC M5218AP	
<<COIL>			
L502	1-410-478-11	INDUCTOR 47UH	
L503	1-459-111-00	COIL, DRAM CORE (CD1)	
L506	1-412-552-11	INDUCTOR 2.2mH	
L509	1-412-533-21	INDUCTOR 47UH	
L601	A 1-424-248-11 TRANSFORMER, LINE FILTER		
L651	1-414-158-11	INDUCTOR 2.2UH	
L652	1-414-158-11	INDUCTOR 2.2UH	
L653	1-414-158-11	INDUCTOR 2.2UH	
L654	1-414-158-11	INDUCTOR 2.2UH	
L656	1-412-523-11	INDUCTOR 6.8UH	
L801	1-406-975-21	COIL, CHOKE 47UH	
L802	1-406-975-21	COIL, CHOKE 47UH	
<NEON LAMP>			
NL501	1-519-108-99	LAMP, NEON	
<IC LINK>			
PS601	A 1-533-597-21 LINK, IC		
PS602	A 1-533-597-21 LINK, IC		
<TRANSISTOR>			
Q501	8-729-119-80	TRANSISTOR 2SC2688-LK	
Q502	8-729-024-05	TRANSISTOR 2SD2348(LBS0NY-1)	
Q503	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q504	8-729-823-81	TRANSISTOR 2SC4632LS-CB7	
Q505	8-729-931-45	TRANSISTOR IRF614	
Q506	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q507	8-729-823-81	TRANSISTOR 2SC4632LS-CB7	
Q651	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q652	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q653	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q654	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q655	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q656	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q657	8-729-119-78	TRANSISTOR 2SA1175-HFE	
Q658	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q659	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q660	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q661	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q662	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q802	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q803	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q804	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q805	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q809	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q810	8-729-119-78	TRANSISTOR 2SC2785-HFE	
<RESISTOR>			
R501	1-249-421-11	CARBON 2.2K	5% 1/4W
R502	1-215-879-11	METAL OXIDE 47K	5% 1W
R503	1-247-843-11	CARBON 3.3K	5% 1/4W
R504	1-249-419-11	CARBON 1.5K	5% 1/4W
R506	1-215-444-00	METAL 9.1K	1% 1/4W



• The components identified by **G** in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.

Les composants identifiés par une trame et une marque **G** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by shading and mark **G** are critical for safety. Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
R507	1-249-422-11	CARBON	2.7K 5%	R583	1-249-428-11	CARBON	8.2K 5%
R508	1-260-337-11	CARBON	5.6K 5%	R584	1-247-887-00	CARBON	220K 5%
R509	1-249-437-11	CARBON	47K 5%	R585	1-216-490-11	METAL OXIDE	39K 5%
R510	1-215-919-11	METAL OXIDE	2.2K 5%	R586	1-260-292-11	CARBON	1 5%
R511	1-215-919-11	METAL OXIDE	2.2K 5%	R588	1-247-863-91	CARBON	22K 5%
R512	1-215-919-11	METAL OXIDE	2.2K 5%	R589	1-247-887-00	CARBON	220K 5%
R513	1-249-424-11	CARBON	3.9K 5%	R591	1-215-917-11	METAL OXIDE	1K 5%
G R514	G 1-215-443-00	G METAL	G 8.2K 1%	R601	G 1-219-312-91	G RESISTOR (SURGE RESISTANT) 2.2M	G 3W F
R516	1-215-443-00	METAL	1% 1/4W	R602	G 1-202-981-21	G WIREWOUND	G 0.32 20W F
R517	1-215-449-00	METAL	15K 1%	R608	G 1-202-933-01	G FUSIBLE	G 0.1 10% 1/2W F
R518	1-215-456-00	METAL	30K 1%	R609	1-247-887-00	CARBON	220K 5%
R519	1-247-863-91	CARBON	22K 5%	R610	1-247-887-00	CARBON	220K 5%
R522	1-249-428-11	CARBON	8.2K 5%	R611	1-216-353-00	METAL OXIDE	2.2 5%
R523	1-249-437-11	CARBON	47K 5%	R612	1-247-887-00	CARBON	220K 5%
R524	1-247-863-91	CARBON	22K 5%	R613	1-216-353-00	METAL OXIDE	2.2 5%
R525	1-249-405-11	CARBON	100 5%	R614	1-247-887-00	CARBON	220K 5%
R528	1-215-910-00	METAL OXIDE	68 5%	R651	1-249-429-11	CARBON	10K 5%
R530	1-249-437-11	CARBON	47K 5%	R652	1-249-425-11	CARBON	4.7K 5%
R531	1-260-326-11	CARBON	680 5%	R653	1-249-377-11	CARBON	0.47 5%
R532	1-260-313-51	CARBON	56 5%	R655	1-247-887-00	CARBON	220K 5%
R533	1-214-912-00	METAL	91K 1%	R656	1-260-288-11	CARBON	0.47 5%
R534	1-215-479-00	METAL	270K 1%	R657	1-249-429-11	CARBON	10K 5%
R535	1-247-887-00	CARBON	220K 5%	R658	1-249-417-11	CARBON	1K 5%
R536	1-249-377-11	CARBON	0.47 5%	R664	1-249-425-11	CARBON	4.7K 5%
R537	1-260-336-11	CARBON	4.7K 5%	R665	1-247-807-31	CARBON	100 5%
R538	1-247-863-91	CARBON	22K 5%	R667	1-249-417-11	CARBON	1K 5%
R539	1-249-377-11	CARBON	0.47 5%	R668	1-249-377-11	CARBON	0.47 5%
R540	1-249-379-11	CARBON	0.68 5%	R672	1-249-421-11	CARBON	2.2K 5%
R541	1-247-807-31	CARBON	100 5%	R673	1-249-413-11	CARBON	470 5%
R542	1-215-862-11	METAL OXIDE	68 5%	R675	1-215-417-00	METAL	680 1%
R542	1-215-862-11	METAL OXIDE	68 (48S35/61S35) 1W F	R667	1-249-417-11	CARBON	1K 5%
R542	1-215-864-00	METAL OXIDE	150 5%	R668	1-249-377-11	CARBON	0.47 5%
R544	1-215-862-11	METAL OXIDE	68 5%	R669	1-249-429-11	CARBON	10K 5%
R544	1-215-864-00	METAL OXIDE	150 5%	R672	1-249-421-11	CARBON	2.2K 5%
R545	1-249-377-11	CARBON	0.47 5%	R673	1-249-413-11	CARBON	470 5%
R546	1-249-377-11	CARBON	0.47 5%	R675	1-215-417-00	METAL	680 1%
R547	1-247-807-31	CARBON	100 5%	R676	1-216-369-00	METAL OXIDE	1 5%
R548	1-249-413-11	CARBON	470 5%	R677	1-247-807-31	CARBON	100 5%
R549	1-247-863-91	CARBON	22K 5%	R679	1-249-421-11	CARBON	2.2K 5%
R550	1-247-807-31	CARBON	100 5%	R680	1-249-417-11	CARBON	1K 5%
R551	1-249-437-11	CARBON	47K 5%	R681	1-249-417-11	CARBON	1K 5%
R552	1-247-807-31	CARBON	100 5%	R682	1-249-417-11	CARBON	1K 5%
R553	1-247-881-00	CARBON	120K 5%	R683	1-249-417-11	CARBON	1K 5%
R554	1-249-405-11	CARBON	100 5%	R684	1-249-417-11	CARBON	1K 5%
R555	1-260-123-11	CARBON	100K 5%	R686	1-215-421-00	METAL	1K 1%
R556	1-216-490-11	METAL OXIDE	39K 5%	R687	1-215-441-00	METAL	6.8K 1%
R557	1-216-490-11	METAL OXIDE	39K 5%	R688	1-215-481-00	METAL	330K 1%
R558	1-216-490-11	METAL OXIDE	39K 5%	R689	1-249-425-11	CARBON	4.7K 5%
R559	1-216-490-11	METAL OXIDE	39K 5%	R690	1-249-417-11	CARBON	1K 5%
R560	1-215-399-00	METAL	120 1%	R692	1-249-425-11	CARBON	4.7K 5%
G R561	G 1-249-429-11	G METAL	G 10K 5%	R693	1-249-429-11	CARBON	10K 5%
R563	1-249-429-11	CARBON	10K 5%	R695	1-247-807-31	CARBON	100 5%
R564	1-260-131-11	CARBON	470K 5%	R696	1-249-417-11	CARBON	1K 5%
R565	1-247-807-31	CARBON	100 5%	R697	1-249-417-11	CARBON	1K 5%
R566	1-249-377-11	CARBON	0.47 5%	R801	1-249-437-11	CARBON	47K 5%
R567	1-249-377-11	CARBON	0.47 5%	R803	1-249-430-11	CARBON	12K 5%
R568	1-247-903-00	CARBON	1M 5%	R804	1-249-429-11	CARBON	10K 5%
R569	1-216-392-11	METAL OXIDE	1.8 5%	R805	1-247-807-31	CARBON	100 5%
R570	1-215-910-00	METAL OXIDE	68 5%	R806	1-249-429-11	CARBON	10K 5%
R571	1-249-422-11	CARBON	2.7K 5%	R807	1-247-807-31	CARBON	100 5%
R572	1-247-895-91	CARBON	470K 5%	R808	1-249-429-11	CARBON	10K 5%
R573	1-249-430-11	CARBON	12K 5%	R809	1-249-425-11	CARBON	4.7K 5%
R574	1-249-429-11	CARBON	10K 5%	R810	1-247-807-31	CARBON	100 5%
R577	1-249-422-11	CARBON	2.7K 5%	R811	1-247-807-31	CARBON	100 5%
R579	1-247-895-91	CARBON	470K 5%	R812	1-249-429-11	CARBON	10K 5%
R580	1-249-434-11	CARBON	27K 5%	R813	1-249-429-11	CARBON	10K 5%
R581	1-249-429-11	CARBON	10K 5%	R814	1-247-807-31	CARBON	100 5%
				R815	1-247-807-31	CARBON	100 5%
				R816	1-247-807-31	CARBON	100 5%
				R817	1-247-807-31	CARBON	100 5%



REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
R818	1-249-430-11	CARBON	12K 5% 1/4W	R899	1-247-815-91	CARBON	220 5% 1/4W
R820	1-249-429-11	CARBON	10K 5% 1/4W	R901	1-249-439-11	CARBON	68K 5% 1/4W
R821	1-249-428-11	CARBON	8.2K 5% 1/4W	R902	1-249-438-11	CARBON	56K 5% 1/4W
R822	1-249-417-11	CARBON	1K 5% 1/4W	R903	1-215-421-00	METAL	1K 1% 1/4W
R823	1-249-417-11	CARBON	1K 5% 1/4W	R904	1-214-800-11	METAL	2.2 1% 1/2W
R824	1-215-462-00	METAL	51K 1% 1/4W	R905	1-214-800-11	METAL	2.2 1% 1/2W
R825	1-249-441-11	CARBON	100K 5% 1/4W	R906	1-214-800-11	METAL	2.2 1% 1/2W
R826	1-215-462-00	METAL	51K 1% 1/4W	R907	1-247-815-91	CARBON	220 5% 1/4W
R827	1-249-417-11	CARBON	1K 5% 1/4W	R908	1-247-815-91	CARBON	220 5% 1/4W
R828	1-249-426-11	CARBON	5.6K 5% 1/4W	R909	1-215-421-00	METAL	1K 1% 1/4W
R829	1-249-426-11	CARBON	5.6K 5% 1/4W	R910	1-215-421-00	METAL	1K 1% 1/4W
R830	1-249-414-11	CARBON	560 5% 1/4W	R911	1-215-455-00	METAL	27K 1% 1/4W
R831	1-249-414-11	CARBON	560 5% 1/4W	R912	1-215-469-00	METAL	100K 1% 1/4W
R832	1-249-441-11	CARBON	100K 5% 1/4W	R913	1-215-455-00	METAL	27K 1% 1/4W
R833	1-249-417-11	CARBON	1K 5% 1/4W	R914	1-215-455-00	METAL	27K 1% 1/4W
R834	1-249-441-11	CARBON	100K 5% 1/4W	R915	1-215-455-00	METAL	27K 1% 1/4W
R835	1-249-441-11	CARBON	100K 5% 1/4W	R916	1-215-455-00	METAL	27K 1% 1/4W
R836	1-247-807-31	CARBON	100 5% 1/4W	R917	1-215-455-00	METAL	27K 1% 1/4W
R837	1-249-441-11	CARBON	100K 5% 1/4W	R918	1-215-455-00	METAL	27K 1% 1/4W
R838	1-249-421-11	CARBON	2.2K 5% 1/4W	R919	1-249-435-11	CARBON	33K 5% 1/4W
R841	1-247-815-91	CARBON	220 5% 1/4W	R920	1-214-800-11	METAL	2.2 1% 1/2W
R842	1-247-807-31	CARBON	100 5% 1/4W	R921	1-249-431-11	CARBON	15K 5% 1/4W
R843	1-247-807-31	CARBON	100 5% 1/4W	R922	1-215-445-00	METAL	10K 1% 1/4W
R844	1-247-807-31	CARBON	100 5% 1/4W	R923	1-249-425-11	CARBON	4.7K 5% 1/4W
R845	1-249-441-11	CARBON	100K 5% 1/4W	R924	1-215-444-00	METAL	9.1K 1% 1/4W
R846	1-247-807-31	CARBON	100 5% 1/4W	R925	1-249-425-11	CARBON	4.7K 5% 1/4W
R847	1-215-469-00	METAL	100K 1% 1/4W	R926	1-249-408-11	CARBON	180 5% 1/4W
R850	1-215-469-00	METAL	100K 1% 1/4W	R927	1-215-445-00	METAL	10K 1% 1/4W
R851	1-247-807-31	CARBON	100 5% 1/4W	R928	1-215-445-00	METAL	10K 1% 1/4W
R852	1-247-807-31	CARBON	100 5% 1/4W	R929	1-214-800-11	METAL	2.2 1% 1/2W
R853	1-247-887-00	CARBON	220K 5% 1/4W	R930	1-214-800-11	METAL	2.2 1% 1/2W
R854	1-249-429-11	CARBON	10K 5% 1/4W	R931	1-215-445-00	METAL	10K 1% 1/4W
R855	1-247-815-91	CARBON	220 5% 1/4W	R933	1-215-453-00	METAL	22K 1% 1/4W
R856	1-247-807-31	CARBON	100 5% 1/4W	R934	1-249-429-11	CARBON	10K 5% 1/4W
R857	1-247-807-31	CARBON	100 5% 1/4W	R935	1-249-429-11	CARBON	10K 5% 1/4W
R858	1-215-455-00	METAL	27K 1% 1/4W	R936	1-249-429-11	CARBON	10K 5% 1/4W
R859	1-215-455-00	METAL	27K 1% 1/4W	R937	1-249-435-11	CARBON	33K 5% 1/4W
R860	1-215-455-00	METAL	27K 1% 1/4W	R938	1-215-421-00	METAL	1K 1% 1/4W
R861	1-215-455-00	METAL	27K 1% 1/4W	R939	1-259-878-11	CARBON	1.5M 5% 1/4W
R862	1-215-455-00	METAL	27K 1% 1/4W	R940	1-249-441-11	CARBON	100K 5% 1/4W
R863	1-215-455-00	METAL	27K 1% 1/4W	R941	1-249-441-11	CARBON	100K 5% 1/4W
R865	1-249-424-11	CARBON	3.9K 5% 1/4W	R942	1-249-421-11	CARBON	2.2K 5% 1/4W
R867	1-215-461-00	METAL	47K 1% 1/4W	R943	1-249-441-11	CARBON	100K 5% 1/4W
R868	1-215-445-00	METAL	10K 1% 1/4W	R944	1-215-421-00	METAL	1K 1% 1/4W
R869	1-249-425-11	CARBON	4.7K 5% 1/4W	R945	1-249-429-11	CARBON	10K 5% 1/4W
R871	1-249-417-11	CARBON	1K 5% 1/4W	R946	1-215-421-00	METAL	1K 1% 1/4W
R872	1-249-425-11	CARBON	4.7K 5% 1/4W	R947	1-249-441-11	CARBON	100K 5% 1/4W
R873	1-247-807-31	CARBON	100 5% 1/4W	R948	1-247-815-91	CARBON	220 5% 1/4W
R874	1-249-429-11	CARBON	100K 5% 1/4W	R949	1-247-807-31	CARBON	100 5% 1/4W
R875	1-249-441-11	CARBON	100K 5% 1/4W	R950	1-247-807-31	CARBON	100 5% 1/4W
R879	1-215-444-00	METAL	9.1K 1% 1/4W	R951	1-247-807-31	CARBON	100 5% 1/4W
R880	1-259-878-11	CARBON	1.5M 5% 1/4W	R952	1-247-807-31	CARBON	100 5% 1/4W
R881	1-249-408-11	CARBON	180 5% 1/4W	R953	1-247-863-91	CARBON	22K 5% 1/4W
R882	1-215-445-00	METAL	10K 1% 1/4W	R954	1-215-433-00	METAL	3.3K 1% 1/4W
R883	1-215-445-00	METAL	10K 1% 1/4W	R955	1-215-433-00	METAL	3.3K 1% 1/4W
R884	1-215-445-00	METAL	10K 1% 1/4W	R956	1-249-429-11	CARBON	10K 5% 1/4W
R885	1-249-441-11	CARBON	100K 5% 1/4W	R957	1-214-800-11	METAL	2.2 1% 1/2W
R886	1-249-428-11	CARBON	8.2K 5% 1/4W	R958	1-214-800-11	METAL	2.2 1% 1/2W
R887	1-247-807-31	CARBON	100 5% 1/4W	R959	1-215-433-00	METAL	3.3K 1% 1/4W
R888	1-247-807-31	CARBON	100 5% 1/4W	R961	1-249-425-11	CARBON	4.7K 5% 1/4W
R889	1-249-438-11	CARBON	56K 5% 1/4W	R962	1-214-800-11	METAL	2.2 1% 1/2W
R890	1-249-441-11	CARBON	100K 5% 1/4W	R963	1-214-800-11	METAL	2.2 1% 1/2W
R891	1-249-429-11	CARBON	10K 5% 1/4W	R964	1-215-433-00	METAL	3.3K 1% 1/4W
R892	1-215-445-00	METAL	10K 1% 1/4W	R965	1-215-433-00	METAL	3.3K 1% 1/4W
R895	1-249-421-11	CARBON	2.2K 5% 1/4W	R966	1-247-815-91	CARBON	220 5% 1/4W
R896	1-249-441-11	CARBON	100K 5% 1/4W	R967	1-215-455-00	METAL	27K 1% 1/4W
R897	1-247-807-31	CARBON	100 5% 1/4W	R968	1-215-455-00	METAL	27K 1% 1/4W
R898	1-247-815-91	CARBON	220 5% 1/4W	R969	1-215-455-00	METAL	27K 1% 1/4W



Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifique.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK
R970	1-215-455-00	METAL	27K 1% 1/4W
R971	1-215-455-00	METAL	27K 1% 1/4W
R972	1-215-455-00	METAL	27K 1% 1/4W
R973	1-214-800-11	METAL	2.2 1% 1/2W
R974	1-215-463-00	METAL	56K 1% 1/4W
R975	1-214-800-11	METAL	2.2 1% 1/2W
R976	1-215-433-00	METAL	3.3K 1% 1/4W
R977	1-247-815-91	CARBON	220 5% 1/4W
R978	1-215-445-00	METAL	10K 1% 1/4W
R979	1-249-425-11	CARBON	4.7K 5% 1/4W
R980	1-247-815-91	CARBON	220 5% 1/4W
R981	1-247-815-91	CARBON	220 5% 1/4W
R982	1-247-895-91	CARBON	470K 5% 1/4W
R983	1-247-815-91	CARBON	220 5% 1/4W
R984	1-215-444-00	METAL	9.1K 1% 1/4W
R985	1-215-445-00	METAL	10K 1% 1/4W
R987	1-249-408-11	CARBON	180 5% 1/4W
R988	1-215-445-00	METAL	10K 1% 1/4W
R989	1-249-425-11	CARBON	4.7K 5% 1/4W
R990	1-249-429-11	CARBON	10K 5% 1/4W
R991	1-249-429-11	CARBON	10K 5% 1/4W
R992	1-259-878-11	CARBON	1.5M 5% 1/4W
R993	1-249-425-11	CARBON	4.7K 5% 1/4W
R994	1-249-425-11	CARBON	4.7K 5% 1/4W
R995	1-249-413-11	CARBON	470 5% 1/4W
R996	1-247-815-91	CARBON	220 5% 1/4W
R997	1-215-445-00	METAL	10K 1% 1/4W
R998	1-249-434-11	CARBON	27K 5% 1/4W
R999	1-249-434-11	CARBON	27K 5% 1/4W

<RELAY>

RX601 Δ 1-755-032-11 RELAY

<TRANSFORMER>

T301 Δ 1-433-195-14 TRANSFORMER, HORIZONTAL DRIVE
T302 Δ 1-433-211-11 TRANSFORMER, FERRITE (PMT)
T303 Δ 1-433-212-11 TRANSFORMER, HORIZONTAL LINEAR
T304 Δ 1-433-218-11 TRANSFORMER, ASST. FLYBACK
T603 Δ 1-423-665-11 TRANSFORMER, POWER (NX-4007/IX4A4)
T604 Δ 1-429-992-11 TRANSFORMER, CONVERTER (PRT)
T605 Δ 1-429-985-11 TRANSFORMER, CONVERTER (PTD)

<THERMISTOR>

TH801 1-808-269-11 THERMISTOR

* A-1331-667-A CR BOARD, COMPLETE

<CAPACITOR>

C702 1-102-949-00 CERAMIC 12PF 5% 50V
C703 1-104-664-11 ELECT 47MF 20% 25V
C704 1-126-964-11 ELECT 10MF 20% 50V
C705 1-161-754-00 CERAMIC 0.001MF 10% 2KV
C706 1-126-934-11 ELECT 220MF 20% 16V
C707 1-107-585-11 CERAMIC 5PF 0.25PF 500V
C708 1-102-050-00 CERAMIC 330PF 10% 500V
C709 1-162-115-00 CERAMIC 22MF 20% 2KV
C712 1-107-662-11 ELECT 22MF 20% 250V

REF. NO. PART NO. DESCRIPTION

REMARK

<CONNECTOR>

CN701 1-695-915-11 TAB (CONTACT)
CN702 * 1-564-510-11 PLUG, CONNECTOR 7P
CN703 * 1-564-512-11 PLUG, CONNECTOR 9P
CN704 * 1-508-784-00 PIN, CONNECTOR (5mm PITCH) 1P
CN705 Δ 1-251-182-11 SOCKET, PICTURE TUBE
CN706 * 1-564-512-11 PLUG, CONNECTOR 9P

<DIODE>

D701 8-719-991-33 DIODE 1SS133T-77
D702 8-719-991-33 DIODE 1SS133T-77
D703 8-719-991-33 DIODE 1SS133T-77
D704 8-719-991-33 DIODE 1SS133T-77
D705 8-719-923-86 DIODE MTZ1-T-77-15
D706 8-719-923-86 DIODE MTZ1-T-77-15
D708 8-719-110-17 DIODE RD10ESB2
D709 8-719-109-89 DIODE RD5.6ESB2
D710 8-719-991-33 DIODE 1SS133T-77

<IC>

IC701 8-759-434-39 IC TDA6106Q

<COIL>

L701 1-408-429-00 INDUCTOR 470UH

<NEON LAMP>

NL701 1-519-108-99 LAMP, NEON

<TRANSISTOR>

Q701 8-729-119-76 TRANSISTOR 2SA1175-HFE
Q702 8-729-119-76 TRANSISTOR 2SA1175-HFE

<RESISTOR>

R701 1-219-743-11 RESISTOR (SURGE RESISTANT) 100
R702 1-215-425-00 METAL 1.5K 1% 1/4W
R703 1-215-437-00 METAL 4.7K 1% 1/4W
R704 1-260-132-11 CARBON 560K 5% 1/2W
R705 1-215-424-00 METAL 1.3K 1% 1/4W
R706 1-215-437-00 METAL 4.7K 1% 1/4W
R707 1-249-435-11 CARBON 33K 5% 1/4W
R708 1-215-428-00 METAL 2K 1% 1/4W
R709 1-260-101-11 CARBON 1.5K 5% 1/2W
R710 1-215-903-11 METAL OXIDE 68K 5% 2W F
R711 1-249-435-11 CARBON 33K 5% 1/4W
R712 1-247-807-31 CARBON 100 5% 1/4W
R713 1-249-437-11 CARBON 47K 5% 1/4W
R714 1-260-099-11 CARBON 1K 5% 1/2W
R715 1-260-133-11 CARBON 680K 5% 1/2W
R717 1-249-417-11 CARBON 1K 5% 1/4W
R718 1-247-807-31 CARBON 100 5% 1/4W
R719 1-260-087-11 CARBON 100 5% 1/2W

<SPARK GAP>

SG701 1-519-422-11 GAP, SPARK
SG702 1-519-422-11 GAP, SPARK

The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

CG CB HA

REF. NO.	PART NO.	DESCRIPTION	REMARK
* A-1331-668-A CG BOARD, COMPLETE *****			
<CAPACITOR>			
C732	1-102-949-00	CERAMIC 12PF 5%	50V
C733	1-161-754-00	CERAMIC 0,001MF 10%	2KV
C735	1-102-050-00	CERAMIC 0,01MF 10%	500V
C736	1-162-115-00	CERAMIC 330PF 10%	2KV
C737	1-107-662-11	ELECT 22MF 20%	250V
C743	1-247-807-31	CARBON 100 5%	1/4W
<CONNECTOR>			
CN731	1-695-915-11	TAB (CONTACT)	
CN732	* 1-564-510-11	PLUG, CONNECTOR 7P	
CN733	* 1-564-507-11	PLUG, CONNECTOR 4P	
CN734	* 1-508-784-00	PIN, CONNECTOR (5mm PITCH) 1P	
CN735	Δ 1-251-182-11	SOCKET, PICTURE TUBE	
CN736	* 1-564-512-11	PLUG, CONNECTOR 9P	
CN737	* 1-564-512-11	PLUG, CONNECTOR 9P	
<DIODE>			
D731	8-719-991-33	DIODE 1SS133T-77	
D732	8-719-991-33	DIODE 1SS133T-77	
D733	8-719-110-17	DIODE RD10ESB2	
<IC>			
IC731	8-759-434-39	IC TDA6106Q	
<COIL>			
L731	1-408-429-00	INDUCTOR 470UH	
<NEON LAMP>			
NL731	1-519-108-99	LAMP, NEON	
<RESISTOR>			
R731	1-219-743-11	RESISTOR (SURGE RESISTANT) 100	
R732	1-260-132-11	CARBON 560K 5%	1/2W
R733	1-215-421-00	METAL 1K 1%	1/4W
R735	1-249-441-11	CARBON 100K 5%	1/4W
R736	1-215-430-00	METAL 24K 1%	1/4W
R737	1-260-101-11	CARBON 1.5K 5%	1/2W
R738	1-215-903-11	METAL OXIDE 68K 5%	2W F
R739	1-260-133-11	CARBON 680K 5%	1/2W
R740	1-260-099-11	CARBON 1K 5%	1/2W
R741	1-215-435-00	METAL 3,9K 1%	1/4W
R742	1-247-885-00	CARBON 180K 5%	1/4W
<SPARK GAP>			
SG731	1-519-422-11	GAP, SPARK	
SG732	1-519-422-11	GAP, SPARK	

* A-1331-669-A CB BOARD, COMPLETE *****			
<CAPACITOR>			
C762	1-102-949-00	CERAMIC 12PF 5%	50V

REF. NO.	PART NO.	DESCRIPTION	REMARK
C763	1-161-754-00	CERAMIC 0,001MF 10%	2KV
C765	1-102-050-00	CERAMIC 0,01MF 10%	500V
C766	1-162-115-00	CERAMIC 330PF 10%	2KV
C767	1-107-662-11	ELECT 22MF 20%	250V
<CONNECTOR>			
CN761	1-695-915-11	TAB (CONTACT)	
CN762	* 1-564-507-11	PLUG, CONNECTOR 4P	
CN763	* 1-508-784-00	PIN, CONNECTOR (5mm PITCH) 1P	
CN764	Δ 1-251-182-11	SOCKET, PICTURE TUBE	
CN765	* 1-564-512-11	PLUG, CONNECTOR 9P	
CN766	* 1-564-513-11	PLUG, CONNECTOR 10P	
<DIODE>			
D761	8-719-991-33	DIODE 1SS133T-77	
D762	8-719-923-86	DIODE MTZ1-T-77-15	
D763	8-719-110-17	DIODE RD10ESB2	
D764	8-719-923-86	DIODE MTZ1-T-77-15	
<IC>			
IC761	8-759-434-39	IC TDA6106Q	
<COIL>			
L761	1-408-429-00	INDUCTOR 470UH	
<NEON LAMP>			
NL761	1-519-108-99	LAMP, NEON	
<RESISTOR>			
R761	1-219-743-11	RESISTOR (SURGE RESISTANT) 100	
R762	1-260-132-11	CARBON 560K 5%	1/2W
R763	1-215-420-00	METAL 910 1%	1/4W
R764	1-249-426-11	CARBON 5,6K 5%	1/4W
R765	1-215-430-00	METAL 24K 1%	1/4W
R766	1-260-101-11	CARBON 1.5K 5%	1/2W
R767	1-215-903-11	METAL OXIDE 68K 5%	2W F
R768	1-260-133-11	CARBON 680K 5%	1/2W
R769	1-260-099-11	CARBON 1K 5%	1/2W
R770	1-247-807-31	CARBON 100 5%	1/4W
R771	1-260-087-11	CARBON 100 5%	1/2W
<SPARK GAP>			
SG761	1-519-422-11	GAP, SPARK	
SG762	1-519-422-11	GAP, SPARK	

* A-1372-288-A HA BOARD, COMPLETE *****			
(except KP-46C36)			
* A-1372-304-A HA BOARD, COMPLETE (KP-46C36 only) *****			
<CAPACITOR>			
C1301	1-137-399-11	FILM 0,1MF 5%	50V
C1302	1-126-959-11	ELECT 0,47MF 20%	(46C36 only) 50V
C1304	1-126-964-11	ELECT 10MF 20%	(46C36 only) 50V
C1305	1-137-399-11	FILM 0,1MF 5%	50V (46C36 only)

HA ZR ZG

REF. NO.	PART NO.	DESCRIPTION	REMARK
C1306	1-126-964-11	ELECT	10MF 20% 50V (46C36 only)
C1307	1-126-964-11	ELECT	10MF 20% 50V (46C36 only)
<CONNECTOR>			
CN1301	1-564-523-11	PLUG, CONNECTOR 8P	
CN1302	* 1-564-526-11	PLUG, CONNECTOR 11P (46C36 only)	
CN1304	* 1-564-518-11	PLUG, CONNECTOR 3P (46C36 only)	
<DIODE>			
D1301	8-719-110-17	DIODE RD10ESB2 (46C36 only)	
D1302	8-719-110-17	DIODE RD10ESB2 (46C36 only)	
D1303	8-719-110-17	DIODE RD10ESB2 (46C36 only)	
D1304	8-719-053-43	DIODE SLR-325VCT31	
D1305	8-719-053-43	DIODE SLR-325VCT31	
D1306	8-719-110-17	DIODE RD10ESB2 (46C36 only)	
D1307	8-719-110-17	DIODE RD10ESB2 (46C36 only)	
D1308	8-719-110-17	DIODE RD10ESB2 (46C36 only)	

<I>
IC1301 8-741-780-51 IC SBX1780-51

<JACK>
J1301 1-770-361-11 TERMINAL BLOCK, S (46C36 only)

<RESISTOR>			
R1301	1-249-425-11	CARBON	4.7K 5% 1/4W (46C36 only)
R1302	1-249-416-11	CARBON	820 5% 1/4W
R1303	1-249-417-11	CARBON	1K 5% 1/4W
R1304	1-249-425-11	CARBON	4.7K 5% 1/4W
R1305	1-247-815-91	CARBON	220 5% 1/4W
R1306	1-247-815-91	CARBON	220 5% 1/4W
R1307	1-249-420-11	CARBON	1.8K 5% 1/4W
R1308	1-247-895-91	CARBON	470K 5% 1/4W
R1309	1-247-895-91	CARBON	470K 5% 1/4W
R1310	1-249-429-11	CARBON	10K 5% 1/4W (46C36 only)
R1311	1-247-804-11	CARBON	75 5% 1/4W
R1312	1-247-804-11	CARBON	75 5% 1/4W (46C36 only)
R1314	1-247-807-31	CARBON	100 5% 1/4W
R1315	1-247-804-11	CARBON	75 5% 1/4W (46C36 only)

<SWITCH>
S1301 1-572-198-11 SWITCH, KEYBOARD
S1302 1-572-198-11 SWITCH, KEYBOARD
S1303 1-572-198-11 SWITCH, KEYBOARD
S1304 1-572-198-11 SWITCH, KEYBOARD
S1305 1-572-198-11 SWITCH, KEYBOARD
S1306 1-572-198-11 SWITCH, KEYBOARD
S1307 1-572-198-11 SWITCH, KEYBOARD

REF. NO. PART NO. DESCRIPTION REMARK
* A-1390-682-A ZR BOARD, COMPLETE

<CONNECTOR>
CN1401 * 1-564-510-11 PLUG, CONNECTOR 7P
CN1403 * 1-564-506-11 PLUG, CONNECTOR 3P
CN1404 * 1-564-507-11 PLUG, CONNECTOR 4P
CN1405 * 1-580-689-11 PIN, CONNECTOR (PC BOARD) 4P

<CONNECTOR>
DY1401 1-451-454-11 DEFLECTION YOKE

<RESISTOR>
R1401 1-249-414-11 CARBON 560 5% 1/4W
R1402 1-249-414-11 CARBON 560 5% 1/4W
R1415 1-215-908-00 METAL OXIDE 33 5% 3W F
R1418 1-216-475-11 METAL OXIDE 120 5% 3W F

* A-1390-683-A ZG BOARD, COMPLETE

4-382-854-11 SCREW (M3X10), P. SW (+)

<CAPACITOR>
C1433 1-104-999-11 MYLAR 0.1MF 10% 200V
C1434 1-106-383-00 MYLAR 0.047MF 10% 200V
C1435 1-107-667-11 ELECT 2.2MF 20% 160V
C1436 1-137-364-11 FILM 0.001MF 5% 50V
C1437 1-137-364-11 FILM 0.001MF 5% 50V
C1438 1-106-383-00 MYLAR 0.047MF 10% 200V
C1439 1-161-830-00 CERAMIC 0.0047MF 500V
C1440 1-126-933-11 ELECT 100MF 20% 16V
C1441 1-102-074-00 CERAMIC 0.001MF 10% 50V
C1443 1-126-935-11 ELECT 470MF 20% 16V
C1444 1-107-639-11 ELECT 47MF 20% 160V
C1445 1-126-933-11 ELECT 100MF 20% 16V
C1446 1-126-933-11 ELECT 100MF 20% 16V

<CONNECTOR>
CN1431 * 1-564-508-11 PLUG, CONNECTOR 5P
CN1432 * 1-564-510-11 PLUG, CONNECTOR 7P
CN1433 * 1-564-507-11 PLUG, CONNECTOR 4P
CN1434 * 1-580-689-11 PIN, CONNECTOR (PC BOARD) 4P
CN1461 * 1-564-506-11 PLUG, CONNECTOR 3P
CN1462 * 1-564-507-11 PLUG, CONNECTOR 4P
CN1464 * 1-564-507-11 PLUG, CONNECTOR 4P

<DIODE>
D1431 8-719-110-88 DIODE RD39ESB2
D1432 8-719-110-88 DIODE RD39ESB2
D1433 8-719-991-33 DIODE ISS133T-77

<CONNECTOR>
DY1431 1-451-454-11 DEFLECTION YOKE

<COIL>
L1431 1-410-478-11 INDUCTOR 47UH
L1432 1-410-478-11 INDUCTOR 47UH

The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une tarme et une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

REF. NO.	PART NO.	DESCRIPTION	REMARK
		<TRANSISTOR>	
Q1431	8-729-017-06	TRANSISTOR 2SC4793	
Q1432	8-729-017-05	TRANSISTOR 2SA1837	
Q1433	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q1434	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q1435	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q1436	8-729-119-78	TRANSISTOR 2SC2785-HFE	
		<RESISTOR>	
R1431	1-249-414-11	CARBON 560	5%
R1432	1-249-414-11	CARBON 560	5%
R1433	1-249-377-11	CARBON 0.47	5%
R1435	1-215-908-00	METAL OXIDE 33	5%
R1436	1-216-475-11	METAL OXIDE 120	5%
R1437	1-249-414-11	CARBON 560	5%
R1438	1-249-432-11	CARBON 18K	5%
R1439	1-249-432-11	CARBON 18K	5%
R1440	1-249-414-11	CARBON 560	5%
R1441	1-249-417-11	CARBON 1K	5%
R1442	1-247-815-91	CARBON 220	5%
R1443	1-249-377-11	CARBON 0.47	5%
R1445	1-249-403-11	CARBON 68	5%
R1448	1-249-416-11	CARBON 820	5%
R1449	1-249-403-11	CARBON 68	5%
R1450	1-249-417-11	CARBON 1K	5%
R1451	1-249-411-11	CARBON 330	5%
R1452	1-249-417-11	CARBON 1K	5%
R1453	1-249-401-11	CARBON 47	5%
R1454	1-260-311-11	CARBON 39	5%
R1455	1-249-384-11	CARBON 1.8	5%
R1456	1-215-916-00	METAL OXIDE 680	5%
R1457	1-249-417-11	CARBON 1K	5%
R1458	1-249-384-11	CARBON 1.8	5%
R1459	1-249-400-11	CARBON 39	5%
R1461	1-249-414-11	CARBON 560	5%
R1462	1-249-414-11	CARBON 560	5%
R1463	1-249-399-11	CARBON 33	5%
R1464	1-249-417-11	CARBON 1K	5%
R1465	1-215-908-00	METAL OXIDE 33	5%
R1466	1-216-475-11	METAL OXIDE 120	5%

REF. NO.	PART NO.	DESCRIPTION	REMARK
		MISCELLANEOUS	

Δ 1-223-925-12	RESISTOR ASSY (HIGH VOLTAGE)		
Δ 1-451-454-11	DEFLECTION YOKE (R) (G)		
Δ 1-451-455-21	DEFLECTION YOKE (B)		
1-452-909-11	MAGNET ASSY. 4 POLE		
1-505-378-11	SPEAKER (10CM)		
1-556-945-21	CABLE, P-P		
Δ 1-769-837-11	CORD, POWER (WITH NOISE FILTER)		
8-598-414-00	ANTENNA SWITCH AS-2F		
Δ 8-598-935-11	BLOCK ASSY, HIGH VOLTAGE		
Δ 8-733-495-05	PICTURE TUBE 07MAC7(B) (LONG NECK)		
Δ 8-733-496-05	PICTURE TUBE 07MAC2(B) (LONG NECK)		
Δ 8-733-497-05	PICTURE TUBE 07MAC3(B) (LONG NECK)		
Δ 8-733-499-05	PICTURE TUBE 07MAC3(R) (LONG NECK)		
Δ 8-733-507-05	PICTURE TUBE 07MAC4(B) (G1S35)		
Δ 8-733-508-05	PICTURE TUBE 07MAC4(R) (G1S35)		
Δ 8-733-518-05	PICTURE TUBE 07MAC2(G) (G1C LENS)		

ACCESSORIES AND PACKING MATERIALS

- 3-859-371-31 MANUAL, INSTRUCTION
- 3-701-627-00 BAG, POLYETHYLENE
- 3-859-371-11 MANUAL, INSTRUCTION (G1S35)
- 3-859-371-31 MANUAL, INSTRUCTION (46C36)
- *4-037-674-01 BOARD, TOP (48S35)
- *4-041-426-01 BAG, PROTECTION (except G1S35)
- *4-041-428-01 BAG, POLYETHYLENE (G1S35)
- *4-042-463-01 SHEET, PROTECTION
- *4-047-555-01 PLATE, TOP (G1S35)
- *4-047-774-01 PLATE, TOP (46C36/53S35)
- *4-056-291-01 INDIVIDUAL CARTON (53S35)
- *4-056-292-01 CUSHION (UPPER) (ASSY) (53S35)
- *4-056-293-01 CUSHION (LOWER) (ASSY) (53S35)
- *4-056-298-01 PLATE, BOTTOM (53S35)
- *4-056-300-01 TRAY (53S35)
- *4-057-642-01 CUSHION (UPPER) (ASSY) (G1S35)
- *4-057-643-01 CUSHION (LOWER) (ASSY) (G1S35)
- *4-057-648-01 INDIVIDUAL CARTON (G1S35)
- *4-057-649-01 TRAY (G1S35)
- *4-057-650-01 BOARD, BOTTOM (G1S35)
- *4-057-651-01 CUSHION (UPPER) (ASSY) (48S35)
- *4-057-652-01 CUSHION (LOWER) (ASSY) (48S35)
- *4-057-657-01 INDIVIDUAL CARTON (48S35)
- *4-057-658-01 TRAY (48S35)
- *4-057-659-01 BOARD, BOTTOM (48S35)

REMOTE COMMANDER

- 1-473-749-31 REMOTE COMMANDER (RM-Y136A)
- 4-978-977-01 POCKET, COVER (FOR RM-Y136A)

